


## RC232 Configuration and Communication Tool (CCT) User Manual



### Table of Contents

TABLE OF CONTENTS .....	1
INSTALLATION GUIDE .....	2
SCREEN SETTINGS .....	2
INTRODUCTION .....	2
CONNECTING TO THE MODULE .....	3
TERMINAL MODE .....	3
CYCLICAL TEXT SENDING .....	4
CONFIGURATION MODE .....	5
CHANGING A MODULES PARAMETERS .....	6
CONFIGURATION FILES .....	7
TEST MODES .....	7
RSSI READING .....	8
DOCUMENT REVISION HISTORY .....	9
DISCLAIMER .....	9
TRADEMARKS .....	9
LIFE SUPPORT POLICY .....	9
CONTACT INFORMATION .....	9

## Installation Guide

RC232-CCT Configuration and Communication Tool (CCT) is a part of Radiocrafts' RCTools PC suite tailored for use with Radiocrafts' RF Modules. For full installation procedure please read the RCTools Installation Guide available at [www.radiocrafts.com](http://www.radiocrafts.com).

The CCT requires access to the modules UART via an available COM-port together with access to the modules CONFIG-pin. Typically UART-access is obtained via an UART-to-RS232 or UART-to-USB converter. The Demo Boards (DB) from Radiocrafts contains onboard level shifter for direct plug-in to a PC and further access to the related COM-port.

## Screen Settings

It is recommended to run the application with screen size at least 1024x768 and font resolution 96dpi.

## Introduction

**RC232 Configuration and Communication Tool, CCT**, helps you to work with your Radiocrafts modules. The program enables you to easily configure the module and can additionally work as a terminal window, where data can be sent or received to / from any serial port.




Figure 1. Main window

Connect the DB or your own hardware with the Radiocrafts module to the COM-port. Start the program and the programs main window looks similar to what is shown in Figure 1.

### Connecting to the Module

Before connecting, select the proper settings for your serial port:

- name of an available communication port (COMx)
- baud rate used to communicate with the module




Figure 2. Port settings

To connect to the module you need to press the **connect** button.



Figure 3. Connect button

If you do not know what baud the module is configured for, there is a possibility to detect your baud rate automatically by pressing the autobaud detection button:



Figure 4. Autobaud button

To perform baud auto detection the module will have to enter configuration mode. To do so, you will be asked either to press configuration button on the board or to use a strap connecting RTS line (at UART voltage level) with CONFIG pin on the module. After pressing auto detect button you will be asked to indicate if you are using the strap or if you use configuration button. In the second case, you need to press it **before** continuing auto detection.

When baud rate is detected successfully the program will automatically connect to the board and go into terminal mode.

If the correct baud is not detected properly at first approach, retry the autobaud process.

### Terminal Mode

After pressing the connect button, the program opens a port and enters **terminal mode**. You now have the possibility to send and receive data to / from the selected serial port.





Figure 5. Terminal part of window

Everything written in the bottom line of the terminal part (right side) of the window will be sent to the serial port when <enter> or the arrow-button to the right is pressed. All data sent into the serial port is highlighted blue, and all the data that have been received is highlighted green in the upper part of the window.


**Important:** when blue data appears, it doesn't guarantee that this data has been sent over RF, it has been sent into the serial port only.

To send ASCII characters, type them in and hit *enter* key. To send bytes, you need to use apostrophes. For example, to send three bytes with values: 12, 50, 0xFF you need to write:



**Figure 6. Terminal line with numbers**

Both decimal and hexadecimal values are proper values. You can mix ASCII, decimal and hexadecimal values in one sting like:



**Figure 7. Terminal line with ASCII and numbers**

To send an apostrophe, type double apostrophe.

To clear the terminal window, click the small white paper-icon at top-right.

To save the content of the terminal window perform; *File->Save Terminal Window*, or Ctrl-T.

Drag-and-drop; By drag-and-drop a proper formatted file into the programs terminal window while being in terminal mode, the contents of the file will be sent to the serial port. You will be asked if it should be parsed. By pressing "no", it will be sent as a normal text file as it is written in the file. By pressing "yes" the program will treat every line of the file as a single line entry into the terminal window.

You can select a lines termination sign: none, CR, LF or CF + LF. Line is added to every line sent with a terminal line.

### Cyclical text sending

A selectable text-string can be sent at regular intervals (every second) from terminal mode.



**Figure 8. Send text cyclically**

The sent text is taken from the terminal line at the moment of pressing the button.


### Configuration Mode

To enter configuration mode, press the **configure** button;



**Figure 9. Configuration mode entry button**

Program will wait 15 seconds for a prompt sign, which is sent from the module when configuration mode is entered.




**Figure 10. Waiting for a prompt**

If you use an RTS line to control the CONFIG line into a module, the program asserts RTS low automatically. If you use RTS line for some other purpose, you can disable this feature with the small button next to RTS lines state indicator.



**Figure 11. RTS lines state indicator**



**Figure 12. Configuration mode**

In configuration mode there is easy access to all of the modules parameters. First thing to do after entering communication mode is loading a configuration from the module by pressing the arrow indicating left in “Non-Volatile Configuration Memory” section.



**Figure 13. Loading and sending configuration**

When the configuration is loaded, you can see all the settings of the module. You can also see the modules name and hardware and firmware revisions.



**Figure 14. Modules name and hardware and firmware revisions**

When you load configuration from module, the modules name is identified and a proper data file (\*.rcc) is loaded.



**Figure 15. Model data loaded for RC1240 (example)**

*Your device model and model which the data file is designed for should always match!*


As can be seen from the window, parameters are divided into sections. In volatile memory section there are a total of three parameters that are not stored in a permanent memory, thus they are erased after resetting the module (or power lost). There is no way to check the values of the parameters in volatile memory, so there is only a button for sending entered parameters into the module.

In non-volatile configuration memory section the parameters stored in the permanent memory are found. The parameters having a gray background means they should **not be changed** as this might cause reduced performance.

### Changing a Modules Parameters


To change a parameter, type a value in a “Dec” or “Hex” column in the data grid for decimal or hexadecimal values respectively. To download the settings into the CONFIG memory, press the “send to module” button (right arrow) to send. Only the differences between previously loaded and new typed configurations are sent, as can be seen from the hexadecimal communication towards the module in the terminal window.

When you load a configuration from the module during the communication, the program also loads constraints on all values that you may enter. You can see the constraint in a status bar, when moving the cursor over any row.



**Figure 16. Hint in a status bar**

There is pop-up help on every parameter, just move and hold the cursor over it. There are hints and help for most parameters and parts of the interface.



**Figure 17. Pop-up hint**

When leaving the configuration mode, do so either by pressing the disconnect button or by pressing the terminal mode button.



Figure 18. Terminal mode button

**Important notes:**

1. It is strongly recommended to leave the configuration mode as described above to avoid situations where you start to use the module in your application while the module is still in configuration mode.
2. After entering some values into non-volatile memory you have to reset the module to make them active. Parameters entered into the volatile memory section works immediately after sending.
3. After changing baud rate you have to reconnect at proper baud rate.

**Configuration Files**

Configurations can be stored in .rcc files. After loading a configuration from a module, it can be stored by selecting *File->Save configuration* (Ctrl + S). You can also load a configuration from file. These files are a reflection of all 128 bytes of the configuration memory.

You can load a default configuration by selecting *File->Load defaults->This model* . To do so, you need to be in configuration mode. When you load defaults, all 128 configuration memory bytes are reset to defaults.

The wanted .rcc-file can also be dragged and dropped into the Non-Volatile Configuration Memory window. Always ensure that you are loading a proper configuration file. After dropping the file a prompt will ask if the contents shall be sent to the module or the settings just entered as data in the window.

It may happen that configuration memory is changed in a way so the application cannot resolve what model it is connected to. If so, you should manually select the model that you are using in *File->Load defaults* .

*Be aware that loading defaults or configuration (.rcc) for a different model than you are actually using can cause module malfunction.*

**Test Modes**

For most modules there are available test modes, which can be entered in a dedicated part of the program window.




Figure 19. Test modes

Next to this box there are two buttons to use with test modes:



Figure 20. Buttons for test modes

The left button enables the selected test mode. You can see the sent hex-sequence in the terminal window.

Every time configuration data is sent to the module the CCT-program automatically exits test mode. If you want to change current channel or power and still remain in a test mode, use the


right button with a lock. With this enabled, every time you send data to the volatile memory the selected test mode will be turned on again.

### **RC1280HP** (High Power long range module) special comment:

To meet the maximum time spent in TX-mode (Testmode 1 or 2) according to the modules Data Sheet, a timer exits Testmode 1 and 2 automatically after a predefined period. It is not possible to configure this period. The timer is active only when maximum output power is configured and disabled when the module is configured for any lower power settings. Thus, for continuous operation in Testmode 1 or 2 without time limitations, first configure the module for a lower output power (see RC1280HP Data Sheet and RC232 User Manual).

### **RSSI Reading**

RSSI signal strength is displayed both as the decimal value of the byte received from the module and the calculated dBm-value.



**Figure 21. RSSI reading**

When the module is placed in a Testmode the RSSI reading might not be correct. Leave testmode to display the correct RSSI value.



### Document Revision History

Document Revision	Changes
1.0	New Revision
1.1	Changed chapter "Installation Guide" to match new installation procedure

### Disclaimer

Radiocrafts AS believes the information contained herein is correct and accurate at the time of this printing. However, Radiocrafts AS reserves the right to make changes to this product without notice. Radiocrafts AS does not assume any responsibility for the use of the described product; neither does it convey any license under its patent rights, or the rights of others. The latest updates are available at the Radiocrafts website or by contacting Radiocrafts directly.

As far as possible, major changes of product specifications and functionality, will be stated in product specific Errata Notes published at the Radiocrafts website. Customers are encouraged to check regularly for the most recent updates on products and support tools.

### Trademarks

RC232™ is a trademark of Radiocrafts AS. The RC232™ Embedded RF Protocol is used in a range of products from Radiocrafts. The protocol handles host communication, data buffering, error check, addressing and broadcasting. It supports point-to-point, point-to-multipoint and peer-to-peer network topologies.

All other trademarks, registered trademarks and product names are the sole property of their respective owners.

### Life Support Policy

This Radiocrafts product is not designed for use in life support appliances, devices, or other systems where malfunction can reasonably be expected to result in significant personal injury to the user, or as a critical component in any life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system, or to affect its safety or effectiveness. Radiocrafts AS customers using or selling these products for use in such applications do so at their own risk and agree to fully indemnify Radiocrafts AS for any damages resulting from any improper use or sale.

© 2008, Radiocrafts AS. All rights reserved.

### Contact Information

Web site: [www.radiocrafts.com](http://www.radiocrafts.com)

Address:

**Radiocrafts AS**  
Sandakerveien 64  
NO-0484 OSLO  
NORWAY

Tel: +47 4000 5195

Fax: +47 22 71 29 15

E-mails: [radiocrafts@radiocrafts.com](mailto:radiocrafts@radiocrafts.com)  
[sales@radiocrafts.com](mailto:sales@radiocrafts.com)  
[support@radiocrafts.com](mailto:support@radiocrafts.com)