

1 Products affected

Product hierarchy no. *				Part no.	SBU	Type / Description
SBU	PG	PUG	Type			
03	070	010	0000003400	See list attached	Switches	MCS
03	070	010	0000003407	See list attached	Switches	MSM
03	070	010	0000003408	See list attached	Switches	MPS
03	070	011	0000003420	See list attached	Switches	PSE
03	070	025	0000003456	See list attached	Switches	CPS
03	070	012	0000003439	See list attached	Switches	Indicator
03	070	025	0000003458	See list attached	Switches	CHS
03	070	029	0000003400	See list attached	Switches	TTS
03	070	025	0000003457	See list attached	Switches	MSS

*SBU (2-digit) / PG (3-digit) / PUG (3-digit) / Type (10-digit)

2 Type of change

- Modified label
- Improved identification product configuration code on the label

3 Detailed description of change

All product types listed in section 1 receive a new label layout.

To better visualize the changes, we have used colors and numbers to cluster information into the following sections (The colors and white numbers are not part of the new label layout):

Product identification section: To improve readability, we clustered all the information concerning product identification in this group. To increase clarity, we introduce our product configuration code into this area.	1
Product conformity section: Identical information was slightly rearranged.	2
Product logistics section: Label names changed. Information was slightly rearranged.	3
Product approval section: Identical information was slightly rearranged.	4
Interruption ratings section: Identical information was slightly rearranged.	5
Origin information section: Label for Factory Code was added. Information was slightly rearranged.	6

Product Change Notification					PCN Global Labeling Pt.10		
owner	creation date	release date	released by	change order no	rev	page	D10-062-032
riedlan	07.12.2021	07.12.2021	riedlan	2023131	A	1 of 2	

Old label	New label

4 Reason of change

SCHURTER improves and modernizes the label printing process to increase standardization and harmonize processes throughout all SCHURTER factory locations.

5 Release date

Packaging labels will be changed earliest in week 01/2022 (Date code 2201 or higher on the label).

6 Impact of change and recommended action

Form	No	
Fit	No	
Function	No	
Manufacturing	No	
Label	Yes	No actions required since bar code & 2D-code are not affected by the change.
Packaging	No	

7 Reference Documents / Attachments

Kind of document	Remarks
List of affected articles	List contains a comparison of text/ content between old and new labels in reference to chapter 3. "Product identification section"

Product Change Notification					PCN Global Labeling Pt.10		
owner	creation date	release date	released by	change order no	rev	page	D10-062-032
riedlan	07.12.2021	07.12.2021	riedlan	2023131	A	2 of 2	

P/N	Short Text	Configuration Code
1241.2800	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.2801	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.2802	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BS0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.2805.057	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1057-0C
1241.2805.065	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1065-0C
1241.2805.066	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1066-0C
1241.2805.072	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1072-0C
1241.2805.210	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1210-0C
1241.2805.215	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1215-0C
1241.2805	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-0000-0C
1241.2806.047	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1047-0C
1241.2806.050	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1050-0C
1241.2806.061	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1061-0C
1241.2806.072	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1072-0C
1241.2806.074	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1074-0C
1241.2806.108	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1108-0C
1241.2806.164	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1164-0C
1241.2806.183	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1183-0C
1241.2806	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-0000-0C
1241.2807.003	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1003-0C
1241.2807.005	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1005-0C
1241.2807.037	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1037-0C
1241.2807.047	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1047-0C
1241.2807.049	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1049-0C
1241.2807.101	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1101-0C
1241.2807.102	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1102-0C
1241.2807.130	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1130-0C
1241.2807.131	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1131-0C
1241.2807.152	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1152-0C
1241.2807.163	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1163-0C
1241.2807	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BS0-0000000000-Z0NCB-S3NCWF-0000-0C
1241.2810	MCS19 Switch MO NO 80mA	MCS-19-MONOA08AD0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.2812	MCS19 Switch MO NO 80mA	MCS-19-MONOA08AS0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.2815	MCS19 Switch MO NO 80mA	MCS-19-MONOA08AD0-0000000000-Z0NCB-S3NCWF-0000-0C
1241.2817	MCS19 Switch MO NO 80mA	MCS-19-MONOA08AS0-0000000000-Z0NCB-S3NCWF-0000-0C
1241.2820	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-S0NCB-S3NCWF-0000-0C
1241.2821.037	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1037-0C
1241.2821.038	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1038-0C

1241.2821.047	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1047-0C
1241.2821.058	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1058-0C
1241.2821	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-0000-0C
1241.2822	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BS0-0000000000-S0NCB-S3NCWF-0000-0C
1241.2827	MCS19 Switch MO NO 80mA	MCS-19-MONOA08AD0-0000000000-S0NCB-S3NCWF-0000-0C
1241.2830	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-S0NCB-S3NCWF-0000-0C
1241.2831	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-S0NCB-S3NCWF-0000-0C
1241.2832	MCS19 Switch MO NO 125mA PI 0YL	MCS-19-MONOA12BE0-PI0YL00RE0-S0NCB-S3NCWF-0000-0C
1241.2833	MCS19 Switch MO NO 125mA PI 0RG	MCS-19-MONOA12BE0-PI0RG00RE0-S0NCB-S3NCWF-0000-0C
1241.2834	MCS19 Switch MO NO 125mA PI 0BL	MCS-19-MONOA12BE0-PI0BL00RE0-S0NCB-S3NCWF-0000-0C
1241.2855.015	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-1015-0C
1241.2855.065	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-1065-0C
1241.2855.072	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-1072-0C
1241.2855	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-0000-0C
1241.2856.009	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-Z0NCB-S3NCWF-1009-0C
1241.2856	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-Z0NCB-S3NCWF-0000-0C
1241.2857.057	MCS19 Switch MO NO 125mA PI 0YL	MCS-19-MONOA12BE0-PI0YL00RE0-Z0NCB-S3NCWF-1057-0C
1241.2857.163	MCS19 Switch MO NO 125mA PI 0YL	MCS-19-MONOA12BE0-PI0YL00RE0-Z0NCB-S3NCWF-1163-0C
1241.2857	MCS19 Switch MO NO 125mA PI 0YL	MCS-19-MONOA12BE0-PI0YL00RE0-Z0NCB-S3NCWF-0000-0C
1241.2858.209	MCS19 Switch MO NO 125mA PI 0RG	MCS-19-MONOA12BE0-PI0RG00RE0-Z0NCB-S3NCWF-1209-0C
1241.2858	MCS19 Switch MO NO 125mA PI 0RG	MCS-19-MONOA12BE0-PI0RG00RE0-Z0NCB-S3NCWF-0000-0C
1241.2859	MCS19 Switch MO NO 125mA PI 0BL	MCS-19-MONOA12BE0-PI0BL00RE0-Z0NCB-S3NCWF-0000-0C
1241.2870.3	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0RDB-Z0NCWF-0000-0C
1241.2870.5	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0GNB-Z0NCWF-0000-0C
1241.2872.1	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0YLB-Z0NCWF-0000-0C
1241.2873.3	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0RDB-S3NCWF-0000-0C
1241.2873.5	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0GNB-S3NCWF-0000-0C
1241.2874.1	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0YLB-S3NCWF-0000-0C
1241.2874.4.220	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0BLB-S3NCWF-1220-0C
1241.2874.4	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0BLB-S3NCWF-0000-0C
1241.2874.5	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0GNB-S3NCWF-0000-0C
1241.2875.1	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BS0-0000000000-Z0YLB-S3NCWF-0000-0C
1241.2877.3	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0YLB-S3NCWF-0000-0C
1241.2878.1	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3YLWF-0000-0C
1241.2878.3	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3RDWF-0000-0C
1241.2878.5	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3GNWF-0000-0C
1241.2878.7	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3BKWF-0000-0C
1241.2879.3	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BS0-0000000000-Z0YLB-S3NCWF-0000-0C
1241.6011	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-Z0NCWF-0000-0A

1241.6012	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-0000-0A
1241.6400	MCS30 Switch MO NO 125mA RI ORD	MCS-30-MONOA12BF0-RI0RDVARF0-A0NCA-Z0NCWF-0000-GA
1241.6401	MCS30 Switch MO NO 125mA RI 0GN	MCS-30-MONOA12BF0-RI0GNVARF0-A0NCA-Z0NCWF-0000-GA
1241.6402	MCS30 Switch MO NO 125mA RI 0YL	MCS-30-MONOA12BF0-RI0YLVARF0-A0NCA-Z0NCWF-0000-GA
1241.6403	MCS30 Switch MO NO 125mA RI 0RG	MCS-30-MONOA12BF0-RI0RGVARF0-A0NCA-Z0NCWF-0000-GA
1241.6404	MCS30 Switch MO NO 125mA RI 0BL	MCS-30-MONOA12BF0-RI0BLVARF0-A0NCA-Z0NCWF-0000-GA
1241.6405	MCS30 Switch MO NO 125mA RI 0RD	MCS-30-MONOA12BF0-RI0RDVARF0-A0NCA-S3NCWF-0000-GF
1241.6408	MCS30 Switch MO NO 125mA RI 0RG	MCS-30-MONOA12BF0-RI0RGVARF0-A0NCA-S3NCWF-0000-GF
1241.6413	MCS30 Switch MO NO 125mA RI 0RG	MCS-30-MONOA12BF0-RI0RGVARF0-A0NCA-Z0NCWF-0000-GA
1241.6438	MCS30 Switch MO NO 125mA RI 0RG 24V DC	MCS-30-MONOA12BG0-RI0RG024G0-S0NCA-S3NCWF-0000-AF
1241.6454	MCS30 Switch MO NO 125mA RI RGB	MCS-30-MONOA12BF0-RIRGBVARF0-A0NCA-Z0NCWF-0000-GA
1241.6455	MCS30 Switch MO NO 125mA RI RGY	MCS-30-MONOA12BF0-RIRGYVARF0-A0NCA-Z0NCWF-0000-GA
1241.6456	MCS30 Switch MO NO 125mA RI RGB	MCS-30-MONOA12BF0-RIRGBVARF0-S0NCA-S3NCWF-0000-AF
1241.6457.074	MCS30 Switch MO NO 125mA RI 0GY 12V DC	MCS-30-MONOA12AF1-RI0GY012F1-A0NCA-S3NCWF-1047-GF
1241.6504	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.6505	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RB2-Z0NCB-S3NCWF-0000-0C
1241.6518.057	MCS19 Switch MO NO 125mA PI 0YL	MCS-19-MONOA12BE0-PI0YL00RE0-Z0NCB-S3NCWF-1057-0F
1241.6520	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-S0NCB-S3NCWF-0000-0C
1241.6525	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-0000-0C
1241.6526	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-Z0NCB-S3NCWF-0000-0C
1241.6532	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BG0-0000000000-S0NCB-S3NCWF-0000-0F
1241.6536	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-0000-00
1241.6542.049	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1049-0A
1241.6542.058	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1058-0A
1241.6542.146	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1146-0A
1241.6542	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-0000-0A
1241.6543	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.6545	MCS19 Switch MO NO 125mA PI 0RG	MCS-19-MONOA12BE0-PI0RG00RE0-Z0NCB-S3NCWF-0000-0C
1241.6546	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0YLB-S3NCWF-0000-0C
1241.6547	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-0000-0C
1241.6548	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-Z0NCB-S3NCWF-0000-0C
1241.6549	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-Z0NCWF-0000-0C
1241.6550.071	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1071-0F
1241.6550.074	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1074-0F
1241.6550	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-0000-0F
1241.6551	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-0000-0C
1241.6553	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BF1-PI0GN00RF1-S0NCB-S3NCWF-0000-0C
1241.6554	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BF1-PI0GN00RF1-S0NCB-S3NCWF-0000-0C
1241.6555	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BF1-PI0GN00RF1-S0NCB-S3NCWF-0000-0C

1241.6556	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BF1-PI0GN00RF1-S0NCB-S3NCWF-0000-0C
1241.6560	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BF1-PI0RD00RF1-S0NCB-S3NCWF-0000-0C
1241.6561	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BF1-PI0RD00RF1-S0NCB-S3NCWF-0000-0C
1241.6562	MCS19 Switch MO NO 125mA PI 0BL	MCS-19-MONOA12BF1-PI0BL00RF1-S0NCB-S3NCWF-0000-0C
1241.6657	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BG0-0000000000-S0NCB-S3NCWF-0000-0C
1301.9560	MCS18 Switch MO NO 2A	MCS-18-MONO02ABS0-0000000000-S0NCA-S0NCNF-0-0E
1301.9565	MCS22 Switch MO NO 50mA	MCS-22-MONOA05AS0-0000000000-S0NCA-S0NCNF-0-0E
3-100-455	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-S0NCB-S3NCWF-0000-0F
3-100-456	MCS19 Switch MO NO 125mA PI 0YL	MCS-19-MONOA12BE0-PI0YL00RE0-Z0NCB-S3NCWF-0000-0F
3-100-457	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-Z0NCB-S3NCWF-0000-0F
3-100-654	MCS19 Switch MO NO 125mA PI 0RG	MCS-19-MONOA12BE0-PI0RG00RE0-Z0NCB-S3NCWF-1074-0C
3-101-084	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BG0-0000000000-S0NCB-S3NCWF-0000-0C
3-101-092	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-S0NCB-S3NCWF-1046-0C
3-102-102	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0YLB-S3CRWF-0000-0C
3-103-195	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1221-0C
3-103-196	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1222-0C
3-103-197	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1223-0C
3-103-198	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1224-0C
3-103-199	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1225-0C
3-103-200	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1226-0C
3-103-212	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1227-0C
3-103-213	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1228-0C
3-103-214	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1229-0C
3-103-222	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1230-0C
3-103-223	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1231-0C
3-103-224	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1232-0C
3-103-225	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1233-0C
3-103-226	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1234-0C
3-103-227	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BF1-0000000000-S0NCB-S3NCWF-1235-0C
3-104-218	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1236-0C
3-104-225	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-S0NCB-S3NCWF-1074-0C
3-104-734	MCS30 Switch MO NO 125mA RI RGB	MCS-30-MONOA12BF1-RIRGBVARF1-S0NCA-S3NCWF-0000-AA
3-109-081	MCS16 Switch MO NO 80mA	MCS-16-MONOA08AD0-0000000000-Z0NCB-Z0NCWF-0000-0C
3-109-091	MCS16 Switch MO NO 125mA PI 0RG	MCS-16-MONOA12BE0-PI0RG00RE0-Z0NCB-Z0NCWF-0000-0C
3-109-092	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BD0-0000000000-Z0NCB-Z0NCWF-0000-0C
3-109-094	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BD0-0000000000-Z0NCB-S3NCWF-0000-0C
3-109-095	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BE0-0000000000-Z0NCB-Z0NCWF-0000-0C
3-109-096	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BE0-0000000000-Z0NCB-S3NCWF-0000-0C
3-109-100	MCS16 Switch MO NO 125mA PI 0RG	MCS-16-MONOA12BE0-PI0RG00RE0-Z0NCB-S3NCWF-0000-0C

3-109-104	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BG0-0000000000-S0NCB-S3NCWF-0000-0C
3-109-664	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-S0BKB-S3BKWF-0000-0C
3-110-251	MCS19 Switch MO NO 125mA PI 0WT	MCS-19-MONOA12BE0-PI0WT00RE0-S0NCB-S3NCWF-1239-0C
3-110-809	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1049-0C
3-110-810	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1240-0C
3-110-811	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1241-0C
3-110-959	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-S0NCB-S3NCWF-1239-0C
3-110-960	MCS19 Switch MO NO 125mA PI 0BL	MCS-19-MONOA12BE0-PI0BL00RE0-S0NCB-S3NCWF-1071-0C
3-119-613	MCS19 Switch MO NO 125mA PI 0BL	MCS-19-MONOA12BE0-PI0BL00RE0-Z0NCB-S3NCWF-1074-0C
3-122-279	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1279-0C
3-122-973	MCS19 Switch MO NO 125mA PI 0RG	MCS-19-MONOA12BE0-PI0RG00RE0-S0NCB-S3NCWF-1074-0C
3-128-402	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1242-0C
3-128-952	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1057-0C
3-129-000	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BF1-0000000000-Z0NCB-S3NCWF-1243-00
3-129-001	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BF1-0000000000-Z0NCB-S3NCWF-1244-00
3-129-012	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BF1-0000000000-Z0NCB-S3NCWF-1245-00
3-129-013	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BF1-0000000000-Z0NCB-S3NCWF-1246-00
3-129-221	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BF1-PI0GN00RF1-Z0NCB-S3NCWF-0000-0C
3-131-331	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-Z0NCB-S3NCWF-1072-0C
3-131-397	MCS18 Switch MO NO	MCS-18-MONO000BS0-0000000000-S3NCA-S3NCWF-0000-0A
3-131-505	MCS19 Switch MO NO 125mA PI 0RD	MCS-19-MONOA12BE0-PI0RD00RE0-Z0NCB-S3NCWF-1057-0C
3-131-933	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1074-0C
3-132-093	MCS30 Switch MO NO 125mA RI 0RG	MCS-30-MONOA12BF0-RI0RGVARE0-A0NCA-S3NCWF-1074-GF
3-132-452	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BE0-0000000000-Z0YLB-S3NCNF-1076-0C
3-132-566	MCS19 Switch MO NO 125mA PI 0GN	MCS-19-MONOA12BE0-PI0GN00RE0-S0NCB-S3NCWF-1072-0C
3-133-062	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-S0NCB-S3NCWF-1046-0C
3-134-920	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-S0NCB-S3NCWF-1017-0C
3-135-557	MCS16 Switch MO NO 125mA	MCS-16-MONOA12BE0-0000000000-Z0NCB-S3NCWF-1247-0C
3-135-773	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1176-0C
3-135-774	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1177-0C
3-135-775	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1180-0C
3-135-776	MCS19 Switch MO NO 125mA	MCS-19-MONOA12BD0-0000000000-Z0NCB-S3NCWF-1181-0C
1241.5400.209	MPS 22 Switch C Sym209	MPS-22-MONOA05AA0-S0NCD-S0NCNF-1209-BG
1241.5401.101	MPS 22 Switch C Sym101	MPS-22-MONOA05AA0-S0NCD-A0TINF-1101-BG
1241.5401.207	MPS 22 Switch C Sym207	MPS-22-MONOA05AA0-S0NCD-A0TINF-1207-BG
1241.5401	MPS 22 Switch C	MPS-22-MONOA05AA0-S0NCD-A0TINF-0000-BG
1241.5402.208	MPS 22 Switch C Sym208	MPS-22-MONOA05AA0-S0NCD-A0ORNF-1208-B0
1241.5404.224	MPS 22 Switch C Sym224	MPS-22-MONOA05AA0-S0NCD-A0BLNF-1224-B0
1241.5411.276	MPS 22 Switch C Sym276	MPS-22-MONOA05AA0-S0NCD-A0RDNF-1276-BG

1241.5531.11100000	MPS 22 Switch	MPS-22-MONOA05AA0-S0NCA-S0NCNF-0000-BA
1241.5531.33100000	MPS 22 Switch	MPS-22-MONOA05AA0-A0RDA-A0RDNF-0000-BA
1241.5531.88100000	MPS 22 Switch	MPS-22-MONOA05AA0-A0NCA-A0NCNF-0000-BA
1241.2350	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-P0RDAP0RDWF-0000-FA
1241.2351	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-P0WTAP0WTWF-0000-FA
1241.2352	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-P0ALAP0ALWF-0000-FA
1241.2353	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-P0BKAP0BKWF-0000-FA
1241.2356	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-P0ALAP0ALWF-0000-FA
1241.2358	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-P0RDAP0RDWF-0000-0A
1241.2411.1	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0GDAA0GDWF-0000-FA
1241.2411.3	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0RDAA0RDWF-0000-FA
1241.2411.4	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0BLAA0BLWF-0000-FA
1241.2411.5	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0GNAA0GNWF-0000-FA
1241.2411.7	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0BKAA0BKWF-0000-FA
1241.2411.8	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0NCAA0NCWF-0000-FA
1241.2415.1	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-A0GDAA0GDWF-0000-FA
1241.2415.3	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-A0RDAA0RDWF-0000-FA
1241.2415.4	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-A0BLAA0BLWF-0000-FA
1241.2415.5	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-A0GNAA0GNWF-0000-FA
1241.2415.7	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-A0BKAA0BKWF-0000-FA
1241.2415.8	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-A0NCAA0NCWF-0000-FA
1241.2434.1	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-A0GDAA0GDWF-0000-FA
1241.2434.3	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-A0RDAA0RDWF-0000-FA
1241.2434.4	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-A0BLAA0BLWF-0000-FA
1241.2434.5	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-A0GNAA0GNWF-0000-FA
1241.2434.7	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-A0BKAA0BKWF-0000-FA
1241.2434.8	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-A0NCAA0NCWF-0000-FA
1241.2445	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AG0-0000000000-S0NCAS0NCNF-0000-AA
1241.2446	PSE30 Switch IV NO 1A RI 0RD 24V AC	PSE-30-00IVNO01AF0-RI0RDA24F0-S0NCAS0NCNF-0000-AA
1241.2448	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AC0-0000000000-S0NCAS0NCWF-0000-FA
1241.2450	PSE22 Switch MO NO 100mA PI 0RD	PSE-22-00MONOA10B2-PI0RD00RB2-A0NCAA0NCNF-0000-CA
1241.2475.3	PSE19 EX Switch MO NO 100mA	PSE-19-EXMONOA10D0-0000000000-A0RDAA0RDWF-0000-FA
1241.2475.5	PSE19 EX Switch MO NO 100mA	PSE-19-EXMONOA10D0-0000000000-A0GNAA0GNWF-0000-FA
1241.2475.8	PSE19 EX Switch MO NO 100mA	PSE-19-EXMONOA10D0-0000000000-A0NCAA0NCWF-0000-FA
1241.2495.3	PSE22 EX Switch MO NO 100mA	PSE-22-EXMONOA10D0-0000000000-A0RDAA0RDWF-0000-FA
1241.2495.5	PSE22 EX Switch MO NO 100mA	PSE-22-EXMONOA10D0-0000000000-A0GNAA0GNWF-0000-FA
1241.2495.8	PSE22 EX Switch MO NO 100mA	PSE-22-EXMONOA10D0-0000000000-A0NCAA0NCWF-0000-FA
1241.2611	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-S0NCAS0NCWF-0000-FA
1241.2615	PSE16 EX Switch MO NO 100mA	PSE-16-EXMONOA10D0-0000000000-S0NCAS0NCWF-0000-FA

1241.2903.000	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2RDWF-0000-FA
1241.2903.002	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2RDWF-3002-FA
1241.2903.024	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2RDWF-3024-FA
1241.2904.000	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2GNWF-0000-FA
1241.2904.042	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2GNWF-3042-FA
1241.2918	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-A0GNBA2GNWF-0000-0A
1241.2924.074	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-A0GNBA2GNWF-1074-FA
1241.3000	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-A0RDAA0RDWF-0000-FA
1241.3001	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-A0GNAA0GNWF-0000-FA
1241.3002	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-A0BKAA0BKWF-0000-FA
1241.3003	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-A0NCAA0NCWF-0000-FA
1241.3004	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-S0NCAS0NCWF-0000-AA
1241.3005	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-A0RDAA0RDWF-0000-FA
1241.3006	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-A0GNAA0GNWF-0000-FA
1241.3007	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-A0BKAA0BKWF-0000-FA
1241.3008.074	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-A0NCAA0NCWF-1074-FA
1241.3008	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-A0NCAA0NCWF-0000-FA
1241.3010	PSE24 Switch MO NO 100mA RI 0RG	PSE-24-00MONOA10F0-RI0RGVARF0-A0NCAA0NCWF-0000-FA
1241.3011	PSE27 Switch MO NO 100mA RI 0RG	PSE-27-00MONOA10F0-RI0RGVARF0-A0NCAA0NCWF-0000-FA
1241.3012	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10F0-RI0RGVARF0-A0NCAA0NCWF-0000-FA
1241.3020.M	PSE22 Switch MO NO 100mA PI 0RD 24V DC	PSE-22-00MONOA10F1-PI0RD024F1-A0NCAA0NCWF-0000-FA
1241.3046.8	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF0-0000000000-A0NCAA0NCWF-0000-FA
1241.3047.M	PSE22 Switch MO NO 100mA PI 0YL 24V DC	PSE-22-00MONOA10F1-PI0YL024F1-A0NCAA0NCWF-0000-FA
1241.3057	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10F0-RI0RGVARF0-S0NCAS0NCWF-0000-AA
1241.3058	PSE30 Switch IV NO 1A RI 0RG	PSE-30-00IVNO01AF0-RI0RGVARF0-S0NCAS0NCWF-0000-AA
1241.3060.125	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AF0-0000000000-A0RDAA0RDWF-1125-FA
1241.3063.265	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10C0-0000000000-S0NCAS0NCWF-1265-FA
1241.3063	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10C0-0000000000-S0NCAS0NCWF-0000-FA
1241.3067.5	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-A0GNAA0GNWF-0000-FA
1241.3068	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10C0-0000000000-S0NCAS0NCWF-0000-FA
1241.3075	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-S0NCAS0NCWF-0000-AA
1241.3077.229	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0BKAA0BKWF-1229-FA
1241.3082	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AF0-0000000000-S0NCAS0NCWF-0000-AA
1241.3087	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F1-0000000000-S0NCAS0NCWF-0000-AA
1241.3089.M	PSE22 Switch MO NO 100mA PI 0GN 24V DC	PSE-22-00MONOA10F1-PI0GN024F1-A0NCAA0NCWF-0000-FA
1241.3090	PSE22 Switch IV NO 1A PI 0RD 24V DC	PSE-22-00IVNO01AG0-PI0RD024G0-S0NCAS0NCWF-0000-AA
1241.3091	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AG0-PI0GN024G0-S0NCAS0NCWF-0000-AA
1241.3094.M	PSE22 Switch MO NO 100mA PI 0RG 24V DC	PSE-22-00MONOA10F0-PI0RG024F0-A0NCAA0NCWF-0000-FA
1241.3122.173	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AC0-0000000000-S0NCAS0NCNF-1173-AA

1241.3123	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10D0-0000000000-A0NCAA0NCWF-0000-FA
1241.3125	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AC0-0000000000-A0NCAA0NCWF-0000-FA
1241.3144	PSE30 Switch IV NO 1A RI 0RG	PSE-30-00IVNO01AF0-RI0RGVARG0-A0NCAA0NCNF-0000-FA
1241.3150	PSE18 Switch MO NO 100mA	PSE-18-00MONOA10C0-0000000000-A0RDAA0RDNF-1199-0A
1241.3152	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10F0-RI0RGVARG0-S0NCAS0NCWF-0000-AA
1241.3166.M	PSE22 Switch MO NO 100mA PI 0RD 24V DC	PSE-22-00MONOA10F1-PI0RD024F1-A0RDAA0RDWF-0000-FA
1241.3174.143	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0BLAA0BLWF-1143-FA
1241.3189	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARG0-A0NCAA0NCWF-0000-FA
1241.3195.M	PSE22 Switch IV NO 1A PI 0RG 24V DC	PSE-22-00IVNO01AF0-PI0RG024F0-A0NCAA0NCWF-0000-FA
1241.3203	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-S0NCAS0NCNF-0000-0A
1241.3214	PSE19 Switch IV NO 1A	PSE-19-00IVNO01AC0-0000000000-A0NCAA0NCWF-0000-FA
1241.3228	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10G0-RI0RGVARG0-S0NCAS0NCWF-0000-AA
1241.3231	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AC0-0000000000-S0NCAS0NCWF-0000-AA
1241.3234	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AF0-0000000000-S0NCAS0NCWF-0000-AA
1241.3235.M	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AF0-PI0GN024F0-S0NCAS0NCWF-0000-AA
1241.3237	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARG0-S0NCAS0NCNF-0000-AA
1241.3241	PSE27 Switch MO NO 100mA RI 0BL	PSE-27-00MONOA10G1-RI0BLVARG1-A0NCAA0NCWF-0000-FA
1241.3242	PSE27 Switch MO NO 100mA RI 0GY	PSE-27-00MONOA10G1-RI0GYVARG1-A0NCAA0NCWF-0000-FA
1241.3244.M	PSE22 Switch MO NO 100mA PI 0BL 24V DC	PSE-22-00MONOA10F1-PI0BL024F1-A0NCAA0NCWF-0000-FA
1241.3249	PSE30 Switch MO NO 100mA RI 0RG 12V DC	PSE-30-00MONOA10F0-RI0RG012F0-A0NCAA0NCWF-0000-FA
1241.3250	PSE22 Switch MO NO 100mA RI 0RD 12V DC	PSE-22-00MONOA10F0-RI0RD012F0-A0NCBA0NCNF-0000-FA
1241.3251	PSE22 Switch MO NO 100mA RI 0GN 12V DC	PSE-22-00MONOA10F0-RI0GN012F0-A0NCBA0NCNF-0000-FA
1241.3252	PSE22 Switch MO NO 100mA RI 0RG 12V DC	PSE-22-00MONOA10F0-RI0RG012F0-A0NCBA0NCNF-0000-FA
1241.3254	PSE22 Switch MO NO 100mA RI 0GN 12V DC	PSE-22-00MONOA10C0-RI0GN012C0-A0NCBA0NCNF-0000-FA
1241.3255	PSE22 Switch MO NO 100mA RI 0RG 12V DC	PSE-22-00MONOA10C0-RI0RG012C0-A0NCBA0NCNF-0000-FA
1241.3256	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10F0-RI0RD024F0-A0NCBA0NCNF-0000-FA
1241.3257	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10F0-RI0GN024F0-A0NCBA0NCNF-0000-FA
1241.3258	PSE22 Switch MO NO 100mA RI 0RG 24V DC	PSE-22-00MONOA10F0-RI0RG024F0-A0NCBA0NCNF-0000-FA
1241.3259	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10C0-RI0RD024C0-A0NCBA0NCNF-0000-FA
1241.3260	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10C0-RI0GN024C0-A0NCBA0NCNF-0000-FA
1241.3261	PSE22 Switch MO NO 100mA RI 0RG 24V DC	PSE-22-00MONOA10C0-RI0RG024C0-A0NCBA0NCNF-0000-FA
1241.3262.178	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10F0-RI0GN024F0-A0TIBA0TINF-1178-FA
1241.3263.179	PSE22 Switch MO NO 100mA RI 0YL 24V DC	PSE-22-00MONOA10F0-RI0YL024F0-A0TIBA0TINF-1179-FA
1241.3267	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10C0-RI0GN024C0-A0GNBA0GNNF-0000-BA
1241.3269	PSE24 Switch MO NO 100mA RI 0GY 24V DC	PSE-24-00MONOA10F0-RI0GY024F0-S0NCBS0NCNF-0000-AA
1241.3276	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10F0-RI0RD024F0-A0NCBA0NCNF-0000-FA
1241.3277	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10F0-RI0GN024F0-A0NCBA0NCNF-0000-FA
1241.3279.027	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10F0-RI0RGVARG0-A0NCAA0NCWF-1027-FA
1241.3282.242	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0RDAA0RDWF-1242-FA

1241.3282	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0RDAA0RDWF-0000-FA
1241.3283.225	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0BLAA0BLWF-1225-AA
1241.3283.226	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0BLAA0BLWF-1226-AA
1241.3298	PSE15 Switch MO NO 100mA	PSE-15-00MONOA10F0-0000000000-A0NC0A0NCWF-0000-0A
1241.3308	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F1-0000000000-A0NCAA0NCWF-0000-FA
1241.3309	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F1-0000000000-A0RDAA0RDWF-0000-FA
1241.3310	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F1-0000000000-A0GNAA0GNWF-0000-FA
1241.3311.179	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10C0-RI0RD024C0-A0RDBA0RDNF-1179-FA
1241.3312	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10C0-RI0GN024C0-A0RDBA0RDNF-0000-FA
1241.3315.178	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10C0-RI0GN024C0-A0GNBA0GNNF-1178-FA
1241.3315	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10C0-RI0GN024C0-A0GNBA0GNNF-0000-FA
1241.3318	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10C0-RI0GN024C0-A0BKBA0BKNF-0000-FA
1241.3329	PSE24 Switch IV NO 1A RI 0RG	PSE-24-00IVNO01AF0-RI0RGVARF0-A0NCAA0NCWF-0000-FA
1241.3330	PSE22 Switch IV NO 1A RI 0RD 12V DC	PSE-22-00IVNO01AF0-RI0RD012F0-A0NCBA0NCNF-0000-FA
1241.3331	PSE22 Switch IV NO 1A RI 0GN 12V DC	PSE-22-00IVNO01AF0-RI0GN012F0-A0NCBA0NCNF-0000-FA
1241.3334	PSE22 Switch IV NO 1A RI 0GN 24V DC	PSE-22-00IVNO01AF0-RI0GN024F0-A0NCBA0NCNF-0000-FA
1241.3335	PSE22 Switch IV NO 1A RI 0RG 24V DC	PSE-22-00IVNO01AF0-RI0RG024F0-A0NCBA0NCNF-0000-FA
1241.3336.075	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0GDAA0GDWF-1075-FA
1241.3338.183	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10F0-RI0RGVARF0-A0NCAA0BLNF-1183-FA
1241.3348	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10D0-0000000000-S0NCBS0NCWF-0000-FA
1241.3350	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10D0-0000000000-A0BLAA0BLWF-0000-FA
1241.3351	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10C0-0000000000-A0NCAA0NCWF-0000-FA
1241.3360.179	PSE22 Switch IV NO 1A RI 0RD 24V DC	PSE-22-00IVNO01AF0-RI0RD024F0-A0RDBA0RDNF-1179-FA
1241.3361.178	PSE22 Switch IV NO 1A RI 0GN 24V DC	PSE-22-00IVNO01AF0-RI0GN024F0-A0GNBA0GNNF-1178-FA
1241.3371	PSE18 Switch MO NO 100mA	PSE-18-00MONOA10D0-0000000000-S0NCAS0NCWF-0000-DA
1241.3382	PSE30 Switch MO NO 100mA RI 0GN	PSE-30-00MONOA10G0-RI0GNVARG0-S1NCAS1NCNF-0000-AA
1241.3388	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10D0-0000000000-S0NCAS0NCWF-0000-FA
1241.3398	PSE24 Switch MO NO 100mA RI 0RG	PSE-24-00MONOA10G0-RI0RGVARG0-S0NCAS0NCWF-0000-AA
1241.3400	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0NCAA0NCNF-0000-FA
1241.3408	PSE22 Switch MO NO 100mA RI 0RG 24V DC	PSE-22-00MONOA10F0-RI0RG024F0-A0NCBA0NCNF-0000-FA
1241.3409.227	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0GDBA0GDWF-1227-FA
1241.3410.228	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0RDBA0RDWF-1228-FA
1241.3413	PSE22 Switch MO NO 100mA RI 0BL 24V DC	PSE-22-00MONOA10F0-RI0BL024F0-A0NCBA0NCNF-0000-FA
1241.3428	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AF1-0000000000-S0NCBS0NCNF-0000-AA
1241.3444	PSE22 Switch MO NO 100mA RI 0BL 24V DC	PSE-22-00MONOA10C0-RI0BL024C0-A0NCAA0NCWF-0000-FA
1241.3445	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10C0-0000000000-A0NCAA0NCWF-0000-FA
1241.3446.050	PSE24 Switch IV NO 1A RI 0RG	PSE-24-00IVNO01AF0-RI0RGVARF0-S0NCAS0NCWF-1050-FA
1241.3446	PSE24 Switch IV NO 1A RI 0RG	PSE-24-00IVNO01AF0-RI0RGVARF0-S0NCAS0NCWF-0000-FA
1241.3448.160	PSE22 Switch IV NO 1A PI 0RD 24V DC	PSE-22-00IVNO01AF0-PI0RD024F0-S0NCBS0NCNF-1160-AA

1241.3449.159	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AF0-PI0GN024F0-S0NCBS0NCNF-1159-AA
1241.3450.287	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF0-0000000000-A0RDBA0RDWF-1287-CA
1241.3452	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AG1-0000000000-A0BKAA0BKNF-0000-FA
1241.3454	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0NCAA0NCWF-0000-FA
1241.3456	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10C0-RI0RD024C0-A0NCAA0NCWF-0000-FA
1241.3457.M	PSE22 Switch IV NO 1A PI 0RD 24V DC	PSE-22-00IVNO01AF0-PI0RD024F0-S0NCAS0NCWF-0000-AA
1241.3464.M	PSE22 Switch IV NO 1A PI 0RG 24V DC	PSE-22-00IVNO01AF1-PI0RG024F1-A0NCAA0NCWF-0000-FA
1241.3465.245M	PSE22 Switch MO NO 100mA PI 0YL	PSE-22-00MONOA10G1-PI0YL00RG1-A0GNAA0GNWF-1245-CA
1241.3466.246	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10G1-0000000000-A0RDAA0RDNF-1246-FA
1241.3469.244M	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AC0-PI0GN024C0-S0NCAS0NCNF-1244-AA
1241.3469.267M	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AC0-PI0GN024C0-S0NCAS0NCNF-1267-AA
1241.3475.251M	PSE25 Switch MO NO 100mA PI 0GN 24V DC	PSE-25-00MONOA10G0-PI0GN024G0-S0NCAS0NCNF-1251-KA
1241.3476	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF0-0000000000-S0NCAS0NCNF-0000-FA
1241.3478	PSE30 Switch MO NO 100mA RI 0BL 24V AC	PSE-30-00MONOA10F0-RI0BLA24F0-A0NCAA0NCWF-0000-FA
1241.3479	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-B0CR0B0CRNF-0000-0B
1241.3480.3	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-B0CR0B0CRNF-0000-0B
1241.3480.4	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-B0CR0B0CRNF-0000-0B
1241.3492	PSE37 Switch MO NO 100mA RI 0BL 24V DC	PSE-37-00MONOA10G1-RI0BL024G1-B0CR0B0CRNF-0000-0B
1241.3494.M	PSE30 Switch IV NO 1A PI 0RD	PSE-30-00IVNO01AF0-PI0RD00RF0-S0NCAS0NCWF-0000-GA
1241.3495.M	PSE30 Switch IV NO 1A PI 0GN	PSE-30-00IVNO01AF0-PI0GN00RF0-S0NCAS0NCWF-0000-GA
1241.3498	PSE27 Switch IV NO 1A RI 0RG	PSE-27-00IVNO01AF0-RI0RGVARG0-S0NCAS0NCWF-0000-AA
1241.3502	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0RDAA0RDNF-0000-FA
1241.3503	PSE22 Switch MO NO 100mA RI 0RD 12V DC	PSE-22-00MONOA10C0-RI0RD012C0-A0BKBA0BKNF-0000-FA
1241.3504	PSE22 Switch MO NO 100mA RI 0GN 12V DC	PSE-22-00MONOA10C0-RI0GN012C0-A0BKBA0BKNF-0000-FA
1241.3506.259	PSE27 Switch MO NO 100mA RI 0GN	PSE-27-00MONOA10G0-RI0GNVARG0-S0NCAS0NCWF-1259-AA
1241.3507.260	PSE27 Switch MO NO 100mA RI 0GN	PSE-27-00MONOA10G0-RI0GNVARG0-S0NCAS0NCWF-1260-AA
1241.3508.258	PSE27 Switch MO NO 100mA RI 0RD	PSE-27-00MONOA10G0-RI0RDVARG0-S0NCAS0NCWF-1258-AA
1241.3509.257	PSE27 Switch MO NO 100mA RI 0BL	PSE-27-00MONOA10G0-RI0BLVARG0-S0NCAS0NCWF-1257-AA
1241.3512	PSE30 Switch IV NO 1A RI 0BL	PSE-30-00IVNO01AF0-RI0BLVARG0-S0NCAS0NCNF-0000-AA
1241.3523	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0RDAA0RDNF-0000-FA
1241.3525.071	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-B0CRBB0CRWF-1071-AA
1241.3536	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F1-0000000000-A0NCAA0NCWF-0000-FA
1241.3539.293	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10S0-0000000000-S0NCBS0NCWF-1293-FA
1241.3543	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10F1-RI0GN024F1-A0NCAA0NCWF-0000-FA
1241.3548	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARG0-S0NCAS0NCWF-0000-FA
1241.3552	PSE19 Switch IV NO 1A	PSE-19-00IVNO01AF0-0000000000-S0NCAS0NCWF-0000-CA
1241.3561	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF0-0000000000-A0BKAA0BKWF-0000-FA
1241.3562	PSE15 Switch MO NO 100mA	PSE-15-00MONOA10F0-0000000000-S1NC0S1NCNF-0000-0A
1241.3582	PSE22 Switch IV NO 1A PI 0BL 24V AC	PSE-22-00IVNO01AG0-PI0BLA24G0-S0NCBS0NCNF-0000-AB

1241.3584	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F0-0000000000-A0RDBA0RDNF-0000-LA
1241.3594.M	PSE22 Switch MO NO 100mA PI 0GN 24V DC	PSE-22-00MONOA10F0-PI0GN024F0-S0NCBS0NCNF-0000-AA
1241.3595	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARF0-S2NCAS2NCNF-0000-AA
1241.3603	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0BLAA0BLWF-0000-FA
1241.3608	PSE22 Switch MO NO 100mA RI 0BL 24V DC	PSE-22-00MONOA10C0-RI0BL024C0-A0NCBA0NCNF-0000-FA
1241.3611.M	PSE22 Switch IV NO 1A PI 0RG 24V DC	PSE-22-00IVNO01AF0-PI0RG024F0-A0NCAA0NCWF-0000-FA
1241.3612	PSE22 Switch MO NO 100mA RI 0RG 24V DC	PSE-22-00MONOA10C0-RI0RG024C0-A0NCBA0NCWF-0000-FA
1241.3614	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10D0-0000000000-A0NCBA0NCWF-0000-CA
1241.3615	PSE24 Switch MO NO 100mA RI 0GY	PSE-24-00MONOA10G0-RI0GYVARG0-S0NCAS0NCNF-0000-AA
1241.3616	PSE24 Switch MO NO 100mA RI 0RD	PSE-24-00MONOA10G0-RI0RDVARG0-S0NCAS0NCNF-0000-AA
1241.3618	PSE30 Switch IV NO 1A RI 0RG	PSE-30-00IVNO01AG1-RI0RGVARG1-S2NCAS2NCWF-0000-AA
1241.3622.291	PSE24 Switch IV NO 1A	PSE-24-00IVNO01AG0-0000000000-S0NCBS0NCNF-1291-AA
1241.3623.290	PSE24 Switch MO NO 100mA RI 0RD	PSE-24-00MONOA10G0-RI0RDVARG0-S0NCBS0NCNF-1290-AA
1241.3624	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F1-0000000000-A0RDAA0RDWF-0000-FA
1241.3636.296	PSE27 Switch MO NO 100mA RI 0GN	PSE-27-00MONOA10G0-RI0GNVARG0-S0NCAS0NCWF-1296-AA
1241.3637	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10F0-RI0RGVARF0-A0NCAA0NCWF-0000-FA
1241.3638	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0NCAA0NCWF-0000-0A
1241.3639	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARF0-S1NCAS1NCNF-0000-AA
1241.3640	PSE30 Switch IV NO 1A RI RGB 12V DC	PSE-30-00IVNO01AG0-RIRGB012G0-S2NCAS2NCNF-0000-AA
1241.3641	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0NCAA0NCNF-0000-FA
1241.3643.027	PSE27 Switch MO NO 100mA RI 0RD	PSE-27-00MONOA10G0-RI0RDVARG0-S0NCAS0NCWF-1027-AA
1241.3645	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S2NCAS2NCNF-0000-0A
1241.3647	PSE27 Switch MO NO 100mA	PSE-27-00MONOA10G1-0000000000-A0NCAA0NCWF-0000-IA
1241.3648	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F0-RIRGBVARF0-S0NCAS0NCNF-0000-AA
1241.3650	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10G0-RI0RD024G0-S2NCAS2NCNF-0000-0A
1241.3656	PSE30 Switch IV NO 1A RI RGB 12V DC	PSE-30-00IVNO01AG0-RIRGB012G0-S1NCAS1NCNF-0000-0A
1241.3657	PSE30 Switch MO NO 100mA RI 0RG	PSE-30-00MONOA10G0-RI0RGVARG0-S2NCAS2NCNF-0000-AA
1241.3658	PSE25 Switch MO NO 100mA PI 0GN 24V DC	PSE-25-00MONOA10G0-PI0GN024G0-S0NCAS0NCNF-0000-KA
1241.3660	PSE22 Switch MO NO 100mA PI 0RG 5V DC	PSE-22-00MONOA10F0-PI0RG005F0-A0BKAA0BKWF-0000-FA
1241.3661.298	PSE22 Switch MO NO 100mA PI 0GN 5V DC	PSE-22-00MONOA10F0-PI0GN005F0-A0BKAA0BKWF-1298-FA
1241.3662.299	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0BKAA0BKWF-1299-FA
1241.3663	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F0-RIRGBVARF0-A0NCAA0NCWF-0000-FA
1241.3664	PSE22 Switch MO NO 100mA RI RGY	PSE-22-00MONOA10F0-RIRGYVARF0-A0NCAA0NCWF-0000-FA
1241.3665	PSE24 Switch MO NO 100mA RI RGB	PSE-24-00MONOA10F0-RIRGBVARF0-A0NCAA0NCWF-0000-FA
1241.3666	PSE27 Switch MO NO 100mA RI RGB	PSE-27-00MONOA10F0-RIRGBVARF0-A0NCAA0NCWF-0000-FA
1241.3667	PSE30 Switch MO NO 100mA RI RGB	PSE-30-00MONOA10F0-RIRGBVARF0-A0NCAA0NCWF-0000-FA
1241.3668	PSE30 Switch MO NO 100mA RI RGY	PSE-30-00MONOA10F0-RIRGYVARF0-A0NCAA0NCWF-0000-FA
1241.3669	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F0-RIRGBVARF0-S0NCAS0NCNF-0000-FA
1241.3670	PSE30 Switch MO NO 100mA RI RGB	PSE-30-00MONOA10F0-RIRGBVARF0-S0NCAS0NCNF-0000-FA

1241.3673	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10C0-0000000000-A0NCAA0NCWF-0000-FA
1241.3674	PSE22 Switch MO NO 100mA PI 0GN 5V DC	PSE-22-00MONOA10G0-PI0GN005G0-S0NCBS0NCNF-0000-0A
1241.3680	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARF0-S0GDAS0GDNF-0000-AA
1241.3683.253	PSE30 Switch MO NO 100mA RI 0RD	PSE-30-00MONOA10F0-RI0RDVARF0-S0NCAS0NCNF-1253-AA
1241.3684.254	PSE30 Switch MO NO 100mA RI 0GN	PSE-30-00MONOA10F0-RI0GNVARF0-S0NCAS0NCNF-1254-AA
1241.3685.252	PSE30 Switch MO NO 100mA RI 0BL	PSE-30-00MONOA10F0-RI0BLVARF0-S0NCAS0NCNF-1252-AA
1241.3687.071	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F1-0000000000-S0NCAS0NCWF-1071-AA
1241.3688	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S0NCBS0NCNF-0000-AA
1241.3689	PSE30 Switch IV NO 1A RI RGB 12V DC	PSE-30-00IVNO01AG0-RIRGB012G0-S1NCAS1NCNF-0000-0A
1241.3690	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AG0-0000000000-S0NCAS0NCNF-0000-AA
1241.3691	PSE22 Switch MO NO 100mA RI 0GN	PSE-22-00MONOA10C0-RI0GNVARC0-S2NCAS2NCNF-0000-AA
1241.3692	PSE24 Switch MO NO 50mA LI GBY 26V DC	PSE-24-00MONOA05G1-LIGBY026G1-S4NCBS4NCNE-0000-EA
1241.3696.184	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1184-FA
1241.3696.185	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1185-FA
1241.3696.186	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1186-FA
1241.3696.187	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1187-FA
1241.3696.188	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1188-FA
1241.3696.189	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1189-FA
1241.3696.190	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1190-FA
1241.3696.191	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1191-FA
1241.3696.192	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1192-FA
1241.3696.193	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1193-FA
1241.3696.194	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1194-FA
1241.3696.195	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1195-FA
1241.3696.196	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1196-FA
1241.3696.197	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1197-FA
1241.3696.198	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10C0-0000000000-A0BLBA0BLWF-1198-FA
1241.3697	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0NCAA0NCWF-0000-FA
1241.3993	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBS3NCWF-0000-AA
1241.3998	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AF0-0000000000-A0NCAA0NCWF-0000-FA
1241.5003	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10A3-0000000000-A0NCBA0NCNF-0000-FA
1241.5008	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F1-0000000000-A0RDBA0RDNF-0000-LA
1241.5009	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F1-0000000000-A0GNBA0GNNF-0000-LA
1241.5453	PSE25 Switch MO NO 100mA	PSE-25-00MONOA10G0-0000000000-S1NCGS1NCNF-0000-0A
1241.5454	PSE25 Switch MO NO 100mA PI 0RG 24V DC	PSE-25-00MONOA10G0-PI0RG024G0-S1NCGS1NCNF-0000-0A
1241.5456.1000	PSE22 Switch IV NO 1A BZ 0TI	PSE-22-00IVNO01AA2-BZ0TI00000-S0NCDS0NCNF-0000-0A
1241.5456.2255	PSE22 Switch IV NO 1A BZ 0BL	PSE-22-00IVNO01AA2-BZ0BL00000-S0NCDS0NCNF-1255-0A
1241.5456.3208	PSE22 Switch IV NO 1A BZ 0OR	PSE-22-00IVNO01AA2-BZ0OR00000-S0NCDS0NCNF-1208-0A
1241.5456.5209	PSE22 Switch IV NO 1A BZ 0NC	PSE-22-00IVNO01AA2-BZ0NC00000-S0NCDS0NCNF-1209-0A

1241.5457	PSE22 Switch IV NO 1A BZ	PSE-22-00IVNO01AA2-BZ00000000-S0NCDS0NCNF-1000-0A
1241.5458	PSE22	PSE-22-000000000000-0000000000-S0NCDS0NCNF-0000-0A
3-100-478	PSE19 Switch IV NO 1A	PSE-19-00IVNO01AC0-0000000000-A0BKAA0BKWF-0000-FA
3-100-484	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10D0-0000000000-A0NCAA0NCWF-1020-FA
3-100-485	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10F0-RI0RD024F0-A0NCBA0NCNF-1016-FA
3-100-486	PSE22 Switch MO NO 100mA RI 0RD 24V DC	PSE-22-00MONOA10F0-RI0RD024F0-A0NCBA0NCNF-1049-FA
3-100-487	PSE22 Switch MO NO 100mA RI 0GN 24V DC	PSE-22-00MONOA10F0-RI0GN024F0-A0NCBA0NCNF-1050-FA
3-100-488	PSE22 Switch MO NO 100mA RI 0RG 24V DC	PSE-22-00MONOA10F0-RI0RG024F0-A0NCAA0NCNF-1008-AA
3-100-525	PSE22 Switch IV NO 1A RI RGB	PSE-22-00IVNO01AF0-RIRGBVARF0-S0NCAS0NCNF-0000-FA
3-100-601	PSE22 Switch IV NO 1A RI RGB	PSE-22-00IVNO01AG0-RIRGBVARG0-S2NCAS2NCNF-0000-GA
3-100-756	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10C0-0000000000-A0GNBA0GNWF-1074-FA
3-100-980	PSE22 Switch IV NO 1A RI RGB	PSE-22-00IVNO01AG0-RIRGBVARG0-S2NCAS2NCNF-0000-AA
3-101-059	PSE19 Switch IV NO 1A	PSE-19-00IVNO01AF1-0000000000-A0BKAA0BKWF-0000-AA
3-101-203	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10C0-0000000000-S0NCAS0NCWF-0000-FA
3-101-568	PSE16 Switch IV NO 1A	PSE-16-00IVNO01AF1-0000000000-S0NCAS0NCWF-0000-FA
3-101-707	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AG0-0000000000-S0NCAS0NCNF-0000-AA
3-101-811	PSE30 Switch IV NO 1A RI RGB	PSE-30-00IVNO01AF0-RIRGBVARF0-S0NCAS0NCWF-0000-FA
3-102-061	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AF0-0000000000-A0BLAA0BLWF-1143-AA
3-102-104	PSE22 Switch IV NO 1A BZ 0TI	PSE-22-00IVNO01AA2-BZ0TI00000-S0NCDS0NCNF-1277-0A
3-102-175	PSE25 Switch MO NO 100mA PI 0GN 24V DC	PSE-25-00MONOA10G0-PI0GN024G0-S1NCAS1NCNF-1251-KA
3-102-521	PSE30 Switch MO NO 100mA RI RGB	PSE-30-00MONOA10G0-RIRGBVARG0-S2NCAS2NCNF-0000-AA
3-102-762	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6101-0B
3-102-763	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6102-0B
3-102-764	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6103-0B
3-102-765	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6104-0B
3-102-766	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6105-0B
3-102-767	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6106-0B
3-102-768	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-S0NC0S0NCNF-6107-0B
3-102-875	PSE30 Switch MO NO 100mA RI RGB	PSE-30-00MONOA10F0-RIRGBVARF0-S0NCAS0NCNF-0000-FA
3-103-137	PSE22 Switch IV NO 1A RI 0GN	PSE-22-00IVNO01AG0-RI0GNVARG0-S0NCAS0NCNF-0000-AA
3-103-228	PSE18 Switch IV NO 1A	PSE-18-00IVNO01AF0-0000000000-B0CR0B0CRNF-0000-0B
3-103-399	PSE22 Switch MO NO 100mA PI 0GN 3.5V DC	PSE-22-00MONOA10F0-PI0GN3V5F0-A0NCAA0NCWF-0000-FA
3-103-408	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F1-RIRGBVARF1-S0NCAS0NCNF-0000-FA
3-103-410	PSE30 Switch MO NO 100mA RI RGB	PSE-30-00MONOA10F1-RIRGBVARF1-S0NCAS0NCNF-0000-FA
3-104-157	PSE22 Switch MO NO 100mA PI 0RG 5V DC	PSE-22-00MONOA10F0-PI0RG005F0-A0BKAA0BKWF-0000-AA
3-104-158	PSE22 Switch MO NO 100mA PI 0GN 5V DC	PSE-22-00MONOA10F0-PI0GN005F0-A0BKAA0BKWF-1298-FA
3-104-159	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-00000000F0-A0BKAA0BKWF-1299-AA
3-104-169	PSE22 Switch MO NO 100mA RI 0BL 24V DC	PSE-22-00MONOA10F1-RI0BL024F1-A0NCDA0NCWF-0000-AA
3-104-254	PSE30 Switch IV NO 1A RI RGB	PSE-30-00IVNO01AF0-RIRGBVARF0-S0NCAS0NCNF-0000-FA

3-104-737	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10G1-0000000000-A0TIBA0TINF-1300-FA
3-105-290	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S2NCAS2NCNF-0000-AA
3-105-352	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4028-FA
3-105-353	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4029-FA
3-105-354	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4030-FA
3-105-355	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4031-FA
3-105-356	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4032-FA
3-105-357	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4033-FA
3-105-358	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4034-FA
3-105-359	PSE22 HI Switch MO NO 100mA	PSE-22-HIMONOA10F0-0000000000-S0NCBA2BLWF-4035-FA
3-107-407	PSE19 Switch IV NO 1A	PSE-19-00IVNO01AC0-0000000000-S0NCAS0NCWF-0000-FA
3-107-506	PSE22 Switch IV NO 1A RI 0GN	PSE-22-00IVNO01AF1-RI0GNVARF1-S0NCBS0NCNF-1074-FA
3-107-696	PSE22 Switch IV NO 1A PI 0RD 24V DC	PSE-22-00IVNO01AF0-PI0RD024F0-S0NCBS0NCNF-1160-AA
3-107-697	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AF0-PI0GN024F0-S0NCBS0NCNF-1159-AA
3-107-885	PSE22 Switch MO NO 100mA PI 0RD	PSE-22-00MONOA10F0-PI0RD00RF0-A0RDAA0RDNF-0000-FA
3-108-158	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S2NCAS2NCNF-0000-AA
3-108-363	PSE22 Switch IV NO 1A RI RGB	PSE-22-00IVNO01AG0-RIRGBVARG0-S2NCAS2NCNF-0000-0A
3-108-395	PSE 16 Switch C solid wire	PSE-16-NO00A10-P0RDP0RDWF-00000000-B0000-C+00B20A000A0
3-108-595	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F0-RIRGBVARF0-S0NCAS0NCNF-0000-FA
3-108-815	PSE22 Switch IV NO 1A RI 0BL	PSE-22-00IVNO01AG1-RI0BLVARG1-S0NCAS0NCWF-0000-FA
3-108-817	PSE22 Switch IV NO 1A RI 0RG	PSE-22-00IVNO01AG1-RI0RGVARG1-S0NCAS0NCWF-0000-FA
3-109-268	PSE27 Switch MO NO 100mA RI 0GN 24V DC	PSE-27-00MONOA10G0-RI0GN024G0-S0NCAS0NCWF-1260-AA
3-109-830	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S2NCAS2NCNF-0000-0A
3-109-940	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S0NCAS0NCNF-0000-FA
3-110-831	PSE22 Switch MO NO 100mA RI 0GN 12V DC	PSE-22-00MONOA10G0-RI0GN012G0-S1NCNS1NCNF-0000-GA
3-111-356	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-S1NCAS1NCWF-0000-AA
3-120-525	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F1-RIRGBVARF1-S0NCBS0NCNF-1074-FA
3-120-581	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AG1-PI0GN024G1-S0NCAS0NCNF-1281-AA
3-121-431	PSE22 Switch IV NO 1A PI 0GN 24V DC	PSE-22-00IVNO01AF0-PI0GN024F0-S0NCBS0NCNF-1159-AA
3-121-432	PSE22 Switch IV NO 1A PI 0RD 24V DC	PSE-22-00IVNO01AF0-PI0RD024F0-S0NCBS0NCNF-1160-AA
3-121-481	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10F1-RIRGBVARF1-S0NCBS0NCNF-0000-FA
3-123-232	PSE22 Switch MO NO 100mA RI 0RG 24V DC	PSE-22-00MONOA10C0-RI0RG024C0-A0RDBA0RDNF-0000-FA
3-123-602	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-S0NCAS0NCWF-0000-AA
3-123-620	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0BLAA0BLWF-0000-FA
3-123-632	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-A0RDAA0RDWF-0000-FA
3-123-799	PSE22 Switch MO NO 100mA RI 0RD	PSE-22-00MONOA10F0-RI0RDVARF0-S0NCAS0NCNF-0000-AA
3-123-800	PSE22 Switch MO NO 100mA RI 0GN	PSE-22-00MONOA10F0-RI0GNVARF0-S0NCAS0NCNF-0000-AA
3-124-945	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S2GDAS2GDNF-0000-0A
3-125-381	PSE24 Switch MO NO 100mA RI 0BL	PSE-24-00MONOA10G1-RI0BL00RG1-S0NCAS0NCWF-0000-IA

3-125-407	PSE24 Switch IV NO 1A RI RGB	PSE-24-00IVNO01AG1-RIRGB00RG1-S0NCAS0NCWF-0000-IA
3-125-924	PSE27 Switch MO NO 100mA RI 0BL	PSE-27-00MONOA10G0-RI0BLVARG0-S0NCAS0NCWF-1300-AA
3-126-095	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S0NCAS0NCNF-0000-AA
3-127-072	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F0-0000000000-S0NCBS0NCWF-1301-FA
3-127-074	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F0-0000000000-S0NCBS0NCWF-1302-FA
3-127-104	PSE22 Switch MO NO 100mA RI 0GN 12V DC	PSE-22-00MONOA10G0-RI0GN012G0-S1NCNS1NCNF-0000-GA
3-127-105	PSE22 Switch MO NO 100mA RI 0GN 12V DC	PSE-22-00MONOA10G0-RI0GN012G0-S1NCNS1NCNF-0000-GA
3-127-963	PSE22 Switch MO NO 100mA RI 0BL 24V DC	PSE-22-00MONOA10C0-RI0BL024C0-A0GDAA0GDWF-0000-AA
3-128-799	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-S0NCAS0NCWF-1074-AA
3-128-800	PSE22 Switch MO NO 100mA	PSE-22-00MONOA10F0-0000000000-S0NCAS0NCWF-1047-AA
3-129-835	PSE16 Switch MO NO 100mA	PSE-16-00MONOA10F0-0000000000-A0GDAA0GDWF-0000-FA
3-129-836	PSE22 Switch MO NO 100mA PI 0RD 24V DC	PSE-22-00MONOA10G0-PI0RD024G0-S2NCAS2NCNF-0000-0A
3-131-409	PSE30 Switch MO NO 100mA RI RGB	PSE-30-00MONOA10G0-RIRGBVARG0-S2NCAS2NCNF-0000-AA
3-131-823	PSE19 Switch MO NO 100mA	PSE-19-00MONOA10F0-0000000000-A0NCAA0NCWF-0000-FA
3-131-842	PSE30 Switch IV NO 1A RI RGB 12V DC	PSE-30-00IVNO01AG0-RIRGB012G0-S1NCAS1NCNF-0000-0A
3-131-969	PSE22 Switch MO NO 100mA RI RGB	PSE-22-00MONOA10G0-RIRGBVARG0-S0NCBS0NCNF-0000-AA
3-132-934	PSE22 Switch IV NO 1A	PSE-22-00IVNO01AC0-0000000000-S0NCAS0NCNF-0000-AA
3-135-021	PSE37 Switch MO NO 100mA	PSE-37-00MONOA10F1-0000000000-A0BLBA0BLNF-1235-LA
3-135-436	PSE30 Switch IV NO 1A RI RGB	PSE-30-00IVNO01AG0-RIRGBVARG0-S0NCAS0NCNF-0000-FA
3-135-753	PSE30 Switch MO NO 100mA RI 0RB	PSE-30-00MONOA10F0-RI0RBVARF0-A0NCAA0NCWF-0000-FA
3-101-394	CPS16 Switch MO NO 100mA AI RGB S0 NC B	CPS-16-MONOA10F0-AIRGBVARF0-S0NCB-C0WTNF-0000C
3-101-395	CPS16 Switch LA NO 100mA AI 0RG S0 NC B	CPS-16-LANOA10F0-AI0RGVAR00-S0NCB-C0WTNF-0000C
3-101-397	CPS16 Switch MO NO 100mA AI RGB S0 NC B	CPS-16-MONOA10F0-AIRGBVARF0-S0NCB-C0WTWF-0000C
3-101-398	CPS16 Switch LA NO 100mA AI 0RG S0 NC B	CPS-16-LANOA10F0-AI0RGVAR00-S0NCB-C0WTWF-0000C
3-101-399	CPS16 Switch MO NO 100mA RI RGB S0 NC B	CPS-16-MONOA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C
3-101-400	CPS16 Switch LA NO 100mA RI RGB S0 NC B	CPS-16-LANOA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C
3-101-401	CPS16 Switch LA NO 100mA RI 0RG S0 NC B	CPS-16-LANOA10F0-RI0RGVAR00-S0NCB-S0NCNF-0000C
3-101-403	CPS16 Switch MO NO 100mA AI RGB S0 NC B	CPS-16-MONOA10F0-AIRGBVARF0-S0NCB-C0WTNF-0000C
3-101-404	CPS22 Switch MO NO 100mA RI RGB S0 NC B	CPS-22-MONOA10F0-RIRGBVARF0-S0NCB-S0NCWF-0000C
3-101-405	CPS22 Switch LA NO 100mA RI 0RG S0 NC B	CPS-22-LANOA10F0-RI0RGVAR00-S0NCB-S0NCWF-0000C
3-101-412	CPS16 Switch MO NO 100mA RI RGB S0 NC B	CPS-16-MONOA10F0-RIRGBVARF0-S0NCB-S0NCWF-0000C
3-101-413	CPS16 Switch LA NO 100mA RI 0RG S0 NC B	CPS-16-LANOA10F0-RI0RGVAR00-S0NCB-S0NCWF-0000C
3-101-414	CPS19 Switch MO NO 100mA AI RGB S0 NC B	CPS-19-MONOA10F0-AIRGBVARF0-S0NCB-C0WTNF-0000C
3-101-415	CPS19 Switch MO NO 100mA AI RGB S0 NC B	CPS-19-MONOA10F0-AIRGBVARF0-S0NCB-C0WTNF-0000C
3-101-416	CPS19 Switch LA NO 100mA AI 0RG S0 NC B	CPS-19-LANOA10F0-AI0RGVAR00-S0NCB-C0WTNF-0000C
3-101-417	CPS19 Switch MO NO 100mA AI RGB S0 NC B	CPS-19-MONOA10F0-AIRGBVARF0-S0NCB-C0WTWF-0000C
3-101-418	CPS19 Switch LA NO 100mA AI 0RG S0 NC B	CPS-19-LANOA10F0-AI0RGVAR00-S0NCB-C0WTWF-0000C
3-101-419	CPS19 Switch MO NO 100mA RI RGB S0 NC B	CPS-19-MONOA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C
3-101-420	CPS19 Switch LA NO 100mA RI RGB S0 NC B	CPS-19-LANOA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C

3-101-421	CPS19 Switch LA NO 100mA RI 0RG S0 NC B	CPS-19-LANOA10F0-RI0RGVAR00-S0NCB-S0NCNF-0000C
3-101-422	CPS19 Switch MO NO 100mA RI RGB S0 NC B	CPS-19-MONOA10F0-RIRGBVARF0-S0NCB-S0NCWF-0000C
3-101-423	CPS19 Switch LA NO 100mA RI 0RG S0 NC B	CPS-19-LANOA10F0-RI0RGVAR00-S0NCB-S0NCWF-0000C
3-101-424	CPS22 Switch MO NO 100mA AI RGB S0 NC B	CPS-22-MONOA10F0-AIRGBVARF0-S0NCB-C0WTNF-0000C
3-101-425	CPS22 Switch LA NO 100mA AI RGB S0 NC B	CPS-22-LANOA10F0-AIRGBVARF0-S0NCB-C0WTNF-0000C
3-101-426	CPS22 Switch LA NO 100mA AI 0RG S0 NC B	CPS-22-LANOA10F0-AI0RGVAR00-S0NCB-C0WTNF-0000C
3-101-427	CPS22 Switch MO NO 100mA AI RGB S0 NC B	CPS-22-MONOA10F0-AIRGBVARF0-S0NCB-C0WTWF-0000C
3-101-428	CPS22 Switch LA NO 100mA AI 0RG S0 NC B	CPS-22-LANOA10F0-AI0RGVAR00-S0NCB-C0WTWF-0000C
3-101-429	CPS22 Switch MO NO 100mA RI RGB S0 NC B	CPS-22-MONOA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C
3-101-430	CPS22 Switch LA NO 100mA RI RGB S0 NC B	CPS-22-LANOA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C
3-101-431	CPS22 Switch LA NO 100mA RI 0RG S0 NC B	CPS-22-LANOA10F0-RI0RGVAR00-S0NCB-S0NCNF-0000C
3-104-279	CPS16 Switch LA NO 100mA RI 0WW S0 NC B	CPS-16-LANOA10F0-RI0WWVAR00-S0NCB-S0NCNF-0000C
3-104-605	CPS22 Switch MO NO 100mA RI 0GN S0 NC B	CPS-22-MONOA10F0-RI0GNVAR00-S0NCB-S0NCWF-0000C
3-107-409	CPS22 Switch MO NO 100mA RI RGB S0 NC B	CPS-22-MONOA10F0-RIRGBVARF0-S0NCB-S0NCWF-1047C
3-108-425	CPS22 Switch MO NO 100mA RI RGB S0 NC A	CPS-22-MONOA10F0-RIRGBVARF0-S0NCA-S0NCWF-0000C
3-108-614	CPS16 Switch LA NO 100mA RI 0BR S0 NC B	CPS-16-LANOA10F0-RI0BRVAR00-S0NCB-S0NCNF-0000C
3-109-466	CPS22 Switch MO NC 100mA RI RGB S0 NC B	CPS-22-MONCA10F0-RIRGBVARF0-S0NCB-S0NCNF-0000C
3-110-085	CPS16 Switch MO NO 100mA RI 0RD S0 NC B	CPS-16-MONOA10F0-RI0RDVAR00-S0NCB-S0NCWF-0000C
3-110-086	CPS16 Switch MO NO 100mA RI 0GR S0 NC B	CPS-16-MONOA10F0-RI0GRVAR00-S0NCB-S0NCWF-0000C
3-110-088	CPS16 Switch LA NO 100mA RI 0BL S0 NC B	CPS-16-LANOA10F0-RI0BLVAR00-S0NCB-S0NCWF-0000C
3-110-090	CPS16 Switch LA NO 100mA RI 0GN S0 NC B	CPS-16-LANOA10F0-RI0GNVAR00-S0NCB-S0NCWF-0000C
3-110-092	CPS19 Switch LA NO 100mA AI 0GR S0 NC B	CPS-19-LANOA10F0-AI0GRVAR00-S0NCB-C0WTNF-0000C
3-110-094	CPS22 Switch LA NO 100mA RI 0GN S0 NC B	CPS-22-LANOA10F0-RI0GNVAR00-S0NCB-S0NCNF-0000C
3-110-974	CPS19 Switch MO NO 100mA AI RGB S0 NC B	CPS-19-MONOA10F0-AIRGBVARF0-S0NCB-C0WTWF-1074C
3-111-433	CPS16 Switch MO NO 100mA RI RGB S0 NC B	CPS-16-MONOA10G1-RIRGBVARG1-S0NCB-S0NCWF-1049C
3-119-010	CPS22 Switch LA NO 100mA RI 0GR S0 NC B	CPS-22-LANOA10F0-RI0GRVAR00-S0NCB-S0NCWF-0000C
3-119-103	CPS19 Switch MO NO 100mA RI RGB S0 NC B	CPS-19-MONOA10F0-RIRGBVARF0-S0NCB-S0NCNF-1072C
3-120-355	CPS19 Switch MO NO 100mA RI RGB S0 NC B	CPS-19-MONOA10F1-RIRGBVARF1-S0NCB-S0NCNF-1072C
3-123-987	CPS22 Switch LA NO 100mA RI 0GR S0 NC B	CPS-22-LANOA10F0-RI0GRVAR00-S0NCB-S0NCNF-1074C
3-128-476	CPS16 Switch MO NO 100mA RI 0BL S0 NC B	CPS-16-MONOA10F0-RI0BLVAR00-S0NCB-S0NCWF-1068C
3-129-523	CPS22 Switch MO NO 100mA RI 0RG S0 NC B	CPS-22-MONOA10F0-RI0RGVAR00-S0NCB-S0NCWF-0000C
1241.3033.M	Indicator PSE16 PI 0RD w/o resistors A0	AE-PSE-16-A0NCA0NCWF-PI0RD00R-0000-F1AF
1241.3034.M	Indicator PSE16 PI 0GN w/o resistors A0	AE-PSE-16-A0NCA0NCWF-PI0GN00R-0000-A3AF
1241.3368	Indicator PSE30 AI 0RG varV 5-28V DC A0	AE-PSE-30-A0NCP1NCNF-AI0RGVAR-0000-F0AF
1241.3532	Indicator PSE30 AI 0RG varV 5-28V DC A0	AE-PSE-30-A0NCP1NCNF-AI0RGVAR-0000-F0AF
1241.3671	Indicator PSE30 AI RGB varV 5-28V DC A0	AE-PSE-30-A0NCP1NCNF-AIRGBVAR-0000-F0AF
1241.3672	Indicator PSE30 AI RGY varV 5-28V DC A0	AE-PSE-30-A0NCP1NCNF-AIRGYVAR-0000-F0AF
1241.3679	Indicator PSE08 PI 0RD 24V DC S0 NC	AE-PSE-08-S0NCS0NCWF-PI0RD024-0000-F1AF
1241.3681	Indicator PSE30 AI 0YL 24V DC A0 NC	AE-PSE-30-A0NCP1NCNF-AI0YL024-0000-G1AF

1241.5831.11	Indicator MPS22 AI RGB 24V DC S0 NC	AE-MPS-22-S0NCP1WTNF-AIRGB024-0000-A2AF
1241.5833.11	Indicator MPS22 AI RGB 24V DC S0 NC	AE-MPS-22-S0NCP1WTNF-AIRGB024-0000-A2D0
1241.5900	Indicator MPS22 AI RGB 24V DC S0 NC	AE-MPS-22-S0NCP1WTNF-AIRGB024-0000-A2D0
3-121-592	Indicator PSE22 AI 0GN varV 5-28V DC S0	AE-PSE-22-S0NCP1WTNF-AI0GNVAR-0000-F1AF
3-131-894	TTS22 Switch MO NO 100mA RI 0RG 06cm S0	TTS-22-MONOA10F0-RI0RGVARF0-S0NC-B-06-S0NCNF-0000C
3-131-913	TTS22 Switch LA NO 100mA RI 0RG 06cm S0	TTS-22-LANOA10F0-RI0RGVARF0-S0NC-B-06-S0NCNF-0000C
0865.7093.1	MSM19Switch AI 0RD 24V DC S0 NC C0 WT	MSM-19-0000000-0-000-0-AI0RD0240A0-S0NCB-C0WTNF-0000-C
0865.7093.4	MSM19Switch AI 0BL 24V DC S0 NC C0 WT	MSM-19-0000000-0-000-0-AI0BL0240A0-S0NCB-C0WTNF-0000-C
0865.7093.5	MSM19Switch AI 0WT 24V DC S0 NC C0 WT	MSM-19-0000000-0-000-0-AI0WT0240A0-S0NCB-C0WTNF-0000-C
0865.7094.1	MSM22Switch AI 0RD 24V DC S0 NC C0 WT	MSM-22-0000000-0-000-0-AI0RD0240A0-S0NCB-C0WTNF-0000-C
0865.7094.2	MSM22Switch AI 0GN 24V DC S0 NC C0 WT	MSM-22-0000000-0-000-0-AI0GN0240A0-S0NCB-C0WTNF-0000-C
0865.7094.4	MSM22Switch AI 0BL 24V DC S0 NC C0 WT	MSM-22-0000000-0-000-0-AI0BL0240A0-S0NCB-C0WTNF-0000-C
0865.7094.5	MSM22Switch AI 0WT 24V DC S0 NC C0 WT	MSM-22-0000000-0-000-0-AI0WT0240A0-S0NCB-C0WTNF-0000-C
0865.7106.1	MSM19Switch RI 0RD 5V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0RD0050A0-S0NCB-S0NCNF-0000-C
0865.7106.2	MSM19Switch RI 0GN 5V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0GN0050A0-S0NCB-S0NCNF-0000-C
0865.7106.4	MSM19Switch RI 0BL 5V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0BL0050A0-S0NCB-S0NCNF-0000-C
0865.7106.5	MSM19Switch RI 0WT 5V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0WT0050A0-S0NCB-S0NCNF-0000-C
0865.7107.1	MSM22Switch RI 0RD 5V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0RD0050A0-S0NCB-S0NCNF-0000-C
0865.7107.2	MSM22Switch RI 0GN 5V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0GN0050A0-S0NCB-S0NCNF-0000-C
0865.7108.4	MSM19Switch RI 0BL 12V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0BL0120A0-S0NCB-S0NCNF-0000-C
0865.7118.3	MSM19Switch S0 RD S0 NC	MSM-19-0000000-0-000-0-00000000000-S0RDB-S0NCNF-0000-C
0865.7118.5	MSM19Switch S0 GN S0 NC	MSM-19-0000000-0-000-0-00000000000-S0GNB-S0NCNF-0000-C
0865.7119.3	MSM22Switch S0 RD S0 NC	MSM-22-0000000-0-000-0-00000000000-S0RDB-S0NCNF-0000-C
0865.7120	MSM19Switch S0 NC C0 WT	MSM-19-0000000-0-000-0-00000000000-S0NCB-C0WTNF-0000-C
0865.7121	MSM22Switch S0 NC C0 WT	MSM-22-0000000-0-000-0-00000000000-S0NCB-C0WTNF-0000-C
0865.7127.1	MSM19Switch AI 0RD 5V DC S0 NC C0 WT	MSM-19-0000000-0-000-0-AI0RD0050A0-S0NCB-C0WTNF-0000-C
0865.7127.4	MSM19Switch AI 0BL 5V DC S0 NC C0 WT	MSM-19-0000000-0-000-0-AI0BL0050A0-S0NCB-C0WTNF-0000-C
0865.7129.5	MSM22Switch AI 0WT 5V DC S0 NC C0 WT	MSM-22-0000000-0-000-0-AI0WT0050A0-S0NCB-C0WTNF-0000-C
0865.7194.4	MSM 22 Switch AI QC	MSM-22-00CS000-S0NCC0WTNF-AI0BL005-0000-S+0000CB0C1
0865.9841	MSM16Switch S0 NC S0 NC	MSM-16-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9842	MSM19Switch S0 NC S0 NC	MSM-19-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9843	MSM22Switch S0 NC S0 NC	MSM-22-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9844	MSM16Switch S0 NC S0 NC	MSM-16-0000000-0-000-0-00000000000-S0NCB-S0NCNF-0000-C
0865.9845	MSM19Switch S0 NC S0 NC	MSM-19-0000000-0-000-0-00000000000-S0NCB-S0NCNF-0000-C
0865.9846	MSM22Switch S0 NC S0 NC	MSM-22-0000000-0-000-0-00000000000-S0NCB-S0NCNF-0000-C
0865.9847.1	MSM19Switch PI 0RD w/o resistors S0 NC	MSM-19-0000000-0-000-0-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
0865.9847.2	MSM19Switch PI 0GN w/o resistors S0 NC	MSM-19-0000000-0-000-0-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
0865.9847.3	MSM19Switch PI 0YL w/o resistors S0 NC	MSM-19-0000000-0-000-0-PI0YL00R0A0-S0NCB-S0NCNF-0000-C
0865.9847.4	MSM19Switch PI 0BL w/o resistors S0 NC	MSM-19-0000000-0-000-0-PI0BL00R0A0-S0NCB-S0NCNF-0000-C

0865.9848.1	MSM22Switch PI 0RD w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
0865.9848.2	MSM22Switch PI 0GN w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
0865.9848.3	MSM22Switch PI 0YL w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0YL00R0A0-S0NCB-S0NCNF-0000-C
0865.9848.4	MSM22Switch PI 0BL w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
0865.9848.6	MSM22Switch PI 0RG w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0RG00R0A0-S0NCB-S0NCNF-0000-C
0865.9849.1	MSM19Switch RI 0RD 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0RD0240A0-S0NCB-S0NCNF-0000-C
0865.9849.2	MSM19Switch RI 0GN 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0GN0240A0-S0NCB-S0NCNF-0000-C
0865.9849.3	MSM19Switch RI 0YL 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0YL0240A0-S0NCB-S0NCNF-0000-C
0865.9849.4	MSM19Switch RI 0BL 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0BL0240A0-S0NCB-S0NCNF-0000-C
0865.9849.5	MSM19Switch RI 0WT 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0WT0240A0-S0NCB-S0NCNF-0000-C
0865.9850.1	MSM22Switch RI 0RD 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0RD0240A0-S0NCB-S0NCNF-0000-C
0865.9850.2	MSM22Switch RI 0GN 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0GN0240A0-S0NCB-S0NCNF-0000-C
0865.9850.3	MSM22Switch RI 0YL 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0YL0240A0-S0NCB-S0NCNF-0000-C
0865.9850.4	MSM22Switch RI 0BL 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0BL0240A0-S0NCB-S0NCNF-0000-C
0865.9850.5	MSM22Switch RI 0WT 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0WT0240A0-S0NCB-S0NCNF-0000-C
0865.9873	MSM30Switch S0 NC S0 NC	MSM-30-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9881.1	MSM30Switch PI 0RD w/o resistors S0 NC	MSM-30-0000000-0-000-0-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
0865.9881.2	MSM30Switch PI 0GN w/o resistors S0 NC	MSM-30-0000000-0-000-0-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
0865.9881.4	MSM30Switch PI 0BL w/o resistors S0 NC	MSM-30-0000000-0-000-0-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
0865.9881.5	MSM30Switch PI 0WT w/o resistors S0 NC	MSM-30-0000000-0-000-0-PI0WT00R0A0-S0NCB-S0NCNF-0000-C
0865.9885.1	MSM30Switch RI 0RD 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0RD0240A0-S0NCB-S0NCNF-0000-C
0865.9885.2	MSM30Switch RI 0GN 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0GN0240A0-S0NCB-S0NCNF-0000-C
0865.9885.3	MSM30Switch RI 0YL 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0YL0240A0-S0NCB-S0NCNF-0000-C
0865.9885.4	MSM30Switch RI 0BL 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0BL0240A0-S0NCB-S0NCNF-0000-C
0865.9885.5	MSM30Switch RI 0WT 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0WT0240A0-S0NCB-S0NCNF-0000-C
0865.9894.1	MSM19Switch RI 0RD 12V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0RD0120A0-S0NCB-S0NCNF-0000-C
0865.9894.2	MSM19Switch RI 0GN 12V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0GN0120A0-S0NCB-S0NCNF-0000-C
0865.9894.4	MSM19Switch RI 0BL 12V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0BL0120A0-S0NCB-S0NCNF-0000-C
0865.9895.1	MSM22Switch RI 0RD 12V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0RD0120A0-S0NCB-S0NCNF-0000-C
0865.9895.2	MSM22Switch RI 0GN 12V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0GN0120A0-S0NCB-S0NCNF-0000-C
0865.9895.4	MSM22Switch RI 0BL 12V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0BL0120A0-S0NCB-S0NCNF-0000-C
0865.9898.2	MSM30Switch RI 0GN 12V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0GN0120A0-S0NCB-S0NCNF-0000-C
0865.9898.4	MSM30Switch RI 0BL 12V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0BL0120A0-S0NCB-S0NCNF-0000-C
0865.9901	MSM19Switch S0 NC S0 NC	MSM-19-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9902	MSM22Switch S0 NC S0 NC	MSM-22-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9903	MSM30Switch S0 NC S0 NC	MSM-30-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
0865.9909.1	MSM22Switch PI 0RD w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
0865.9909.2	MSM22Switch PI 0GN w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
0865.9909.5	MSM22Switch PI 0WT w/o resistors S0 NC	MSM-22-0000000-0-000-0-PI0WT00R0A0-S0NCB-S0NCNF-0000-C

0865.9910.1	MSM30Switch PI 0RD w/o resistors S0 NC	MSM-30-0000000-0-000-0-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
0865.9911.1	MSM19Switch RI 0RD 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0RD0240A0-S0NCB-S0NCNF-0000-C
0865.9911.2	MSM19Switch RI 0GN 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0GN0240A0-S0NCB-S0NCNF-0000-C
0865.9911.3	MSM19Switch RI 0YL 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0YL0240A0-S0NCB-S0NCNF-0000-C
0865.9911.4	MSM19Switch RI 0BL 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0BL0240A0-S0NCB-S0NCNF-0000-C
0865.9911.5	MSM19Switch RI 0WT 24V DC S0 NC S0 NC	MSM-19-0000000-0-000-0-RI0WT0240A0-S0NCB-S0NCNF-0000-C
0865.9912.1	MSM22Switch RI 0RD 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0RD0240A0-S0NCB-S0NCNF-0000-C
0865.9912.2	MSM22Switch RI 0GN 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0GN0240A0-S0NCB-S0NCNF-0000-C
0865.9912.4	MSM22Switch RI 0BL 24V DC S0 NC S0 NC	MSM-22-0000000-0-000-0-RI0BL0240A0-S0NCB-S0NCNF-0000-C
0865.9913.1	MSM30Switch RI 0RD 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0RD0240A0-S0NCB-S0NCNF-0000-C
0865.9913.2	MSM30Switch RI 0GN 24V DC S0 NC S0 NC	MSM-30-0000000-0-000-0-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6611.1110000	MSM16Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-16-MONXA10-B-AA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6611.1120000	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6611.1130000	MSM16Switch MO NX SPDT 10A S0 NC S0 NC	MSM-16-MONX10A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6611.1170000	MSM16Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-16-MONXA10-B-AA0-B-00000000000-S0NCA-S0NCNF-0000-C
1241.6612.1110000	MSM16Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-16-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6612.1110074	MSM16Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-16-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1074-C
1241.6612.1120000	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6612.1120074	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1074-C
1241.6621.1110000	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-AA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6621.1120000	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6621.1130000	MSM19Switch MO NX SPDT 10A S0 NC S0 NC	MSM-19-MONX10A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6621.1170000	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-AA0-B-00000000000-S0NCA-S0NCNF-0000-C
1241.6621.1180000	MSM19Switch MO NX SPDT 6A S0 NC S0 NC	MSM-19-MONX06A-B-BA0-B-00000000000-S0NCA-S0NCNF-0000-C
1241.6622.1110000	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-A00-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6622.1110138	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-A00-A-00000000000-S0NCB-S0NCNF-1138-C
1241.6622.1110142	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-A00-A-00000000000-S0NCB-S0NCNF-1142-C
1241.6622.1120000	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6622.1120168	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-A00-A-00000000000-S0NCB-S0NCNF-1168-C
1241.6622.3120000	MSM19Switch MO NX SPDT 5A A0 RD S0 NC	MSM-19-MONX05A-B-BA0-A-00000000000-A0RDB-S0NCNF-0000-C
1241.6622.3120066	MSM19Switch MO NX SPDT 5A A0 RD S0 NC	MSM-19-MONX05A-B-BA0-A-00000000000-A0RDB-S0NCNF-1066-C
1241.6622.5120000	MSM19Switch MO NX SPDT 5A A0 GN S0 NC	MSM-19-MONX05A-B-BA0-A-00000000000-A0GNB-S0NCNF-0000-C
1241.6622.5120065	MSM19Switch MO NX SPDT 5A A0 GN S0 NC	MSM-19-MONX05A-B-BA0-A-00000000000-A0GNB-S0NCNF-1065-C
1241.6623.1111000	MSM19Switch MO NX SPDT 100mA PI 0RD S0	MSM-19-MONXA10-B-AA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1112000	MSM19Switch MO NX SPDT 100mA PI 0GN S0	MSM-19-MONXA10-B-AA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1113000	MSM19Switch MO NX SPDT 100mA PI 0YL S0	MSM-19-MONXA10-B-AA0-A-PI0YL00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1114000	MSM19Switch MO NX SPDT 100mA PI 0BL S0	MSM-19-MONXA10-B-AA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1121000	MSM19Switch MO NX SPDT 5A PI 0RD S0 NC	MSM-19-MONX05A-B-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1122000	MSM19Switch MO NX SPDT 5A PI 0GN S0 NC	MSM-19-MONX05A-B-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C

1241.6623.1124000	MSM19Switch MO NX SPDT 5A PI 0BL S0 NC	MSM-19-MONX05A-B-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1131000	MSM19Switch MO NX SPDT 10A PI 0RD S0 NC	MSM-19-MONX10A-B-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6623.1132000	MSM19Switch MO NX SPDT 10A PI 0GN S0 NC	MSM-19-MONX10A-B-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6624.1111000	MSM19Switch MO NX SPDT 100mA RI 0RD S0	MSM-19-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1111000B	MSM19Switch MO NX SPDT 100mA RI 0RD S0	MSM-19-MONXA10-B-AA0-A-RI0RD0050A0-S0NCB-S0NCNF-0000-C
1241.6624.1112000	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1112000B	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0050A0-S0NCB-S0NCNF-0000-C
1241.6624.1113000	MSM19Switch MO NX SPDT 100mA RI 0YL S0	MSM-19-MONXA10-B-AA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1114000	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1114000E	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0120A0-S0NCB-S0NCNF-0000-C
1241.6624.1114074	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0240A0-S0NCB-S0NCNF-1074-C
1241.6624.1114074E	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0120A0-S0NCB-S0NCNF-1074-C
1241.6624.1115000	MSM19Switch MO NX SPDT 100mA RI 0WT S0	MSM-19-MONXA10-B-AA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1121000	MSM19Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-19-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1121047	MSM19Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-19-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-1047-C
1241.6624.1122000	MSM19Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1122047	MSM19Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1047-C
1241.6624.1122074	MSM19Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
1241.6624.1123000	MSM19Switch MO NX SPDT 5A RI 0YL 24V DC	MSM-19-MONX05A-B-AA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1124000	MSM19Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-19-MONX05A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1124000E	MSM19Switch MO NX SPDT 5A RI 0BL 12V DC	MSM-19-MONX05A-B-BA0-A-RI0BL0120A0-S0NCB-S0NCNF-0000-C
1241.6624.1125000	MSM19Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-19-MONX05A-B-BA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1131000	MSM19Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-19-MONX10A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1132000	MSM19Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-19-MONX10A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1134000	MSM19Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-19-MONX10A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1181000	MSM19Switch MO NX SPDT 6A RI 0RD 24V DC	MSM-19-MONX06A-B-BA0-B-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6624.1182000	MSM19Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-19-MONX06A-B-BA0-B-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6631.1110000	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6631.1120000	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6631.1130000	MSM22Switch MO NX SPDT 10A S0 NC S0 NC	MSM-22-MONX10A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6631.1180000	MSM22Switch MO NX SPDT 6A S0 NC S0 NC	MSM-22-MONX06A-B-BA0-B-00000000000-S0NCA-S0NCNF-0000-C
1241.6631.3110000	MSM22Switch MO NX SPDT 100mA A0 RD A0 RD	MSM-22-MONXA10-B-AA0-A-00000000000-A0RDA-A0RDNF-0000-C
1241.6631.7110000	MSM22Switch MO NX SPDT 100mA A0 BK A0 BK	MSM-22-MONXA10-B-AA0-A-00000000000-A0BKA-A0BKNF-0000-C
1241.6632.1110000	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6632.1110164	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1164-C
1241.6632.1110165	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1165-C
1241.6632.1120000	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6632.1120024	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1024-C
1241.6632.1120188	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1188-C

1241.6632.1120189	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1189-C
1241.6632.1120216	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1216-C
1241.6632.3120000	MSM22Switch MO NX SPDT 5A A0 RD S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-A0RDB-S0NCNF-0000-C
1241.6632.3120057	MSM22Switch MO NX SPDT 5A A0 RD S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-A0RDB-S0NCNF-1057-C
1241.6632.3120066	MSM22Switch MO NX SPDT 5A A0 RD S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-A0RDB-S0NCNF-1066-C
1241.6632.5120000	MSM22Switch MO NX SPDT 5A A0 GN S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-A0GNB-S0NCNF-0000-C
1241.6632.5120061	MSM22Switch MO NX SPDT 5A A0 GN S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-A0GNB-S0NCNF-1061-C
1241.6632.5120065	MSM22Switch MO NX SPDT 5A A0 GN S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-A0GNB-S0NCNF-1065-C
1241.6633.1111000	MSM22Switch MO NX SPDT 100mA PI 0RD S0	MSM-22-MONXA10-B-AA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1111163	MSM22Switch MO NX SPDT 100mA PI 0RD S0	MSM-22-MONXA10-B-AA0-B-PI0RD00R0A0-S0NCB-S0NCNF-1163-C
1241.6633.1112000	MSM22Switch MO NX SPDT 100mA PI 0GN S0	MSM-22-MONXA10-B-AA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1114000	MSM22Switch MO NX SPDT 100mA PI 0BL S0	MSM-22-MONXA10-B-AA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1121000	MSM22Switch MO NX SPDT 5A PI 0RD S0 NC	MSM-22-MONX05A-B-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1122000	MSM22Switch MO NX SPDT 5A PI 0GN S0 NC	MSM-22-MONX05A-B-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1124000	MSM22Switch MO NX SPDT 5A PI 0BL S0 NC	MSM-22-MONX05A-B-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1126000	MSM22Switch MO NX SPDT 5A PI 0RG S0 NC	MSM-22-MONX05A-B-BA0-A-PI0RG00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1131000	MSM22Switch MO NX SPDT 10A PI 0RD S0 NC	MSM-22-MONX10A-B-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6633.1132000	MSM22Switch MO NX SPDT 10A PI 0GN S0 NC	MSM-22-MONX10A-B-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6634.1111000	MSM22Switch MO NX SPDT 100mA RI 0RD S0	MSM-22-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1111000B	MSM22Switch MO NX SPDT 100mA RI 0RD S0	MSM-22-MONXA10-B-AA0-A-RI0RD0050A0-S0NCB-S0NCNF-0000-C
1241.6634.1111000E	MSM22Switch MO NX SPDT 100mA RI 0RD S0	MSM-22-MONXA10-B-AA0-A-RI0RD0120A0-S0NCB-S0NCNF-0000-C
1241.6634.1112000	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1112000B	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0050A0-S0NCB-S0NCNF-0000-C
1241.6634.1112000E	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0120A0-S0NCB-S0NCNF-0000-C
1241.6634.1112074E	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0120A0-S0NCB-S0NCNF-1074-C
1241.6634.1113000	MSM22Switch MO NX SPDT 100mA RI 0YL S0	MSM-22-MONXA10-B-AA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1114000	MSM22Switch MO NX SPDT 100mA RI 0BL S0	MSM-22-MONXA10-B-AA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1114000B	MSM22Switch MO NX SPDT 100mA RI 0BL S0	MSM-22-MONXA10-B-AA0-A-RI0BL0050A0-S0NCB-S0NCNF-0000-C
1241.6634.1114000E	MSM22Switch MO NX SPDT 100mA RI 0BL S0	MSM-22-MONXA10-B-AA0-A-RI0BL0120A0-S0NCB-S0NCNF-0000-C
1241.6634.1115000B	MSM22Switch MO NX SPDT 100mA RI 0WT S0	MSM-22-MONXA10-B-AA0-A-RI0WT0050A0-S0NCB-S0NCNF-0000-C
1241.6634.1121000	MSM22Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-22-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1122000	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1123000	MSM22Switch MO NX SPDT 5A RI 0YL 24V DC	MSM-22-MONX05A-B-BA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1124000	MSM22Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1124000B	MSM22Switch MO NX SPDT 5A RI 0BL 5V DC	MSM-22-MONX05A-B-BA0-A-RI0BL0050A0-S0NCB-S0NCNF-0000-C
1241.6634.1124000E	MSM22Switch MO NX SPDT 5A RI 0BL 12V DC	MSM-22-MONX05A-B-BA0-A-RI0BL0120A0-S0NCB-S0NCNF-0000-C
1241.6634.1125000	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1131000	MSM22Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-22-MONX10A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1132000	MSM22Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-22-MONX10A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C

1241.6634.1134000	MSM22Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-22-MONX10A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1181000	MSM22Switch MO NX SPDT 6A RI 0RD 24V DC	MSM-22-MONX06A-B-BA0-B-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1182000	MSM22Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-22-MONX06A-B-BA0-B-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6634.1184000	MSM22Switch MO NX SPDT 6A RI 0BL 24V DC	MSM-22-MONX06A-B-BA0-B-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6641.1110000	MSM24Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-24-MONXA10-B-AA0-A-00000000000-S0NCA-S0NCNF-0000-A
1241.6641.1120000	MSM24Switch MO NX SPDT 5A S0 NC S0 NC	MSM-24-MONX05A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-A
1241.6661.1110000	MSM30Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6661.1120000	MSM30Switch MO NX SPDT 5A S0 NC S0 NC	MSM-30-MONX05A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6661.1130000	MSM30Switch MO NX SPDT 10A S0 NC S0 NC	MSM-30-MONX10A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6661.1170000	MSM30Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-30-MONXA10-B-AA0-B-00000000000-S0NCA-S0NCNF-0000-C
1241.6662.1120134	MSM30Switch MO NX SPDT 5A S0 NC S0 NC	MSM-30-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1134-C
1241.6662.1120135	MSM30Switch MO NX SPDT 5A S0 NC S0 NC	MSM-30-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1135-C
1241.6662.1120136	MSM30Switch MO NX SPDT 5A S0 NC S0 NC	MSM-30-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1136-C
1241.6662.1120137	MSM30Switch MO NX SPDT 5A S0 NC S0 NC	MSM-30-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1137-C
1241.6662.1180114	MSM30Switch MO NX SPDT 6A S0 NC S0 NC	MSM-30-MONX06A-B-BA0-B-00000000000-S0NCB-S0NCNF-1114-C
1241.6663.1112000	MSM30Switch MO NX SPDT 100mA PI 0GN S0	MSM-30-MONXA10-B-AA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.1114000	MSM30Switch MO NX SPDT 100mA PI 0BL S0	MSM-30-MONXA10-B-AA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.1121000	MSM30Switch MO NX SPDT 5A PI 0RD S0 NC	MSM-30-MONX05A-B-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.1122000	MSM30Switch MO NX SPDT 5A PI 0GN S0 NC	MSM-30-MONX05A-B-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.1124000	MSM30Switch MO NX SPDT 5A PI 0BL S0 NC	MSM-30-MONX05A-B-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.1125000	MSM30Switch MO NX SPDT 5A PI 0WT S0 NC	MSM-30-MONX05A-B-BA0-A-PI0WT00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.1132000	MSM30Switch MO NX SPDT 10A PI 0GN S0 NC	MSM-30-MONX10A-B-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6663.3121	MSM30Switch MO NX SPDT 5A PI 0RD A0 RD	MSM-30-MONX05A-B-BA0-A-PI0RD00R0A0-A0RDB-A0RDNF-0000-C
1241.6664.1111000	MSM30Switch MO NX SPDT 100mA RI 0RD S0	MSM-30-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1112000	MSM30Switch MO NX SPDT 100mA RI 0GN S0	MSM-30-MONXA10-B-AA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1112000E	MSM30Switch MO NX SPDT 100mA RI 0GN S0	MSM-30-MONXA10-B-AA0-A-RI0GN0120A0-S0NCB-S0NCNF-0000-C
1241.6664.1113000	MSM30Switch MO NX SPDT 100mA RI 0YL S0	MSM-30-MONXA10-B-AA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1114000	MSM30Switch MO NX SPDT 100mA RI 0BL S0	MSM-30-MONXA10-B-AA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1121000	MSM30Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1121028	MSM30Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-1028-C
1241.6664.1121029	MSM30Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-1029-C
1241.6664.1121030	MSM30Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-1030-C
1241.6664.1121031	MSM30Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-1031-C
1241.6664.1122000	MSM30Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-30-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1123000	MSM30Switch MO NX SPDT 5A RI 0YL 24V DC	MSM-30-MONX05A-B-BA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1124000	MSM30Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-30-MONX05A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1124000E	MSM30Switch MO NX SPDT 5A RI 0BL 12V DC	MSM-30-MONX05A-B-BA0-A-RI0BL0120A0-S0NCB-S0NCNF-0000-C
1241.6664.1125000	MSM30Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-30-MONX05A-B-BA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1131000	MSM30Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-30-MONX10A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C

1241.6664.1132000	MSM30Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-30-MONX10A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6664.1134000	MSM30Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-30-MONX10A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6664.3111000	MSM30Switch MO NX SPDT 100mA RI 0RD S0	MSM-30-MONXA10-B-AA0-A-RI0RD0240A0-S0RDB-A0RDNF-0000-C
1241.6664.5112000	MSM30Switch MO NX SPDT 100mA RI 0GN S0	MSM-30-MONXA10-B-AA0-A-RI0GN0240A0-S0GNB-A0GNNF-0000-C
1241.6693.1121000	MSM22Switch MO NX SPDT 5A PI 0RD S0 NC	MSM-22-MONX05A-B-BA0-A-PI0RD00R0A0-S0NCD-S0NCNF-0000-0
1241.6693.1122000	MSM22Switch MO NX SPDT 5A PI 0GN S0 NC	MSM-22-MONX05A-B-BA0-A-PI0GN00R0A0-S0NCD-S0NCNF-0000-0
1241.6695.1120000	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCD-S0NCNF-0000-0
1241.6697.1121000	MSM22Switch MO NX SPDT 5A PI 0RD S0 NC	MSM-22-MONX05A-B-BA0-A-PI0RD00R0A0-S0NCE-S0NCNF-0000-0
1241.6697.1122000	MSM22Switch MO NX SPDT 5A PI 0GN S0 NC	MSM-22-MONX05A-B-BA0-A-PI0GN00R0A0-S0NCE-S0NCNF-0000-0
1241.6698.1120119	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCE-S0NCNF-1119-0
1241.6699.1120000	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCE-S0NCNF-0000-0
1241.6710	MSM22Switch MO NX SPDT 5A RI 0RG S0 NC	MSM-22-MONX05A-B-BA0-A-RI0RG00R0F0-S0NCB-S0NCNF-0000-C
1241.6714	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6716	MSM30Switch S0 NC S0 NC	MSM-30-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
1241.6718	MSM18Switch MO NX SPDT 5A w/o resistors	MSM-18-MONX05A-B-BA0-A-0000000R000-S0NCA-S0NCNF-0000-A
1241.6722	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-A
1241.6731	MSM30Switch MO NX SPDT 100mA RI 0RD S0	MSM-30-MONXA10-B-AA0-A-RI0RD0120A0-S0NCB-S0NCNF-0000-C
1241.6733	MSM19Switch S0 NC S0 NC	MSM-19-0000000-0-000-0-00000000000-S0NCB-S0NCNF-0000-C
1241.6737.120	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1120-C
1241.6747	MSM30Switch S0 NC S0 NC	MSM-30-0000000-0-000-0-00000000000-S0NCA-S0NCNF-0000-C
1241.6755	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6756.065	MSM19Switch MO NX SPDT 6A A0 GN S0 NC	MSM-19-MONX06A-B-BF0-B-00000000000-A0GNB-S0NCNF-1065-C
1241.6757.066	MSM19Switch MO NX SPDT 6A A0 RD S0 NC	MSM-19-MONX06A-B-BF0-B-00000000000-A0RDB-S0NCNF-1066-C
1241.6760.065	MSM22Switch MO NX SPDT 5A A0 GN A0 GN	MSM-22-MONX05A-B-BA0-A-00000000000-A0GNB-A0GNNF-1065-C
1241.6761.066	MSM22Switch MO NX SPDT 5A A0 RD A0 RD	MSM-22-MONX05A-B-BA0-A-00000000000-A0RDB-A0RDNF-1066-C
1241.6763	MSM22Switch LA NO DPST 12A PI 0BL S0 NC	MSM-22-LANO12A-C-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6764	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6765	MSM30Switch MO NX SPDT 6A S0 NC A0 RD	MSM-30-MONX06A-B-BF1-B-00000000000-S0NCA-A0RDNF-0000-C
1241.6768	MSM30Switch MO NX SPDT 6A S0 NC S0 NC	MSM-30-MONX06A-B-BA0-B-00000000000-S0NCA-S0NCNF-0000-0
1241.6770	MSM16Switch MO NX DPDT 100mA A0 BK A0 BK	MSM-16-MONXA10-D-AA0-A-00000000000-A0BKA-A0BKNF-0000-A
1241.6775	MSM30Switch MO NX SPDT 6A S0 NC S0 NC	MSM-30-MONX06A-B-BF1-B-00000000000-S0NCA-S0NCNF-0000-C
1241.6776	MSM19Switch LA NO DPST 12A S0 NC S0 NC	MSM-19-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-A
1241.6777	MSM22Switch MO NX SPDT 5A S0 NC A0 RD	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-A0RDNF-0000-C
1241.6778	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-0000-A
1241.6781	MSM22Switch LA NO SPST 12A RI 0GN 24V DC	MSM-22-LANO12A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-A
1241.6782	MSM22Switch MO NX SPDT 100mA RI 0RG S0	MSM-22-MONXA10-B-AA0-A-RI0RG00R0A0-S0NCB-S0NCNF-0000-A
1241.6783.1120190	MSM19Switch S0 NC S0 NC	MSM-19-0000000-0-000-0-00000000000-S0NCB-S0NCNF-1190-A
1241.6783.1120191	MSM19Switch S0 NC S0 NC	MSM-19-0000000-0-000-0-00000000000-S0NCB-S0NCNF-1191-A
1241.6786	MSM19Switch MO NO SPST 6A S0 NC S0 NC	MSM-19-MONO06A-A-BF1-B-00000000000-S0NCA-S0NCNF-0000-C

1241.6790.075	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1075-A
1241.6792	MSM22Switch MO NX SPDT 100mA S2 NC S2 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S2NCA-S2NCNF-0000-C
1241.6793	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AF1-A-00000000000-S0NCA-S0NCNF-0000-A
1241.6796	MSM22Switch LA NO DPST 12A RI 0RD 24V DC	MSM-22-LANO12A-C-BG1-A-RI0RD0240G1-S0NCB-S0NCNF-0000-C
1241.6798	MSM19Switch LA NO DPST 12A S0 NC S0 NC	MSM-19-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6821.1110000	MSM19Switch LA NO SPST 12A S0 NC S0 NC	MSM-19-LANO12A-A-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6821.1120000	MSM19Switch LA NO DPST 12A S0 NC S0 NC	MSM-19-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6822.1110050	MSM19Switch LA NO SPST 12A S0 NC S0 NC	MSM-19-LANO12A-A-BA4-A-00000000000-S0NCB-S0NCNF-1050-C
1241.6822.1120074	MSM19Switch LA NO DPST 12A S0 NC S0 NC	MSM-19-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-1074-C
1241.6823.1111000	MSM19Switch LA NO SPST 12A PI 0RD S0 NC	MSM-19-LANO12A-A-BA4-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6823.1112000	MSM19Switch LA NO SPST 12A PI 0GN S0 NC	MSM-19-LANO12A-A-BA4-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6823.1114000	MSM19Switch LA NO SPST 12A PI 0BL S0 NC	MSM-19-LANO12A-A-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6823.1121000	MSM19Switch LA NO DPST 12A PI 0RD S0 NC	MSM-19-LANO12A-C-BA4-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6823.1122000	MSM19Switch LA NO DPST 12A PI 0GN S0 NC	MSM-19-LANO12A-C-BA4-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6823.1124000	MSM19Switch LA NO DPST 12A PI 0BL S0 NC	MSM-19-LANO12A-C-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6824.1111000	MSM19Switch LA NO SPST 12A RI 0RD 24V DC	MSM-19-LANO12A-A-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1111218	MSM19Switch LA NO SPST 12A RI 0RD 24V DC	MSM-19-LANO12A-A-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-1218-C
1241.6824.1112000	MSM19Switch LA NO SPST 12A RI 0GN 24V DC	MSM-19-LANO12A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1114000	MSM19Switch LA NO SPST 12A RI 0BL 24V DC	MSM-19-LANO12A-A-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1115000	MSM19Switch LA NO SPST 12A RI 0WT 24V DC	MSM-19-LANO12A-A-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1121000	MSM19Switch LA NO DPST 12A RI 0RD 24V DC	MSM-19-LANO12A-C-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1122000	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1122074	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
1241.6824.1122077	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1077-C
1241.6824.1122141	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1141-C
1241.6824.1122192	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1192-C
1241.6824.1122193	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1193-C
1241.6824.1122217	MSM19Switch LA NO DPST 12A RI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1217-C
1241.6824.1124000	MSM19Switch LA NO DPST 12A RI 0BL 24V DC	MSM-19-LANO12A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6824.1124193	MSM19Switch LA NO DPST 12A RI 0BL 24V DC	MSM-19-LANO12A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1193-C
1241.6824.1127000	MSM19Switch LA NO DPST 12A RI 0OR 24V DC	MSM-19-LANO12A-C-BA4-A-RI0OR0240A0-S0NCB-S0NCNF-0000-C
1241.6831.1110000	MSM22Switch LA NO SPST 12A S0 NC S0 NC	MSM-22-LANO12A-A-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6831.1110074	MSM22Switch LA NO SPST 12A S0 NC S0 NC	MSM-22-LANO12A-A-BA4-A-00000000000-S0NCB-S0NCNF-1074-C
1241.6831.1120000	MSM22Switch LA NO DPST 12A S0 NC S0 NC	MSM-22-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6831.1120074	MSM22Switch LA NO DPST 12A S0 NC S0 NC	MSM-22-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-1074-C
1241.6833.1111000	MSM22Switch LA NO SPST 12A PI 0RD S0 NC	MSM-22-LANO12A-A-BA4-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6833.1112000	MSM22Switch LA NO SPST 12A PI 0GN S0 NC	MSM-22-LANO12A-A-BA4-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6833.1114000	MSM22Switch LA NO SPST 12A PI 0BL S0 NC	MSM-22-LANO12A-A-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6833.1121000	MSM22Switch LA NO DPST 12A PI 0RD S0 NC	MSM-22-LANO12A-C-BA4-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C

1241.6833.1122000	MSM22Switch LA NO DPST 12A PI 0GN S0 NC	MSM-22-LANO12A-C-BA4-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6833.1124000	MSM22Switch LA NO DPST 12A PI 0BL S0 NC	MSM-22-LANO12A-C-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6833.1124074	MSM22Switch LA NO DPST 12A PI 0BL S0 NC	MSM-22-LANO12A-C-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-1074-C
1241.6834.1111000	MSM22Switch LA NO SPST 12A RI 0RD 24V DC	MSM-22-LANO12A-A-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6834.1112000	MSM22Switch LA NO SPST 12A RI 0GN 24V DC	MSM-22-LANO12A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6834.1112074	MSM22Switch LA NO SPST 12A RI 0GN 24V DC	MSM-22-LANO12A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
1241.6834.1114000	MSM22Switch LA NO SPST 12A RI 0BL 24V DC	MSM-22-LANO12A-A-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6834.1115075	MSM22Switch LA NO SPST 12A RI 0WT 24V DC	MSM-22-LANO12A-A-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-1075-C
1241.6834.1121000	MSM22Switch LA NO DPST 12A RI 0RD 24V DC	MSM-22-LANO12A-C-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6834.1121074	MSM22Switch LA NO DPST 12A RI 0RD 24V DC	MSM-22-LANO12A-C-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-1074-C
1241.6834.1122000	MSM22Switch LA NO DPST 12A RI 0GN 24V DC	MSM-22-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6834.1122074	MSM22Switch LA NO DPST 12A RI 0GN 24V DC	MSM-22-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
1241.6834.1122147	MSM22Switch LA NO DPST 12A RI 0GN 24V DC	MSM-22-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1147-C
1241.6834.1124000	MSM22Switch LA NO DPST 12A RI 0BL 24V DC	MSM-22-LANO12A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6834.1124074	MSM22Switch LA NO DPST 12A RI 0BL 24V DC	MSM-22-LANO12A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1074-C
1241.6834.1125000	MSM22Switch LA NO DPST 12A RI 0WT 24V DC	MSM-22-LANO12A-C-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6921.1120000	MSM19Switch MO NX DPDT 5A S0 NC S0 NC	MSM-19-MONX05A-D-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6922.1120000	MSM19Switch MO NX DPDT 5A S0 NC S0 NC	MSM-19-MONX05A-D-BA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6923.1121000	MSM19Switch MO NX DPDT 5A PI 0RD S0 NC	MSM-19-MONX05A-D-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6923.1122000	MSM19Switch MO NX DPDT 5A PI 0GN S0 NC	MSM-19-MONX05A-D-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6923.1122074	MSM19Switch MO NX DPDT 5A PI 0GN S0 NC	MSM-19-MONX05A-D-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-1074-C
1241.6923.1124000	MSM19Switch MO NX DPDT 5A PI 0BL S0 NC	MSM-19-MONX05A-D-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6924.1121000	MSM19Switch MO NX DPDT 5A RI 0RD 24V DC	MSM-19-MONX05A-D-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6924.1122000	MSM19Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6924.1124000	MSM19Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-19-MONX05A-D-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6931.1120000	MSM22Switch MO NX DPDT 5A S0 NC S0 NC	MSM-22-MONX05A-D-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6932.1120000	MSM22Switch MO NX DPDT 5A S0 NC S0 NC	MSM-22-MONX05A-D-BA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6933.1121000	MSM22Switch MO NX DPDT 5A PI 0RD S0 NC	MSM-22-MONX05A-D-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6933.1122000	MSM22Switch MO NX DPDT 5A PI 0GN S0 NC	MSM-22-MONX05A-D-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6933.1124000	MSM22Switch MO NX DPDT 5A PI 0BL S0 NC	MSM-22-MONX05A-D-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
1241.6933.1125000	MSM22Switch MO NX DPDT 5A PI 0WT S0 NC	MSM-22-MONX05A-D-BA0-A-PI0WT00R0A0-S0NCB-S0NCNF-0000-C
1241.6934.1121000	MSM22Switch MO NX DPDT 5A RI 0RD 24V DC	MSM-22-MONX05A-D-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6934.1122000	MSM22Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6934.1124000	MSM22Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-22-MONX05A-D-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.6934.1125000	MSM22Switch MO NX DPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-D-BA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
1241.6961.1120000	MSM30Switch MO NX DPDT 5A S0 NC S0 NC	MSM-30-MONX05A-D-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
1241.6962.1120000	MSM30Switch MO NX DPDT 5A S0 NC S0 NC	MSM-30-MONX05A-D-BA0-A-00000000000-S0NCB-S0NCNF-0000-C
1241.6962.1120205	MSM30Switch MO NX DPDT 5A S0 NC S0 NC	MSM-30-MONX05A-D-BA0-A-00000000000-S0NCB-S0NCNF-1205-C
1241.6963.1113000	MSM30Switch MO NX DPDT 100mA PI 0YL S0	MSM-30-MONXA10-D-AA0-A-PI0YL00R0A0-S0NCB-S0NCNF-0000-C

1241.6963.1121000	MSM30Switch MO NX DPDT 5A PI 0RD S0 NC	MSM-30-MONX05A-D-BA0-A-PI0RD00R0A0-S0NCB-S0NCNF-0000-C
1241.6963.1122000	MSM30Switch MO NX DPDT 5A PI 0GN S0 NC	MSM-30-MONX05A-D-BA0-A-PI0GN00R0A0-S0NCB-S0NCNF-0000-C
1241.6964.1121000	MSM30Switch MO NX DPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-D-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
1241.6964.1122000	MSM30Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-30-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
1241.6964.1124000	MSM30Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-30-MONX05A-D-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
1241.7021.1120000	MSM19Switch MO NX SPDT 5A S0 NC C0 WT	MSM-19-MONX05A-B-BA0-A-00000000000-S0NCB-C0WTNF-0000-C
1241.7021.1180000	MSM19Switch MO NX SPDT 6A S0 NC C0 WT	MSM-19-MONX06A-B-BA0-B-00000000000-S0NCB-C0WTNF-0000-C
1241.7026.1112074E	MSM19Switch MO NX SPDT 100mA AI 0GN S0	MSM-19-MONXA10-B-AA0-A-AI0GN0120A0-S0NCB-C0WTNF-1074-C
1241.7026.1121000E	MSM19Switch MO NX SPDT 5A AI 0RD 12V DC	MSM-19-MONX05A-B-BA0-A-AI0RD0120A0-S0NCB-C0WTNF-0000-C
1241.7026.1124000E	MSM19Switch MO NX SPDT 5A AI 0BL 12V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0120A0-S0NCB-C0WTNF-0000-C
1241.7026.1181000	MSM19Switch MO NX SPDT 6A AI 0RD 24V DC	MSM-19-MONX06A-B-BA0-B-AI0RD0240A0-S0NCB-C0WTNF-0000-C
1241.7031.1110000	MSM22Switch MO NX SPDT 100mA S0 NC C0 WT	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCA-C0WTNF-0000-C
1241.7031.1120000	MSM22Switch MO NX SPDT 5A S0 NC C0 WT	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCA-C0WTNF-0000-C
1241.7031.1130000	MSM22Switch MO NX SPDT 10A S0 NC C0 WT	MSM-22-MONX10A-B-BA0-A-00000000000-S0NCA-C0WTNF-0000-C
1241.7032.1110159	MSM22Switch MO NX SPDT 100mA S0 NC C0 WT	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-C0WTNF-1159-C
1241.7032.1110160	MSM22Switch MO NX SPDT 100mA S0 NC C0 WT	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-C0WTNF-1160-C
1241.7032.1110161	MSM22Switch MO NX SPDT 100mA S0 NC C0 WT	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-C0WTNF-1161-C
1241.7032.1120000	MSM22Switch MO NX SPDT 5A S0 NC C0 WT	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-C0WTNF-0000-C
1241.7036.1112074E	MSM22Switch MO NX SPDT 100mA AI 0GN S0	MSM-22-MONXA10-B-AA0-A-AI0GN0120A0-S0NCB-C0WTNF-1074-C
1241.7036.1114000E	MSM22Switch MO NX SPDT 100mA AI 0BL S0	MSM-22-MONXA10-B-AA0-A-AI0BL0120A0-S0NCB-C0WTNF-0000-C
1241.7036.1115162B	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0050A0-S0NCB-C0WTNF-1162-C
1241.7036.1115219B	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0050A0-S0NCB-C0WTNF-1219-C
1241.7036.1115220B	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0050A0-S0NCB-C0WTNF-1220-C
1241.7036.1115221B	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0050A0-S0NCB-C0WTNF-1221-C
1241.7036.1115222B	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0050A0-S0NCB-C0WTNF-1222-C
1241.7036.1122065B	MSM22Switch MO NX SPDT 5A AI 0GN 5V DC	MSM-22-MONX05A-B-BA0-A-AI0GN0050A0-S0NCB-C0WTNF-1065-C
1241.7036.1124074B	MSM22Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-22-MONX05A-B-BA0-A-AI0BL0050A0-S0NCB-C0WTNF-1074-C
1241.7036.1124166	MSM22Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-1166-C
1241.7036.1124167	MSM22Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-1167-C
1241.7101.1124166	MSM22Switch MO NX DPDT 5A AI 0BL 24V DC	MSM-22-MONX05A-D-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-1166-C
1241.7101.1124167	MSM22Switch MO NX DPDT 5A AI 0BL 24V DC	MSM-22-MONX05A-D-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-1167-C
1241.7221.1110000	MSM19Switch LA NO SPST 12A S0 NC C0 WT	MSM-19-LANO12A-A-BA4-A-00000000000-S0NCB-C0WTNF-0000-C
1241.7221.1120000	MSM19Switch LA NO DPST 12A S0 NC C0 WT	MSM-19-LANO12A-C-BA4-A-00000000000-S0NCB-C0WTNF-0000-C
1241.7231.1110000	MSM22Switch LA NO SPST 12A S0 NC C0 WT	MSM-22-LANO12A-A-BA4-A-000000000A0-S0NCB-C0WTNF-0000-C
1241.7231.1120000	MSM22Switch LA NO DPST 12A S0 NC C0 WT	MSM-22-LANO12A-C-BA4-A-000000000A0-S0NCB-C0WTNF-0000-C
1241.7236.1113075	MSM22Switch LA NO SPST 12A AI 0YL 24V DC	MSM-22-LANO12A-A-BA4-A-AI0YL0241A0-S0NCB-C0WTNF-1075-C
1241.7236.1123075	MSM22Switch LA NO DPST 12A AI 0YL 24V DC	MSM-22-LANO12A-C-BA4-A-AI0YL0241A0-S0NCB-C0WTNF-1075-C
1241.7236.1124075	MSM22Switch LA NO DPST 12A AI 0BL 24V DC	MSM-22-LANO12A-C-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-1075-C
1241.7236.1124215	MSM22Switch LA NO DPST 12A AI 0BL 24V DC	MSM-22-LANO12A-C-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-1215-C

1241.7300.196	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BA0-A-AI0WT0241A0-Z0NCB-C0WTNF-1196-J
1241.7300.197	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BA0-A-AI0WT0241A0-Z0NCB-C0WTNF-1197-J
1241.7300.198	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BA0-A-AI0WT0241A0-Z0NCB-C0WTNF-1198-J
1241.7300.199	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BA0-A-AI0WT0241A0-Z0NCB-C0WTNF-1199-J
1241.7300.201	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BA0-A-AI0WT0241A0-Z0NCB-C0WTNF-1201-J
1241.7300	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BA0-A-AI0WT0241A0-Z0NCB-C0WTNF-0000-J
1241.7301.195	MSM22Switch MO NX DPST 5A AI 0RD 24V DC	MSM-22-MONX05A-C-BA0-A-AI0RD0240A0-Z0NCB-C0WTNF-1195-J
1241.7302.194	MSM22Switch MO NX DPST 5A AI 0GN 24V DC	MSM-22-MONX05A-C-BA0-A-AI0GN0241A0-Z0NCB-C0WTNF-1194-J
1241.7302	MSM22Switch MO NX DPST 5A AI 0GN 24V DC	MSM-22-MONX05A-C-BA0-A-AI0GN0241A0-Z0NCB-C0WTNF-0000-J
1241.7303.200	MSM22Switch MO NX DPST 5A AI 0RG 24V DC	MSM-22-MONX05A-C-BA0-A-AI0RG0241A0-Z0NCB-C0WTNF-1200-J
1241.7304.197	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BG1-A-AI0WT0241G1-S0NCB-C0WTNF-1197-J
1241.7700.209	MSM25Switch LA NO DPST 12A S0 NC S0 NC	MSM-25-LANO12A-C-BA4-A-0000000000-S0NCD-S0NCNF-1209-0
1241.7701.074	MSM30Switch MO NX SPDT 5A RI 0RG 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RG0240A0-S0NCB-S0NCNF-1074-C
1241.7702.037	MSM22Switch MO NX SPDT 100mA AI 0VT S0	MSM-22-MONXA10-B-AA0-A-AI0VT0120A0-S0NCB-C0WTNF-1037-C
1241.7702.038	MSM22Switch MO NX SPDT 100mA AI 0VT S0	MSM-22-MONXA10-B-AA0-A-AI0VT0120A0-S0NCB-C0WTNF-1038-C
1241.7702.213	MSM22Switch MO NX SPDT 100mA AI 0VT S0	MSM-22-MONXA10-B-AA0-A-AI0VT0120A0-S0NCB-C0WTNF-1213-C
1241.7704	MSM30Switch MO NX DPDT 100mA A0 RD S0 NC	MSM-30-MONXA10-D-AA0-A-0000000000-A0RDA-S0NCNF-0000-C
1241.7711	MSM19Switch MO NO SPST 6A S0 NC S0 NC	MSM-19-MONO06A-A-BF1-B-0000000000-S0NCA-S0NCNF-0000-C
1241.7712	MSM19Switch MO NO SPST 6A S0 NC S0 NC	MSM-19-MONO06A-A-BF1-B-0000000000-S0NCA-S0NCNF-0000-C
1241.8412	MSM19Switch MO NX SPDT 100mA AI 0RD S0	MSM-19-MONXA10-B-AA0-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8413	MSM19Switch MO NX SPDT 100mA AI 0GN S0	MSM-19-MONXA10-B-AA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8415	MSM19Switch MO NX SPDT 100mA AI 0BL S0	MSM-19-MONXA10-B-AA0-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8416	MSM19Switch MO NX SPDT 100mA AI 0WT S0	MSM-19-MONXA10-B-AA0-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8421	MSM19Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0051A0-S0NCB-C0WTNF-0000-C
1241.8448	MSM19Switch MO NX SPDT 10A AI 0RD 24V DC	MSM-19-MONX10A-B-BA0-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8449	MSM19Switch MO NX SPDT 10A AI 0GN 24V DC	MSM-19-MONX10A-B-BA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8451	MSM19Switch MO NX SPDT 10A AI 0BL 24V DC	MSM-19-MONX10A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8452	MSM19Switch MO NX SPDT 10A AI 0WT 24V DC	MSM-19-MONX10A-B-BA0-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8484	MSM22Switch MO NX SPDT 100mA AI 0RD S0	MSM-22-MONXA10-B-AA0-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8485	MSM22Switch MO NX SPDT 100mA AI 0GN S0	MSM-22-MONXA10-B-AA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8487	MSM22Switch MO NX SPDT 100mA AI 0BL S0	MSM-22-MONXA10-B-AA0-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8488	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8493	MSM 22 Switch 5A AI QC	MSM-22-NXCS05A-S0NCC0WTNF-AI0BL005-0000-S+BAA0CBAC1
1241.8520	MSM22Switch MO NX SPDT 10A AI 0RD 24V DC	MSM-22-MONX10A-B-BA0-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8521	MSM22Switch MO NX SPDT 10A AI 0GN 24V DC	MSM-22-MONX10A-B-BA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8523	MSM22Switch MO NX SPDT 10A AI 0BL 24V DC	MSM-22-MONX10A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8524	MSM22Switch MO NX SPDT 10A AI 0WT 24V DC	MSM-22-MONX10A-B-BA0-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8544	MSM19Switch LA NO SPST 12A AI 0RD 24V DC	MSM-19-LANO12A-A-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8545	MSM19Switch LA NO SPST 12A AI 0GN 24V DC	MSM-19-LANO12A-A-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C

1241.8546	MSM19Switch LA NO SPST 12A AI 0YL 24V DC	MSM-19-LANO12A-A-BA4-A-AI0YL0241A0-S0NCB-C0WTNF-0000-C
1241.8547	MSM19Switch LA NO SPST 12A AI 0BL 24V DC	MSM-19-LANO12A-A-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8548	MSM19Switch LA NO SPST 12A AI 0WT 24V DC	MSM-19-LANO12A-A-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8549	MSM19Switch LA NO SPST 12A AI 0OR 24V DC	MSM-19-LANO12A-A-BA4-A-AI0OR0241A0-S0NCB-C0WTNF-0000-C
1241.8550	MSM19Switch LA NO DPST 12A AI 0RD 24V DC	MSM-19-LANO12A-C-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8551	MSM19Switch LA NO DPST 12A AI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8552	MSM19Switch LA NO DPST 12A AI 0YL 24V DC	MSM-19-LANO12A-C-BA4-A-AI0YL0241A0-S0NCB-C0WTNF-0000-C
1241.8553	MSM19Switch LA NO DPST 12A AI 0BL 24V DC	MSM-19-LANO12A-C-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8554	MSM19Switch LA NO DPST 12A AI 0WT 24V DC	MSM-19-LANO12A-C-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8555	MSM19Switch LA NO DPST 12A AI 0OR 24V DC	MSM-19-LANO12A-C-BA4-A-AI0OR0241A0-S0NCB-C0WTNF-0000-C
1241.8556	MSM22Switch LA NO SPST 12A AI 0RD 24V DC	MSM-22-LANO12A-A-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8557	MSM22Switch LA NO SPST 12A AI 0GN 24V DC	MSM-22-LANO12A-A-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8558	MSM22Switch LA NO SPST 12A AI 0YL 24V DC	MSM-22-LANO12A-A-BA4-A-AI0YL0241A0-S0NCB-C0WTNF-0000-C
1241.8559	MSM22Switch LA NO SPST 12A AI 0BL 24V DC	MSM-22-LANO12A-A-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8560	MSM22Switch LA NO SPST 12A AI 0WT 24V DC	MSM-22-LANO12A-A-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8561	MSM22Switch LA NO SPST 12A AI 0OR 24V DC	MSM-22-LANO12A-A-BA4-A-AI0OR0241A0-S0NCB-C0WTNF-0000-C
1241.8562	MSM22Switch LA NO DPST 12A AI 0RD 24V DC	MSM-22-LANO12A-C-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
1241.8563	MSM22Switch LA NO DPST 12A AI 0GN 24V DC	MSM-22-LANO12A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
1241.8564	MSM22Switch LA NO DPST 12A AI 0YL 24V DC	MSM-22-LANO12A-C-BA4-A-AI0YL0241A0-S0NCB-C0WTNF-0000-C
1241.8565	MSM22Switch LA NO DPST 12A AI 0BL 24V DC	MSM-22-LANO12A-C-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
1241.8566	MSM22Switch LA NO DPST 12A AI 0WT 24V DC	MSM-22-LANO12A-C-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
1241.8567	MSM22Switch LA NO DPST 12A AI 0OR 24V DC	MSM-22-LANO12A-C-BA4-A-AI0OR0241A0-S0NCB-C0WTNF-0000-C
3-100-143	MSM22Switch MO NX SPDT 5A AI 0GN 12V DC	MSM-22-MONX05A-B-BA0-A-AI0GN0120A0-S0NCB-C0WTNF-1074-C
3-100-287	MSM22Switch MO NX SPDT 100mA PI 0WT S0	MSM-22-MONXA10-B-AA0-A-PI0WT0240A0-S0NCA-S0NCNF-0000-C
3-100-288	MSM22Switch MO NX SPDT 100mA PI 0WT S0	MSM-22-MONXA10-B-AA0-A-PI0WT0240A0-S0NCA-S0NCNF-1223-C
3-100-289	MSM22Switch MO NX SPDT 100mA PI 0WT S0	MSM-22-MONXA10-B-AA0-A-PI0WT0240A0-S0NCB-S0NCNF-1224-C
3-100-353	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1074-C
3-100-600	MSM22Switch LA NO DPST 16A RI 0GN 24V DC	MSM-22-LANO16A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
3-100-630	MSM30Switch MO NX SPDT 100mA RI 0BL S0	MSM-30-MONXA10-B-AA0-A-RI0BL0240A0-S0NCB-S0NCNF-1225-C
3-100-631	MSM30Switch MO NX SPDT 100mA RI 0YL S0	MSM-30-MONXA10-B-AA0-A-RI0YL0240A0-S0NCB-S0NCNF-1226-C
3-100-651	MSM30Switch MO NX SPDT 100mA RI 0RD S0	MSM-30-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-1231-C
3-100-652	MSM30Switch MO NX SPDT 100mA RI 0GN S0	MSM-30-MONXA10-B-AA0-A-RI0GN0240A0-S0NCB-S0NCNF-1230-C
3-100-683	MSM19Switch LA NO DPST 12A AI 0GN 24V DC	MSM-19-LANO12A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-1077-C
3-100-741	MSM22Switch MO NX SPDT 100mA PI 0RD A0	MSM-22-MONXA10-B-AA0-B-PI0RD00R0A0-A0BKB-A0BKNF-0000-C
3-100-746	MSM30Switch MO NX SPDT 5A RI 0RD 12V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0120A0-S0NCB-S0NCNF-0000-C
3-100-799	MSM22Switch LA NO DPST 12A RI 0GN 24V DC	MSM-22-LANO12A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1077-C
3-100-816	MSM30Switch MO NX SPDT 100mA RI 0RG S0	MSM-30-MONXA10-B-AA0-A-RI0RG0120A0-S0NCB-S0NCNF-0000-C
3-100-833	MSM19Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-1076-D
3-100-866	MSM22Switch MO NX DPST 5A AI 0YL 24V DC	MSM-22-MONX05A-C-BA0-A-AI0YL0240A0-Z0NCB-C0WTNF-1229-J

3-100-882	MSM22Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
3-100-883	MSM19Switch MO NX SPDT 5A RI 0RD 12V DC	MSM-19-MONX05A-B-BA0-B-RI0RD0120A0-S0NCA-S0NCNF-0000-C
3-100-884	MSM19Switch MO NX SPDT 5A RI 0GN 12V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0120A0-S0NCB-S0NCNF-0000-C
3-100-912	MSM22Switch LA NO DPST 16A RI 0GN 24V DC	MSM-22-LANO16A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-100-938	MSM30Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1227-C
3-100-987	MSM19Switch LA NO SPST 16A S0 NC S0 NC	MSM-19-LANO16A-A-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
3-100-989	MSM19Switch LA NO DPST 16A S0 NC S0 NC	MSM-19-LANO16A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
3-100-990	MSM19Switch LA NO SPST 16A RI 0RD 24V DC	MSM-19-LANO16A-A-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-100-991	MSM19Switch LA NO SPST 16A RI 0GN 24V DC	MSM-19-LANO16A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-100-999	MSM19Switch LA NO DPST 16A RI 0BL 24V DC	MSM-19-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-101-001	MSM22Switch LA NO SPST 16A S0 NC S0 NC	MSM-22-LANO16A-A-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
3-101-002	MSM19Switch LA NO SPST 16A RI 0BL 24V DC	MSM-19-LANO16A-A-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-101-003	MSM19Switch LA NO DPST 16A RI 0RD 24V DC	MSM-19-LANO16A-C-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-101-004	MSM19Switch LA NO DPST 16A RI 0GN 24V DC	MSM-19-LANO16A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-101-005	MSM22Switch LA NO SPST 16A S0 NC S0 NC	MSM-22-LANO16A-A-BA4-A-00000000100-S0NCB-S0NCNF-0000-C
3-101-007	MSM19Switch LA NO SPST 16A AI 0GN 24V DC	MSM-19-LANO16A-A-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-101-009	MSM19Switch LA NO SPST 16A AI 0BL 24V DC	MSM-19-LANO16A-A-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
3-101-010	MSM19Switch LA NO DPST 16A AI 0BL 24V DC	MSM-19-LANO16A-C-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
3-101-011	MSM19Switch LA NO DPST 16A AI 0WT 24V DC	MSM-19-LANO16A-C-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
3-101-012	MSM22Switch LA NO DPST 16A S0 NC S0 NC	MSM-22-LANO16A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
3-101-013	MSM22Switch LA NO SPST 16A RI 0RD 24V DC	MSM-22-LANO16A-A-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-101-014	MSM22Switch LA NO SPST 16A RI 0GN 24V DC	MSM-22-LANO16A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-101-015	MSM22Switch LA NO SPST 16A RI 0BL 24V DC	MSM-22-LANO16A-A-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-101-016	MSM22Switch LA NO DPST 16A RI 0RD 24V DC	MSM-22-LANO16A-C-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-101-018	MSM22Switch LA NO DPST 16A RI 0BL 24V DC	MSM-22-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-101-022	MSM19Switch LA NO SPST 16A AI 0WT 24V DC	MSM-19-LANO16A-A-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
3-101-023	MSM19Switch LA NO DPST 16A AI 0RD 24V DC	MSM-19-LANO16A-C-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
3-101-024	MSM19Switch LA NO DPST 16A AI 0GN 24V DC	MSM-19-LANO16A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-101-029	MSM22Switch LA NO SPST 16A AI 0BL 24V DC	MSM-22-LANO16A-A-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
3-101-030	MSM22Switch LA NO SPST 16A AI 0WT 24V DC	MSM-22-LANO16A-A-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
3-101-031	MSM22Switch LA NO DPST 16A AI 0RD 24V DC	MSM-22-LANO16A-C-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
3-101-032	MSM22Switch LA NO SPST 16A AI 0RD 24V DC	MSM-22-LANO16A-A-BA4-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
3-101-033	MSM22Switch LA NO SPST 16A AI 0GN 24V DC	MSM-22-LANO16A-A-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-101-039	MSM22Switch LA NO DPST 16A AI 0GN 24V DC	MSM-22-LANO16A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-101-040	MSM22Switch LA NO DPST 16A RI 0BL 24V DC	MSM-22-LANO16A-C-BA4-A-RI0BL0241A0-S0NCB-S0NCNF-0000-C
3-101-041	MSM22Switch LA NO DPST 16A AI 0WT 24V DC	MSM-22-LANO16A-C-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
3-101-076	MSM19Switch MO NX SPDT 100mA RI 0RG S0	MSM-19-MONXA10-B-AA0-A-RI0RG00R0F0-S0NCB-S0NCNF-0000-C
3-101-094	MSM22Switch MO NX SPDT 6A RI 0WT 24V DC	MSM-22-MONX06A-B-BA0-B-RI0WT0240A0-S0NCB-S0NCNF-0000-C
3-101-099	MSM22Switch MO NX SPDT 100mA RI 0RD S0	MSM-22-MONXA10-B-AA0-A-RI0RD0120A0-S0NCB-S0NCNF-1074-C

3-101-127	MSM19Switch LA NO DPST 12A S0 NC S0 NC	MSM-19-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-1232-C
3-101-152	MSM19Switch LA NO DPST 12A RI 0BL 24V DC	MSM-19-LANO12A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1074-C
3-101-333	MSM22Switch LA NO DPST 12A S0 NC S0 NC	MSM-22-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-1233-C
3-101-488	MSM19Switch LA NO DPST 12A AI 0WT 24V DC	MSM-19-LANO12A-C-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-1074-C
3-101-515	MSM19Switch MO NX SPDT 5A PI 0GY S0 NC	MSM-19-MONX05A-B-BA0-A-PI0GY00R0A0-S0NCB-S0NCNF-0000-C
3-101-569	MSM19Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-19-MONX10A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
3-101-711	MSM19Switch LA NO DPST 16A S0 NC S0 NC	MSM-19-LANO16A-C-BA4-A-00000000000-S0NCB-S0NCNF-1253-C
3-101-884	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0050A0-S0NCB-S0NCNF-1074-C
3-101-891	MSM19Switch MO NX SPDT 6A S0 NC S0 NC	MSM-19-MONX06A-B-B00-B-00000000000-S0NCB-S0NCNF-0000-C
3-102-188	MSM19Switch MO NX SPDT 6A RI 0RD 12V DC	MSM-19-MONX06A-B-BA0-B-RI0RD0120A0-S0NCB-S0NCNF-0000-C
3-102-426	MSM22Switch LA NO DPST 16A S0 NC S0 NC	MSM-22-LANO16A-C-BA4-A-00000000000-S0NCB-S0NCNF-1074-C
3-102-445	MSM19Switch MO NX SPDT 10A AI 0BL 24V DC	MSM-19-MONX10A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-1074-C
3-102-446	MSM22Switch MO NX SPDT 10A AI 0RD 24V DC	MSM-22-MONX10A-B-BA0-A-AI0RD0241A0-S0NCB-C0WTNF-1074-C
3-102-602	MSM22Switch MO NX DPDT 5A S0 NC S0 NC	MSM-22-MONX05A-D-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
3-102-618	MSM16Switch MO NX SPDT 100mA RI 0RD S0	MSM-16-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-102-619	MSM16Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-16-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-102-620	MSM16Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-16-MONX10A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-102-621	MSM16Switch MO NX SPDT 100mA RI 0GN S0	MSM-16-MONXA10-B-AA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-102-622	MSM16Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-16-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-102-623	MSM16Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-16-MONX10A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-102-624	MSM16Switch MO NX SPDT 100mA RI 0BL S0	MSM-16-MONXA10-B-AA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-102-625	MSM16Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-16-MONX05A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-102-626	MSM16Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-16-MONX10A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-102-627	MSM16Switch MO NX SPDT 100mA RI 0YL S0	MSM-16-MONXA10-B-AA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
3-102-628	MSM16Switch MO NX SPDT 5A RI 0YL 24V DC	MSM-16-MONX05A-B-BA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
3-102-629	MSM16Switch MO NX SPDT 10A RI 0YL 24V DC	MSM-16-MONX10A-B-BA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
3-102-630	MSM16Switch MO NX SPDT 100mA RI 0WT S0	MSM-16-MONXA10-B-AA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
3-102-631	MSM16Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-16-MONX05A-B-AA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
3-102-632	MSM16Switch MO NX SPDT 10A RI 0WT 24V DC	MSM-16-MONX10A-B-BA0-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
3-102-633	MSM16Switch MO NX SPDT 100mA AI 0RD S0	MSM-16-MONXA10-B-AA0-A-AI0RD0240A0-S0NCB-C0WTNF-0000-C
3-102-634	MSM16Switch MO NX SPDT 5A AI 0RD 24V DC	MSM-16-MONX05A-B-BA0-A-AI0RD0240A0-S0NCB-C0WTNF-0000-C
3-102-635	MSM16Switch MO NX SPDT 10A AI 0RD 24V DC	MSM-16-MONX10A-B-BA0-A-AI0RD0240A0-S0NCB-C0WTNF-0000-C
3-102-636	MSM16Switch MO NX SPDT 100mA AI 0GN S0	MSM-16-MONXA10-B-AA0-A-AI0GN0240A0-S0NCB-C0WTNF-0000-C
3-102-637	MSM16Switch MO NX SPDT 5A AI 0GN 24V DC	MSM-16-MONX05A-B-BA0-A-AI0GN0240A0-S0NCB-C0WTNF-0000-C
3-102-639	MSM16Switch MO NX SPDT 10A AI 0GN 24V DC	MSM-16-MONX10A-B-BA0-A-AI0GN0240A0-S0NCB-C0WTNF-0000-C
3-102-640	MSM16Switch MO NX SPDT 100mA AI 0BL S0	MSM-16-MONXA10-B-AA0-A-AI0BL0240A0-S0NCB-C0WTNF-0000-C
3-102-641	MSM16Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-16-MONX05A-B-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-0000-C
3-102-642	MSM16Switch MO NX SPDT 10A AI 0BL 24V DC	MSM-16-MONX10A-B-BA0-A-AI0BL0240A0-S0NCB-C0WTNF-0000-C
3-102-643	MSM16Switch MO NX SPDT 100mA AI 0YL S0	MSM-16-MONXA10-B-AA0-A-AI0YL0240A0-S0NCB-C0WTNF-0000-C

3-102-644	MSM16Switch MO NX SPDT 5A AI 0YL 24V DC	MSM-16-MONX05A-B-BA0-A-AI0YL0240A0-S0NCB-C0WTNF-0000-C
3-102-645	MSM16Switch MO NX SPDT 10A AI 0YL 24V DC	MSM-16-MONX10A-B-BA0-A-AI0YL0240A0-S0NCB-C0WTNF-0000-C
3-102-646	MSM16Switch MO NX SPDT 100mA AI 0WT S0	MSM-16-MONXA10-B-AA0-A-AI0WT0240A0-S0NCB-C0WTNF-0000-C
3-102-647	MSM16Switch MO NX SPDT 5A AI 0WT 24V DC	MSM-16-MONX05A-B-BA0-A-AI0WT0240A0-S0NCB-C0WTNF-0000-C
3-102-648	MSM16Switch MO NX SPDT 10A AI 0WT 24V DC	MSM-16-MONX10A-B-BA0-A-AI0WT0240A0-S0NCB-C0WTNF-0000-C
3-102-649	MSM16Switch MO NX SPDT 100mA S0 NC C0 WT	MSM-16-MONXA10-B-AA0-A-000000000A0-S0NCB-C0WTNF-0000-C
3-102-650	MSM16Switch MO NX SPDT 5A S0 NC C0 WT	MSM-16-MONX05A-B-BA0-A-000000000A0-S0NCB-C0WTNF-0000-C
3-102-651	MSM16Switch MO NX SPDT 10A S0 NC C0 WT	MSM-16-MONX10A-B-BA0-A-000000000A0-S0NCB-C0WTNF-0000-C
3-102-656	MSM19Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0050A0-S0NCB-C0WTNF-1006-C
3-102-657	MSM19Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0050A0-S0NCB-C0WTNF-1047-C
3-102-658	MSM19Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0050A0-S0NCB-C0WTNF-1048-C
3-102-659	MSM19Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0050A0-S0NCB-C0WTNF-1236-C
3-102-660	MSM19Switch MO NX SPDT 5A AI 0BL 5V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0050A0-S0NCB-C0WTNF-1237-C
3-102-708	MSM19Switch MO NX SPDT 100mA RI RGB S0	MSM-19-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-709	MSM22Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-1074-C
3-102-731	MSM19Switch MO NX SPDT 5A RI RGB 24V DC	MSM-19-MONX05A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-772	MSM19Switch MO NX SPDT 10A RI RGB 24V DC	MSM-19-MONX10A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-773	MSM22Switch MO NX SPDT 100mA RI RGB S0	MSM-22-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-774	MSM22Switch MO NX SPDT 100mA AI RGB S0	MSM-22-MONXA10-B-AA0-A-AIRGB0244A0-S0NCB-C0WTNF-0000-C
3-102-775	MSM22Switch MO NX SPDT 5A AI RGB 24V DC	MSM-22-MONX05A-B-BA0-A-AIRGB0244A0-S0NCB-C0WTNF-0000-C
3-102-776	MSM22Switch MO NX SPDT 10A AI RGB 24V DC	MSM-22-MONX10A-B-BA0-A-AIRGB0244C0-S0NCB-C0WTNF-0000-C
3-102-783	MSM22Switch MO NX SPDT 5A RI RGB 24V DC	MSM-22-MONX05A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-784	MSM22Switch MO NX SPDT 10A RI RGB 24V DC	MSM-22-MONX10A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-785	MSM30Switch MO NX SPDT 100mA RI RGB S0	MSM-30-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-786	MSM30Switch MO NX SPDT 5A RI RGB 24V DC	MSM-30-MONX05A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-787	MSM30Switch MO NX SPDT 10A RI RGB 24V DC	MSM-30-MONX10A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-102-788	MSM19Switch MO NX SPDT 100mA AI RGB S0	MSM-19-MONXA10-B-AA0-A-AIRGB0244A0-S0NCB-C0WTNF-0000-C
3-102-789	MSM19Switch MO NX SPDT 5A AI RGB 24V DC	MSM-19-MONX05A-B-BA0-A-AIRGB0244A0-S0NCB-C0WTNF-0000-C
3-102-790	MSM19Switch MO NX SPDT 10A AI RGB 24V DC	MSM-19-MONX10A-B-BA0-A-AIRGB0244A0-S0NCB-C0WTNF-0000-C
3-102-896	MSM30Switch MO NX SPDT 6A RI 0RG 24V DC	MSM-30-MONX06A-B-BF0-B-RI0RG0240F0-S0NCA-S0NCNF-0000-I
3-102-996	MSM19Switch MO NX SPDT 5A RI 0WT 5V DC	MSM-19-MONX05A-B-BA0-B-RI0WT0050A0-S0NCB-S0NCNF-0000-C
3-103-005	MSM19Switch MO NX SPDT 5A RI 0WT 12V DC	MSM-19-MONX05A-B-BA0-B-RI0WT0120A0-S0NCB-S0NCNF-0000-C
3-103-070	MSM22Switch LA NO SPST 12A RI 0WT 24V DC	MSM-22-LANO12A-A-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-0000-C
3-103-161	MSM22Switch MO NX SPDT 100mA RI 0RD S0	MSM-22-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-1057-C
3-103-164	MSM19Switch MO NX SPDT 100mA AI 0BL S0	MSM-19-MONXA10-B-AA0-A-AI0BL0120A0-S0NC0-C0WTNF-1074-C
3-103-170	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-B-RI0GN0240A0-S0NCB-S0NCNF-1072-C
3-103-171	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0240A0-S0NCB-S0NCNF-1073-C
3-103-413	MSM19Switch MO NX SPDT 5A PI 0BL S0 NC	MSM-19-MONX05A-B-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-1074-C
3-103-541	MSM22Switch LA NO DPST 12A PI 0BL S0 NC	MSM-22-LANO12A-C-BA4-A-PI0BL00R0A0-S0NCB-S0NCNF-1077-0

3-103-577	MSM22Switch MO NX SPDT 5A AI 0GN 12V DC	MSM-22-MONX05A-B-BA0-A-AI0GN0120A0-S0NCB-C0WTFN-1065-C
3-103-586	MSM22Switch MO NX SPDT 5A AI 0GN 12V DC	MSM-22-MONX05A-B-BA0-A-AI0GN0120A0-S0NCB-C0WTFN-0000-C
3-103-627	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1047-C
3-103-628	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1048-C
3-103-768	MSM19Switch LA NO SPST 12A RI 0GN 12V DC	MSM-19-LANO12A-A-BA4-A-RI0GN0120A0-S0NCB-S0NCNF-0000-C
3-103-769	MSM22Switch LA NO DPST 12A AI 0GN 12V DC	MSM-22-LANO12A-C-BA4-A-AI0GN0120A0-S0NCB-C0WTFN-0000-C
3-103-770	MSM22Switch LA NO DPST 12A AI 0GN 12V DC	MSM-22-LANO12A-C-BA4-A-AI0GN0120A0-S0NCB-C0WTFN-1077-C
3-103-889	MSM22Switch S0 NC S0 NC	MSM-22-0000000-0-000-0-00000000000-S0NCB-S0NCNF-1009-0
3-103-890	MSM22Switch S0 NC S0 NC	MSM-22-0000000-0-000-0-00000000000-S0NCB-S0NCNF-1027-0
3-104-051	MSM19Switch MO NX SPDT 100mA A0 BK A0 BK	MSM-19-MONXA10-B-AA0-B-00000000000-A0BKB-A0BKNF-1243-C
3-104-179	MSM22Switch MO NX DPDT 100mA RI 0GN S0	MSM-22-MONXA10-D-AA0-A-RI0GN0050A0-S0NCB-S0NCNF-1239-C
3-104-186	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0050A0-S0NCB-S0NCNF-1240-C
3-104-187	MSM22Switch MO NX DPDT 100mA RI 0GN S0	MSM-22-MONXA10-D-AA0-A-RI0GN0050A0-S0NCB-S0NCNF-1238-C
3-104-246	MSM22Switch LA NO DPST 16A S0 NC S0 NC	MSM-22-LANO16A-C-BA4-A-00000000000-S0NCB-S0NCNF-1074-A
3-104-361	MSM22Switch MO NX SPDT 100mA AI 0GN S0	MSM-22-MONXA10-B-AA0-A-AI0GN0240A0-S0NCB-C0WTFN-1244-C
3-104-372	MSM22Switch MO NX SPDT 100mA AI 0YL S0	MSM-22-MONXA10-B-AA0-A-AI0YL0240A0-S0NCB-C0WTFN-1245-C
3-104-590	MSM22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-0000-F
3-104-674	MSM19Switch LA NO DPST 16A PI 0WT S0 NC	MSM-19-LANO16A-C-BA4-A-PI0WT00R0A0-S0NCB-S0NCNF-0000-C
3-104-675	MSM19Switch LA NO SPST 16A PI 0WT S0 NC	MSM-19-LANO16A-A-BA4-A-PI0WT00R0A0-S0NCB-S0NCNF-1077-C
3-104-682	MSM16Switch MO NX SPDT 5A A0 BK A0 BK	MSM-16-MONX05A-B-BA0-A-00000000000-A0BKB-A0BKNF-0000-C
3-104-746	MSM16Switch MO NX SPDT 6A RI 0RD 24V DC	MSM-16-MONX06A-B-BA0-B-RI0RD0240A0-S0NCB-S0NCNF-0000-C
3-104-747	MSM16Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-16-MONX06A-B-BA0-B-RI0GN0240A0-S0NCB-S0NCNF-0000-C
3-104-748	MSM16Switch MO NX SPDT 6A RI 0BL 24V DC	MSM-16-MONX06A-B-BA0-B-RI0BL0240A0-S0NCB-S0NCNF-0000-C
3-107-447	MSM22Switch MO NO SPDT 100mA AI 0GN S0	MSM-22-MONOA10-B-AA0-A-AI0GN0241A0-S0NCB-C0WTFN-1009-C
3-107-563	MSM19Switch MO NX DPDT 5A S0 NC S0 NC	MSM-19-MONX05A-D-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
3-107-568	MSM19Switch LA NO DPST 12A RI 0BL 5V DC	MSM-19-LANO12A-C-BA4-A-RI0BL0054A0-S0NCB-S0NCNF-0000-A
3-107-578	MSM19Switch MO NX SPDT 100mA RI 0RD S0	MSM-19-MONXA10-B-AA0-A-RI0RD0054A0-S0NCB-S0NCNF-0000-F
3-107-579	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0054A0-S0NCB-S0NCNF-0000-F
3-107-692	MSM19Switch LA NO DPST 16A RI 0WT 24V DC	MSM-19-LANO16A-C-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-1077-C
3-107-721	MSM30Switch MO NX SPDT 100mA A0 RD A0 RD	MSM-30-MONXA10-B-AF0-B-00000000000-A0RDB-A0RDNF-7000-G
3-107-781	MSM22Switch LA NO DPDT 12A RI 0BL 24V DC	MSM-22-LANO12A-D-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1075-C
3-107-782	MSM19Switch MO NX SPDT 100mA A0 BK A0 BK	MSM-19-MONXA10-B-AA0-B-00000000000-A0BKB-A0BKNF-1248-C
3-107-989	MSM22Switch MO NO SPST 100mA RI 0GY S0	MSM-22-MONOA10-A-AF0-A-RI0GY0240F1-S0NCB-S0NCNF-0000-F
3-108-170	MSM19Switch MO NX DPDT 10A S0 NC S0 NC	MSM-19-MONX10A-D-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
3-108-384	MSM22Switch MO NX SPDT 100mA S5 NC S5 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S5NCB-S5NCNF-0000-C
3-108-440	MSM22Switch LA NO DPST 12A RI 0GN 12V DC	MSM-22-LANO12A-C-BA4-A-RI0GN0120A0-S0NCB-S0NCNF-1077-C
3-108-590	MSM22Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-22-MONX05A-B-BA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-A
3-108-826	MSM16Switch MO NX SPDT 10A S0 NC S0 NC	MSM-16-MONX10A-B-BA0-A-00000000000-S0NCB-S0NCNF-1074-C
3-108-945	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C

3-108-946	MSM19Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-947	MSM19Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-19-MONX10A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-948	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-949	MSM19Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-19-MONX05A-B-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-950	MSM19Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-19-MONX10A-B-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-951	MSM19Switch MO NX DPDT 5A RI 0RD 24V DC	MSM-19-MONX05A-D-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-952	MSM19Switch MO NX SPDT 100mA RI 0RD S0	MSM-19-MONXA10-B-AA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-953	MSM19Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-19-MONX05A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-954	MSM19Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-19-MONX10A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-955	MSM22Switch MO NX SPDT 100mA RI 0RD S0	MSM-22-MONXA10-B-AA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-956	MSM22Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-22-MONX05A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-957	MSM22Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-22-MONX10A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-958	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-959	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-960	MSM22Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-22-MONX10A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-961	MSM22Switch MO NX SPDT 100mA RI 0BL S0	MSM-22-MONXA10-B-AA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-962	MSM19Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-963	MSM19Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-19-MONX05A-D-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-964	MSM30Switch MO NX SPDT 100mA RI 0RD S0	MSM-30-MONXA10-B-AA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-965	MSM30Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-30-MONX05A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-966	MSM30Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-30-MONX10A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-967	MSM30Switch MO NX SPDT 100mA RI 0GN S0	MSM-30-MONXA10-B-AA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-968	MSM30Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-30-MONX05A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-969	MSM30Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-30-MONX10A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-972	MSM22Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-973	MSM22Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-22-MONX10A-B-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-974	MSM22Switch MO NX DPDT 5A RI 0RD 24V DC	MSM-22-MONX05A-D-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-0000-C
3-108-975	MSM22Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-D-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-0000-C
3-108-976	MSM22Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-22-MONX05A-D-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-977	MSM30Switch MO NX SPDT 100mA RI 0BL S0	MSM-30-MONXA10-B-AA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-978	MSM30Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-30-MONX05A-B-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-108-979	MSM30Switch MO NX SPDT 10A RI 0BL 24V DC	MSM-30-MONX10A-B-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-0000-C
3-109-176	MSM30Switch MO NX DPDT 5A RI 0YL 24V DC	MSM-30-MONX05A-D-BA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
3-109-303	MSM22Switch LA NO DPST 12A RI 0BL 5V DC	MSM-22-LANO12A-C-BA4-A-RI0BL0054A0-S0NCB-S0NCNF-0000-C
3-109-418	MSM22Switch LA NO DPST 12A S0 NC S0 NC	MSM-22-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-1077-C
3-109-456	MSM30Switch MO NX SPDT 6A S0 NC A0 RD	MSM-30-MONX06A-B-BF1-B-00000000000-S0NCA-A0RDNF-0000-I
3-109-464	MSM19Switch LA NO DPST 16A RI 0BL 24V DC	MSM-19-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1074-C
3-109-580	MSM22Switch MO NX SPDT 100mA RI RGB S0	MSM-22-MONXA10-B-AA0-B-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-109-692	MSM19Switch LA NO SPST 12A RI RGB 24V DC	MSM-19-LANO12A-A-BA4-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C

3-109-730	MSM22Switch MO NX SPDT 100mA RI RGB S0	MSM-22-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-0000-C
3-109-775	MSM19Switch MO NX SPDT 100mA RI 0WT S0	MSM-19-MONXA10-B-AA0-A-RI0WT0050A0-S0NCB-S0NCNF-0000-C
3-109-795	MSM22Switch LA NO DPST 16A RI 0BL 24V DC	MSM-22-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-0074-C
3-110-050	MSM22Switch LA NO DPST 12A AI 0WT 24V DC	MSM-22-LANO12A-C-BA4-A-AI0WT0241A0-S0NCB-C0WTNF-1075-C
3-110-051	MSM22Switch LA NO DPST 12A AI 0BL 24V DC	MSM-22-LANO12A-C-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-1215-B
3-110-101	MSM30Switch MO NX SPDT 100mA S2 NC S2 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S2NCA-S2NCNF-0000-C
3-110-478	MSM19Switch MO NX SPDT 100mA RI 0WT S0	MSM-19-MONXA10-B-AA0-A-RI0WT0240A0-S0NCB-S0NCNF-1074-C
3-110-829	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BF1-A-00000000000-S0NCA-S0NCNF-0000-C
3-110-927	MSM22Switch LA NO SPST 12A RI 0GN 24V DC	MSM-22-LANO12A-A-BF1-A-RI0GN0240F1-S0NCB-S0NCNF-1074-C
3-111-268	MSM22Switch MO NX SPDT 50mA RI 0GN S0	MSM-22-MONXA05-B-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-0000-A
3-111-269	MSM22Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-0000-A
3-111-418	MSM30Switch MO NX SPDT 100mA RI 0GN S0	MSM-30-MONXA10-B-AA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-419	MSM30Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-30-MONX05A-B-BA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-420	MSM30Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-30-MONX10A-B-BA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-423	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-424	MSM19Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-425	MSM19Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-19-MONX10A-B-BA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-426	MSM22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-427	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-428	MSM22Switch MO NX SPDT 10A RI 0GN 24V DC	MSM-22-MONX10A-B-BA0-A-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-111-431	MSM22Switch MO NX DPST 5A AI 0WT 24V DC	MSM-22-MONX05A-C-BG1-A-AI0WT0241G1-S0NCA-C0WTFW-1179-J
3-111-453	MSM16Switch MO NX SPDT 100mA RI 0GN S0	MSM-16-MONXA10-B-AA0-A-RI0GN0244A0-S0NCB-S0NCNF-1074-C
3-111-481	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-B00-A-00000000000-S0NCG-S0NCNF-1049-0
3-111-523	MSM19Switch MO NX DPST 12A S0 NC S0 NC	MSM-19-MONX12A-C-BA4-A-00000000000-S0NCB-S0NCNF-1251-C
3-111-566	MSM22Switch MO NO SPST 12A S0 NC C0 WT	MSM-22-MONO12A-A-BA4-A-0000000000A0-S0NCB-C0WTNF-0000-I
3-115-047	MSM22Switch LA NO DPST 12A S0 NC S0 NC	MSM-22-LANO12A-C-BF1-A-00000000000-S0NCB-S0NCNF-1077-I
3-115-063	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0057A0-S0NCB-S0NCNF-0000-C
3-118-996	MSM22Switch MO NX SPDT 10A AI 0GN 5V DC	MSM-22-MONX10A-B-BA0-A-AI0GN0051A0-S0NCB-C0WTNF-0000-C
3-119-655	MSM22Switch MO NX SPDT 5A RI 0BL 5V DC	MSM-22-MONX05A-B-BA0-A-RI0BL0054A0-S0NCB-S0NCNF-1074-C
3-119-711	MSM22Switch MO NX SPDT 10A RI RGB 24V DC	MSM-22-MONX10A-B-BA0-B-RIRGB0244A0-S0NCB-S0NCNF-1252-C
3-119-732	MSM22Switch MO NX SPDT 10A RI RGB 24V DC	MSM-22-MONX10A-B-BA0-B-RIRGB0244A0-S0NCB-S0NCNF-1012-C
3-119-733	MSM22Switch MO NX SPDT 10A RI RGB 24V DC	MSM-22-MONX10A-B-BA0-B-RIRGB0244A0-S0NCB-S0NCNF-1018-C
3-120-085	MSM22Switch MO NX SPDT 10A AI RGB 24V DC	MSM-22-MONX10A-B-BA0-A-AIRGB0240A0-S0NCB-C0WTNF-1074-C
3-120-086	MSM22Switch MO NX SPDT 10A AI RGB 24V DC	MSM-22-MONX10A-B-BA0-A-AIRGB0240A0-S0NCB-C0WTNF-1075-C
3-120-088	MSM19Switch MO NX SPDT 5A AI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-120-089	MSM19Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C
3-120-091	MSM19Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-1074-C
3-120-103	MSM19Switch MO NX SPDT 5A AI 0RD 24V DC	MSM-19-MONX05A-B-BA0-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
3-120-106	MSM22Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-22-MONX05A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-0000-C

3-120-107	MSM22Switch MO NX SPDT 5A AI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-AI0WT0241A0-S0NCB-C0WTNF-0000-C
3-120-108	MSM22Switch MO NX SPDT 5A AI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-AI0WT0241A0-S0NCB-C0WTNF-1009-C
3-120-112	MSM19Switch MO NX SPDT 5A AI 0BL 24V DC	MSM-19-MONX05A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-1076-C
3-120-115	MSM19Switch MO NX SPDT 6A AI 0RD 24V DC	MSM-19-MONX06A-B-BA0-B-AI0RD0241A0-S0NCB-C0WTNF-0000-C
3-120-117	MSM22Switch MO NX SPDT 100mA AI 0RD S0	MSM-22-MONXA10-B-AA0-A-AI0RD0241A0-S0NCB-C0WTNF-1015-C
3-120-118	MSM22Switch MO NX SPDT 100mA AI 0GN S0	MSM-22-MONXA10-B-AA0-A-AI0GN0241A0-S0NCB-C0WTNF-1009-C
3-120-119	MSM22Switch MO NX SPDT 5A AI 0RD 24V DC	MSM-22-MONX05A-B-BA0-A-AI0RD0241A0-S0NCB-C0WTNF-0000-C
3-120-123	MSM22Switch MO NX SPDT 5A AI 0RD 24V DC	MSM-22-MONX05A-B-BA0-A-AI0RD0241A0-S0NCB-C0WTNF-1074-C
3-120-124	MSM22Switch MO NX SPDT 5A AI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-120-125	MSM22Switch MO NX SPDT 10A AI 0BL 24V DC	MSM-22-MONX10A-B-BA0-A-AI0BL0241A0-S0NCB-C0WTNF-1013-C
3-120-174	MSM16Switch MO NX SPDT 100mA S0 BK S0 BK	MSM-16-MONXA10-B-AA0-A-00000000000-S0BKB-S0BKNF-1254-C
3-120-262	MSM22Switch LA NO DPST 16A AI 0GN 24V DC	MSM-22-LANO16A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-1074-C
3-120-362	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BE0-A-RI0WT0244A0-S0NCB-S0NCNF-0000-C
3-120-485	MSM22Switch LA NO DPST 16A RI 0GN 24V DC	MSM-22-LANO16A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1065-C
3-120-537	MSM19Switch LA NO DPST 16A RI 0BL 24V DC	MSM-19-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1077-A
3-120-538	MSM19Switch LA NO SPST 16A AI 0BL 24V DC	MSM-19-LANO16A-A-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-1077-C
3-120-688	MSM22Switch MO NO SPST 100mA RI 0GY S0	MSM-22-MONOA10-A-AF0-A-RI0GY00R4F0-S0NCB-S0NCNF-0000-F
3-120-828	MSM30Switch MO NX SPDT 100mA S1 NC S1 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S1NCA-S1NCNF-1145-C
3-120-840	MSM30Switch MO NX SPDT 100mA S1 NC S1 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S1NCA-S1NCNF-0000-C
3-120-868	MSM30Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-30-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1255-C
3-121-133	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-0000-C
3-121-135	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1256-C
3-121-136	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1257-C
3-121-137	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1258-C
3-121-138	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1259-C
3-121-140	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1260-C
3-121-141	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1261-C
3-121-142	MSM22Switch MO NX SPDT 5A RI 0YL 24V DC	MSM-22-MONX05A-B-BA0-A-RI0YL0244A0-S0NCB-S0NCNF-1262-C
3-121-144	MSM22Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-22-MONX05A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-1263-C
3-121-145	MSM22Switch MO NX SPDT 5A RI 0RD 24V DC	MSM-22-MONX05A-B-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-1264-C
3-121-146	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1265-C
3-121-176	MSM22Switch MO NX SPDT 100mA AI 0WT S0	MSM-22-MONXA10-B-AA0-A-AI0WT0240A0-S0NCB-C0WTNF-1075-C
3-121-177	MSM22Switch MO NX SPDT 100mA AI 0YL S0	MSM-22-MONXA10-B-AA0-A-AI0YL0240A0-S0NCB-C0WTNF-1049-C
3-121-474	MSM22Switch LA NO DPST 16A AI 0GN 24V DC	MSM-22-LANO16A-C-BA4-A-AI0GN0241A0-S0NCB-C0WTNF-1077-C
3-121-593	MSM22Switch LA NO SPST 12A RI 0YL 24V DC	MSM-22-LANO12A-A-BA4-A-RI0YL0247A0-S0NCB-S0NCNF-1266-C
3-121-679	MSM19Switch MO NX DPDT 5A AI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-AI0GN0241A0-S0NCB-C0WTNF-0000-C
3-121-779	MSM19Switch LA NO DPST 16A RI 0GN 24V DC	MSM-19-LANO16A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1077-C
3-122-039	MSM19Switch LA NO SPST 16A AI 0BL 24V DC	MSM-19-LANO16A-A-BA4-A-AI0BL0241A0-S0NCB-C0WTNF-1074-C
3-122-088	MSM19Switch LA NO DPST 16A RI 0GN 24V DC	MSM-19-LANO16A-C-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C

3-122-296	MSM16Switch MO NX SPDT 100mA AI 0WT S0	MSM-16-MONXA10-B-AA0-A-AI0WT0050A0-S0NCB-C0WTFN-0000-C
3-122-358	MSM19Switch LA NO SPST 12A RI 0GB 24V DC	MSM-19-LANO12A-A-BA4-A-RI0GB0240F0-S1NCB-S1NCNF-0000-C
3-122-436	MSM19Switch MO NX SPDT 10A RI RGB 24V DC	MSM-19-MONX10A-B-BA0-A-RIRGB0244A0-S1NCB-S1NCNF-0000-C
3-122-503	MMS22Switch LA NO SPDT 12A RI 0WT 24V DC	MSM-22-LANO12A-B-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-1074-C
3-122-638	MMS22Switch MO NO SPST 100mA RI 0CY S0	MSM-22-MONOA10-A-AF1-B-RI0CY0244F1-S0NCB-S0NCNF-0000-C
3-122-681	MMS22Switch MO NX SPDT 10A RI 0RD 24V DC	MSM-22-MONX10A-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-1073-C
3-123-077	MMS30Switch MO NX SPDT 100mA RI RGB S0	MSM-30-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-1074-C
3-123-555	MMS19Switch MO NX DPDT 100mA RI 0WT S0	MSM-19-MONXA10-D-AA0-A-RI0WT0054A0-S0NCB-S0NCNF-0000-C
3-123-630	MMS16Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-16-MONXA10-B-AF1-B-00000000000-S0NCA-S0NCNF-0000-C
3-123-641	MMS30Switch MO NO SPST 6A S0 NC A0 RD	MSM-30-MONO06A-A-BF1-B-00000000000-S0NCA-A0RDNF-0000-C
3-123-655	MMS30Switch MO NX SPDT 100mA RI RGB S0	MSM-30-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-1049-C
3-123-821	MMS16Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-16-MONXA10-B-AA0-A-00000000000-S0NCA-S0NCNF-0000-A
3-123-988	MMS22Switch LA NO SPST 12A S0 NC S0 NC	MSM-22-LANO12A-A-BA4-A-00000000000-S0NCB-S0NCNF-1075-C
3-124-072	MMS22Switch S0 NC S0 NC	MSM-22-0000000-0-000-0-00000000000-S0NCB-S0NCNF-0000-0
3-124-337	MMS19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-A00-A-00000000000-S0NCB-S0NCNF-1047-C
3-125-228	MMS22Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1267-C
3-125-229	MMS22Switch MO NX SPDT 100mA RI 0GN S0	MSM-22-MONXA10-B-AA0-A-RI0GN0244A0-S0NCB-S0NCNF-1251-C
3-125-283	MMS16Switch MO NO SPST 100mA S0 NC S0 NC	MSM-16-MONOA10-A-AF1-A-00000000000-S0NCA-S0NCNF-0000-C
3-125-835	MMS19Switch MO NX SPDT 100mA AI 0RD S0	MSM-19-MONXA10-B-AA0-A-AI0RD0125A0-S0NCB-C0WTFN-1268-C
3-125-836	MMS19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN0054A0-S0NCB-S0NCNF-1271-C
3-125-844	MMS19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1269-C
3-125-845	MMS19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1270-C
3-126-108	MMS19Switch LA NO DPST 12A AI 0GN 12V DC	MSM-19-LANO12A-C-BA4-A-AI0GN0121A0-S0NCB-C0WTFN-1077-C
3-126-371	MMS22Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-22-MONX05A-D-BA0-A-RI0BL0244A0-S0NCB-S0NCNF-1074-C
3-126-418	MMS19Switch MO NX DPDT 5A RI 0BL 5V DC	MSM-19-MONX05A-D-BA0-A-RI0BL0054A0-S0NCB-S0NCNF-0000-C
3-126-669	MMS19Switch MO NX SPDT 100mA A0 NC A0 NC	MSM-19-MONXA10-B-AA0-A-00000000000-A0NCA-A0NCNF-0000-C
3-126-681	MMS19Switch MO NX DPDT 10A A0 NC A0 NC	MSM-19-MONX10A-D-BA0-A-00000000000-A0NCA-A0NCNF-0000-C
3-126-829	MMS22Switch MO NX SPDT 100mA RI 0GO S0	MSM-22-MONXA10-B-AA0-A-RI0GO0054A0-S0NCB-S0NCNF-1273-F
3-126-830	MMS22Switch MO NX SPDT 100mA A0 RD S0 NC	MSM-22-MONXA10-B-AA0-A-00000000000-A0RDB-S0NCNF-1274-F
3-126-831	MMS22Switch MO NX SPDT 100mA AI 0GN S0	MSM-22-MONXA10-B-AA0-A-AI0GN0241A0-S0NCB-C0WTFN-1275-F
3-126-924	MMS19Switch MO NX SPDT 5A PI 0BL S0 NC	MSM-19-MONX05A-B-BE0-A-PI0BL00R0A0-S0NCB-S0NCNF-1074-C
3-127-043	MMS22Switch LA NO SPST 16A RI 0RD 24V DC	MSM-22-LANO16A-A-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-1074-C
3-127-342	MMS22Switch MO NX SPDT 100mA RI 0BL S0	MSM-22-MONXA10-B-AA0-A-RI0BL0244A0-S0NCB-S0NCNF-1272-C
3-127-436	MMS19Switch MO NX SPDT 5A RI 0WT 12V DC	MSM-19-MONX05A-B-BA0-A-RI0WT0124A0-S0NCB-S0NCNF-0000-C
3-127-439	MMS19Switch LA NO DPST 16A RI 0WT 12V DC	MSM-19-LANO16A-C-BA4-A-RI0WT0127A0-S0NCB-S0NCNF-0000-C
3-127-715	MMS19Switch MO NX SPDT 6A RI 0BL 24V DC	MSM-19-MONX06A-B-BA0-B-RI0BL0240A0-S0NCB-S0NCNF-1073-C
3-127-716	MMS19Switch MO NX SPDT 6A RI 0BL 24V DC	MSM-19-MONX06A-B-BA0-B-RI0BL0244A0-S0NCB-S0NCNF-1046-C
3-127-717	MMS19Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-19-MONX06A-B-BA0-B-RI0GN0244A0-S0NCB-S0NCNF-1047-C
3-127-718	MMS19Switch MO NX SPDT 6A RI RGB 24V DC	MSM-19-MONX06A-B-BA0-B-RIRGB0244A0-S0NCB-S0NCNF-1072-C

3-127-720	MSM19Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-19-MONX06A-B-BA0-B-RI0GN0244A0-S0NCB-S0NCNF-1048-C
3-127-959	MSM19Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
3-128-222	MSM30Switch MO NX SPDT 10A RI RGB 24V DC	MSM-30-MONX10A-B-BA0-A-RIRGB0244A0-S0NCB-S0NCNF-1076-C
3-128-295	MSM24Switch MO NX SPDT 10A S0 NC S0 NC	MSM-24-MONX10A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-A
3-128-297	MSM19Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1072-C
3-128-298	MSM19Switch MO NX DPDT 5A RI 0BL 24V DC	MSM-19-MONX05A-D-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-1073-C
3-128-299	MSM19Switch LA NO DPST 12A RI 0RD 24V DC	MSM-19-LANO12A-C-BA4-A-RI0RD0240A0-S0NCB-S0NCNF-1074-C
3-128-320	MSM30Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-30-MONX05A-D-0A0-0-RI0GN0247A0-S0NCB-S0NCNF-0000-C
3-128-342	MSM30Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-30-MONX05A-B-BA0-A-RI0WT0244A0-S0NCB-S0NCNF-1074-C
3-128-345	MSM30Switch MO NX SPDT 5A S0 NC S0 NC	MSM-30-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1114-C
3-128-353	MSM30Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1077-C
3-128-354	MSM30Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-30-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1049-C
3-128-487	MSM19Switch MO NX SPDT 5A RI 0BL 12V DC	MSM-19-MONX05A-B-BA0-A-RI0BL0124A0-S0NCB-S0NCNF-0000-C
3-128-507	MSM19Switch MO NX SPDT 5A A0 RD A0 RD	MSM-19-MONX05A-B-BA0-A-00000000000-A0RDB-A0RDNF-0000-C
3-128-603	MSM24Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-24-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1050-A
3-128-785	MSM19Switch MO NX DPDT 10A RI 0RD 24V DC	MSM-19-MONX10A-D-BA0-A-RI0RD0244A0-S0NCB-S0NCNF-1074-C
3-128-890	MSM22Switch MO NX SPDT 5A A0 BK A0 BK	MSM-22-MONX05A-B-BA0-A-00000000000-A0BKA-A0BKNF-0000-B
3-128-961	MSM30Switch MO NO SPST 6A RI 0BL 24V DC	MSM-30-MONO06A-A-BF1-B-RI0BL0244A0-S0CUB-S0CUNF-0000-C
3-129-019	MSM30Switch MO NO SPST 6A S0 CU S0 CU	MSM-30-MONO06A-A-BF1-B-00000000000-S0CUA-S0CUNF-0000-C
3-129-281	MSM19Switch MO NX SPDT 100mA RI 0GN S0	MSM-19-MONXA10-B-AA0-A-RI0GN00R0A0-S0NCB-S0NCNF-0000-C
3-129-333	MSM19Switch MO NX SPDT 100mA RI 0BL S0	MSM-19-MONXA10-B-AA0-A-RI0BL0054A0-S0NCB-S0NCNF-0000-C
3-129-461	MSM22Switch MO NX SPDT 5A S0 NC S0 NC	MSM-22-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1276-C
3-129-469	MSM30Switch MO NX SPDT 5A RI 0BL 24V DC	MSM-30-MONX05A-B-BA0-A-RI0BL0240A0-S0NCB-S0NCNF-1008-C
3-129-496	MSM22Switch LA NO DPST 16A RI 0RD 12V DC	MSM-22-LANO16A-C-BA4-A-RI0RD0124A0-S0NCB-S0NCNF-0000-C
3-129-510	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCB-S0NCNF-1009-C
3-129-511	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCB-S0NCNF-1013-C
3-129-512	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCB-S0NCNF-1015-C
3-129-513	MSM19Switch MO NX SPDT 5A S0 NC S0 NC	MSM-19-MONX05A-B-B00-A-00000000000-S0NCB-S0NCNF-1018-C
3-129-606	MSM19Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-1074-C
3-129-672	MSM19Switch LA NO DPST 12A A0 RD A0 RD	MSM-19-LANO12A-C-BA4-A-00000000000-A0RDB-A0RDNF-0000-C
3-129-679	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0243A0-S0NCB-S0NCNF-1004-C
3-129-680	MSM22Switch MO NX SPDT 5A RI 0WT 24V DC	MSM-22-MONX05A-B-BA0-A-RI0WT0243A0-S0NCB-S0NCNF-1006-C
3-129-774	MSM30Switch MO NX DPDT 5A RI 0YL 24V DC	MSM-30-MONX05A-D-BA0-A-RI0YL0240A0-S0NCB-S0NCNF-0000-C
3-129-971	MSM24Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-24-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1074-A
3-129-978	MSM22Switch LA NO SPST 16A RI 0GN 24V DC	MSM-22-LANO16A-A-BA4-A-RI0GN0240A0-S0NCB-S0NCNF-1074-C
3-130-290	MSM22Switch MO NX SPDT 100mA PI 0RD S2	MSM-22-MONXA10-B-AA0-B-PI0RD00R0A0-S2NCB-S2NCNF-1163-C
3-130-305	MSM22Switch MO NX SPDT 100mA PI 0RD S2	MSM-22-MONXA10-B-AA0-B-PI0RD00R0A0-S2NCB-S2NCNF-0000-C
3-130-596	MSM19Switch MO NX DPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-D-BA0-A-RI0GN0240A0-S0NCB-S0NCNF-1277-C
3-130-647	MSM30Switch MO NX SPDT 5A RI 0GN 12V DC	MSM-30-MONX05A-B-BA0-A-RI0GN0120A0-S0NCB-S0NCNF-0000-C

3-130-822	MSM30Switch MO NX SPDT 100mA RI 0RD S0	MSM-30-MONXA10-B-AA0-A-RI0RD0240A0-S0NCB-S0NCNF-0000-F
3-130-930	MSM22Switch MO NX SPDT 100mA PI 0RD S2	MSM-22-MONXA10-B-AA0-B-PI0RD00R0A0-S2NCB-S2NCNF-1278-C
3-131-073	MSM24Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-24-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1279-A
3-131-074	MSM24Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-24-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-1068-A
3-131-273	MSM19Switch LA NO DPST 16A S0 NC S0 NC	MSM-19-LANO16A-C-BA4-A-00000000000-S0NCB-S0NCNF-1253-A
3-131-548	MSM22Switch LA NO DPST 12A S0 NC S0 NC	MSM-22-LANO12A-C-BA4-A-00000000000-S0NCB-S0NCNF-0000-C
3-131-573	MSM19Switch MO NX SPDT 100mA RI RGB S0	MSM-19-MONXA10-B-AA0-A-RIRGB0244A0-S0NCB-S0NCNF-1076-C
3-131-574	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-A00-A-00000000000-S0NCB-S0NCNF-1075-C
3-131-740	MSM22Switch MO NX DPDT 5A S0 NC S0 NC	MSM-22-MONX05A-D-BA0-A-00000000000-S0NCA-S0NCNF-1077-C
3-131-780	MSM19Switch LA NO DPST 16A RI 0BL 24V DC	MSM-19-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1071-C
3-131-800	MSM22Switch LA NO SPST 12A AI 0RD 24V DC	MSM-22-LANO12A-A-BA4-A-AI0RD0241A0-S0NCB-C0WTFN-1057-C
3-131-806	MSM22Switch MO NX SPDT 100mA RI RGB S0	MSM-22-MONXA10-B-AA0-B-RIRGB0244A0-S0NCB-S0NCNF-1074-C
3-131-836	MSM22Switch LA NO DPST 16A RI 0BL 24V DC	MSM-22-LANO16A-C-BA4-A-RI0BL0240A0-S0NCB-S0NCNF-1077-C
3-132-026	MSM19Switch LA NO DPST 12A RI 0GN 12V DC	MSM-19-LANO12A-C-BA4-A-RI0GN0127A0-S0NCB-S0NCNF-1077-C
3-132-119	MSM19Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-19-MONXA10-B-A00-A-00000000000-S0NCB-S0NCNF-1280-C
3-132-395	MSM24Switch MO NX SPDT 100mA S0 NC S0 NC	MSM-24-MONXA10-B-AA0-A-00000000000-S0NCB-S0NCNF-0000-A
3-132-396	MSM24Switch MO NX SPDT 5A S0 NC S0 NC	MSM-24-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-0000-A
3-132-861	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BA0-A-00000000000-S0NCB-S0NCNF-1050-C
3-132-877	MSM30Switch MO NX SPDT 6A S0 NC S0 NC	MSM-30-MONX06A-B-BA0-B-00000000000-S0NCA-S0NCNF-0000-C
3-132-952	MSM22Switch LA NO DPST 12A PI 0GN S0 NC	MSM-22-LANO12A-C-BA4-A-PI0GN00R0A0-S0NCB-S0NCNF-1077-C
3-133-637	MSM16Switch MO NX SPDT 5A S0 NC S0 NC	MSM-16-MONX05A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-F
3-133-703	MSM16Switch MO NO SPST 100mA S0 NC S0 NC	MSM-16-MONOA10-A-AF1-A-00000000000-S0NCA-S0NCNF-0000-A
3-134-657	MSM22Switch MO NX SPDT 10A S0 NC S0 NC	MSM-22-MONX10A-B-BA0-A-00000000000-S0NCA-S0NCNF-0000-C
3-135-024	MSM19Switch MO NX SPDT 100mA AI RGB S0	MSM-19-MONXA10-B-AA0-A-AIRGB0244A0-S0NCB-C0WTFN-1037-C
3-135-025	MSM19Switch MO NX SPDT 100mA AI RGB S0	MSM-19-MONXA10-B-AA0-A-AIRGB0244A0-S0NCB-C0WTFN-1038-C
3-135-231	MSM22Switch LA NO SPST 12A RI 0WT 24V DC	MSM-22-LANO12A-A-BA4-A-RI0WT0240A0-S0NCB-S0NCNF-1075-C
3-135-251	MSM19Switch S0 NC A0 GN	MSM-19-0000000-0-000-0-00000000000-S0NCA-A0GNNF-0000-C
3-135-262	MSM19Switch S0 NC A0 RD	MSM-19-0000000-0-000-0-00000000000-S0NCA-A0RDNF-0000-C
3-135-884	MSM22Switch MO NX SPDT 100mA AI RGB S0	MSM-22-MONXA10-B-AA0-A-AIRGB0244A0-S0NCB-C0WTFN-1200-C
3-136-061	MSM19Switch MO NX SPDT 5A RI 0GN 24V DC	MSM-19-MONX05A-B-BA0-A-RI0GN0244A0-S0NCB-S0NCNF-1074-C
3-136-151	MSM30Switch MO NX DPDT 5A PI 0BL S0 NC	MSM-30-MONX05A-D-BA0-A-PI0BL00R0A0-S0NCB-S0NCNF-0000-C
3-136-656	MSM19Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-19-MONX06A-B-BA0-B-RI0GN0244A0-S0NCB-S0NCNF-1049-C
3-136-657	MSM19Switch MO NX SPDT 6A RI 0GN 24V DC	MSM-19-MONX06A-B-BA0-B-RI0GN0244A0-S0NCB-S0NCNF-1050-C
3-126-722	MSS19 Switch MO NO 100mA LI RGB P2 OQ B	MSS-19-MONOA10C0-LIRGB00RC0-P2OQB-S0NCWF-0000-K
3-126-723	MSS19 Switch LA NO 100mA LI RGB P2 OQ B	MSS-19-LANOA10C0-LIRGB00RC0-P2OQB-S0NCWF-0000-K
3-126-726	MSS19 Switch MO NO 100mA P3 RD B	MSS-19-MONOA10C0-00000000000-P3RDB-S0NCWF-0000-K
3-126-727	MSS19 Switch MO NO 100mA P3 GN B	MSS-19-MONOA10C0-00000000000-P3GNB-S0NCWF-0000-K
3-126-728	MSS19 Switch MO NO 100mA P3 BL B	MSS-19-MONOA10C0-00000000000-P3BLB-S0NCWF-0000-K
3-126-729	MSS19 Switch MO NO 100mA P3 BK B	MSS-19-MONOA10C0-00000000000-P3BKB-S0NCWF-0000-K

3-126-730	MSS19 Switch MO NO 100mA P3 GE B	MSS-19-MONOA10C0-0000000000-P3GEB-S0NCWF-0000-K
3-126-731	MSS19 Switch MO NO 100mA P3 YL B	MSS-19-MONOA10C0-0000000000-P3YLB-S0NCWF-0000-K
3-126-732	MSS19 Switch MO NO 100mA P3 WT B	MSS-19-MONOA10C0-0000000000-P3WTB-S0NCWF-0000-K
3-126-733	MSS19 Switch MO NO 100mA P3 OR B	MSS-19-MONOA10C0-0000000000-P3ORB-S0NCWF-0000-K
3-126-734	MSS19 Switch LA NO 100mA P3 RD B	MSS-19-LANOA10C0-0000000000-P3RDB-S0NCWF-0000-K
3-126-735	MSS19 Switch LA NO 100mA P3 GN B	MSS-19-LANOA10C0-0000000000-P3GNB-S0NCWF-0000-K
3-126-736	MSS19 Switch LA NO 100mA P3 BL B	MSS-19-LANOA10C0-0000000000-P3BLB-S0NCWF-0000-K
3-126-737	MSS19 Switch LA NO 100mA P3 BK B	MSS-19-LANOA10C0-0000000000-P3BKB-S0NCWF-0000-K
3-126-738	MSS19 Switch LA NO 100mA P3 GE B	MSS-19-LANOA10C0-0000000000-P3GEB-S0NCWF-0000-K
3-126-739	MSS19 Switch LA NO 100mA P3 YL B	MSS-19-LANOA10C0-0000000000-P3YLB-S0NCWF-0000-K
3-126-740	MSS19 Switch LA NO 100mA P3 WT B	MSS-19-LANOA10C0-0000000000-P3WTB-S0NCWF-0000-K
3-126-741	MSS19 Switch LA NO 100mA P3 OR B	MSS-19-LANOA10C0-0000000000-P3ORB-S0NCWF-0000-K
3-126-758	MSS22 Switch MO NO 100mA LI RGB P2 OQ B	MSS-22-MONOA10C0-LIRGB00RC0-P2OQB-S0NCWF-0000-K
3-126-759	MSS22 Switch LA NO 100mA LI RGB P2 OQ B	MSS-22-LANOA10C0-LIRGB00RC0-P2OQB-S0NCWF-0000-K
3-126-762	MSS22 Switch MO NO 100mA P3 RD B	MSS-22-MONOA10C0-0000000000-P3RDB-S0NCWF-0000-K
3-126-763	MSS22 Switch MO NO 100mA P3 GN B	MSS-22-MONOA10C0-0000000000-P3GNB-S0NCWF-0000-K
3-126-764	MSS22 Switch MO NO 100mA P3 BL B	MSS-22-MONOA10C0-0000000000-P3BLB-S0NCWF-0000-K
3-126-765	MSS22 Switch MO NO 100mA P3 BK B	MSS-22-MONOA10C0-0000000000-P3BKB-S0NCWF-0000-K
3-126-766	MSS22 Switch MO NO 100mA P3 GE B	MSS-22-MONOA10C0-0000000000-P3GEB-S0NCWF-0000-K
3-126-767	MSS22 Switch MO NO 100mA P3 YL B	MSS-22-MONOA10C0-0000000000-P3YLB-S0NCWF-0000-K
3-126-768	MSS22 Switch MO NO 100mA P3 WT B	MSS-22-MONOA10C0-0000000000-P3WTB-S0NCWF-0000-K
3-126-769	MSS22 Switch MO NO 100mA P3 OR B	MSS-22-MONOA10C0-0000000000-P3ORB-S0NCWF-0000-K
3-126-770	MSS22 Switch LA NO 100mA P3 RD B	MSS-22-LANOA10C0-0000000000-P3RDB-S0NCWF-0000-K
3-126-771	MSS22 Switch LA NO 100mA P3 GN B	MSS-22-LANOA10C0-0000000000-P3GNB-S0NCWF-0000-K
3-126-772	MSS22 Switch LA NO 100mA P3 BL B	MSS-22-LANOA10C0-0000000000-P3BLB-S0NCWF-0000-K
3-126-773	MSS22 Switch LA NO 100mA P3 BK B	MSS-22-LANOA10C0-0000000000-P3BKB-S0NCWF-0000-K
3-126-774	MSS22 Switch LA NO 100mA P3 GE B	MSS-22-LANOA10C0-0000000000-P3GEB-S0NCWF-0000-K
3-126-775	MSS22 Switch LA NO 100mA P3 YL B	MSS-22-LANOA10C0-0000000000-P3YLB-S0NCWF-0000-K
3-126-776	MSS22 Switch LA NO 100mA P3 WT B	MSS-22-LANOA10C0-0000000000-P3WTB-S0NCWF-0000-K
3-126-777	MSS22 Switch LA NO 100mA P3 OR B	MSS-22-LANOA10C0-0000000000-P3ORB-S0NCWF-0000-K
3-126-793	MSS30 Switch MO NO 100mA LI RGB P2 OQ B	MSS-30-MONOA10C0-LIRGB00RC0-P2OQB-S0NCWF-0000-K
3-126-794	MSS30 Switch LA NO 100mA LI RGB P2 OQ B	MSS-30-LANOA10C0-LIRGB00RC0-P2OQB-S0NCWF-0000-K
3-126-797	MSS30 Switch MO NO 100mA P3 RD B	MSS-30-MONOA10C0-0000000000-P3RDB-S0NCWF-0000-K
3-126-798	MSS30 Switch MO NO 100mA P3 GN B	MSS-30-MONOA10C0-0000000000-P3GNB-S0NCWF-0000-K
3-126-799	MSS30 Switch MO NO 100mA P3 BL B	MSS-30-MONOA10C0-0000000000-P3BLB-S0NCWF-0000-K
3-126-800	MSS30 Switch MO NO 100mA P3 BK B	MSS-30-MONOA10C0-0000000000-P3BKB-S0NCWF-0000-K
3-126-801	MSS30 Switch MO NO 100mA P3 GE B	MSS-30-MONOA10C0-0000000000-P3GEB-S0NCWF-0000-K
3-126-802	MSS30 Switch MO NO 100mA P3 YL B	MSS-30-MONOA10C0-0000000000-P3YLB-S0NCWF-0000-K
3-126-803	MSS30 Switch MO NO 100mA P3 WT B	MSS-30-MONOA10C0-0000000000-P3WTB-S0NCWF-0000-K

3-126-804	MSS30 Switch MO NO 100mA P3 OR B	MSS-30-MONOA10C0-0000000000-P3ORB-S0NCWF-0000-K
3-126-805	MSS30 Switch LA NO 100mA P3 RD B	MSS-30-LANOA10C0-0000000000-P3RDB-S0NCWF-0000-K
3-126-806	MSS30 Switch LA NO 100mA P3 GN B	MSS-30-LANOA10C0-0000000000-P3GNB-S0NCWF-0000-K
3-126-807	MSS30 Switch LA NO 100mA P3 BL B	MSS-30-LANOA10C0-0000000000-P3BLB-S0NCWF-0000-K
3-126-808	MSS30 Switch LA NO 100mA P3 BK B	MSS-30-LANOA10C0-0000000000-P3BKB-S0NCWF-0000-K
3-126-809	MSS30 Switch LA NO 100mA P3 GE B	MSS-30-LANOA10C0-0000000000-P3GEB-S0NCWF-0000-K
3-126-810	MSS30 Switch LA NO 100mA P3 YL B	MSS-30-LANOA10C0-0000000000-P3YLB-S0NCWF-0000-K
3-126-811	MSS30 Switch LA NO 100mA P3 WT B	MSS-30-LANOA10C0-0000000000-P3WTB-S0NCWF-0000-K
3-126-812	MSS30 Switch LA NO 100mA P3 OR B	MSS-30-LANOA10C0-0000000000-P3ORB-S0NCWF-0000-K
3-132-513	CHS30 Switch MO NO 30mA P G0 20	CHS-30-MONOA03C0-0000000000-0000P-G020
3-132-515	CHS30 Switch MO NO 100mA AI RGB P4 BK P	CHS-30-MONOA10C0-AIRGB00RC0-P4BKP-G020
3-132-516	CHS30 Switch MO NO 2A AI RGB P4 BK P G0	CHS-30-MONO02AF0-AIRGB00RF0-P4BKP-G020