



Assembly Instructions

1) Strip the cable to the dimensions shown, cutting the centre conductor at approximately 30° angle. Take care not to nick the centre conductor or braid. Cutting the centre conductor at 30° facilitates easy entry of the conductor into the connector.


A = 6.4mm
B = 8mm




2) Twist the braid in a clockwise direction so that a minimum of 1.0mm dielectric is shown. Make sure to avoid loose or stray strands that could cause short circuits.



3) Insert the centre conductor into the guide hole in the rear insulator of the connector.



4) Firmly push the cable as far forward as possible and screw the connector hex back end onto the cable in a clockwise direction until it stops.



CAD Issue	SN	2	30 July 01
First Issue	CBB	1	23 Jan 98
DESCRIPTION OF REVISION	APPVD	ISS	DATE

EMERSON
Network Power

Connectivity Solutions
7-13 Russel Way,
Widford Industrial Estate,
Chelmsford, Essex,
CM1 3AA, UK.
Tel: +44 (0) 1245 359515
Fax: +44 (0) 1245 358938

SCALE: Not To Scale

DIMENSIONS: mm

TOLERANCES:

DRAWN BY:

S Nash

CHECKED BY:

M Nielsen

APPROVED BY:

R Drennan

DATE:

30 July 01

DESCRIPTION:

Stripping and Assembly
Instructions for BNC Twist On
Plug

DRAWING NUMBER:

VAIB1301

PAGE: 1 OF 1